
REPAIR PARTS PRICE LIST

DURANT, STAR and RUGBY ALL MODELS

3

Effective Jan. 1st, 1930, to June 30th, 1930

DURANT MOTOR CO. OF CALIFORNIA
OAKLAND, CALIFORNIA



REPAIR PARTS PRICE LIST

DURANT, STAR and RUGBY
ALL MODELS

Effective January 1st, 1930 to June 30th, 1930

We have shown Standard Parts specifications in Parts Lists for infertua in to obtained at hardware dealers, Though Standard Parts stocked by

Manufactured by

DURANT MOTORS, INC.

5057 WOODWARD AVENUE DETROIT, MICH.

DURANT MOTOR CO. of NEW JERSEY
Elizabeth, N. J.

DURANT MOTOR CO. of CALIFORNIA
Oakland, Calif.

DURANT MOTOR CO. of MICHIGAN Lansing, Michigan

DURANT MOTORS of CANADA, LTD.

Toronto (Leaside), Ontario

TO ORDER PARTS

Parts Order forms are furnished to our dealers without charge, for ordering parts from us. This form should be used in each instance where written orders are sent in, and should be used as confirmations of telephone and telegraph orders.

The order in such an instance should be marked, "Confirmation of our wire (or telephone) of such and such a date," so there will be no possibility of making another shipment on the same order.

The information requested on the Parts Order should be filled out in detail in order to insure the quickest possible service. The part number, the full name as listed in Parts Book, the model, and the serial number of the car should be furnished in each instance. In case of any doubt, give a full description of the part, and if possible send the old part to us for duplication. Dealers should use "Returned Goods Form" furnished without charge.

In case of any error in the shipment of a parts order, claim must be made within 5 days from receipt of the shipment, and the original packing slip returned to us with full information concerning the error.

We cannot assume responsibility for delay or damage to goods while in transit. Our control ceases when we deliver shipments to the transportation companies. We will be very glad, however, in each instance to assist in tracing or placing claims. When the delay works a hardship on the customer, dealers should always wire for duplicate shipment.

STANDARD PARTS

We have shown Standard Parts specifications in Parts Lists for information only, as they can be obtained at hardware dealers. The only Standard Parts stocked by us are those shown in this Repair Parts Price List.

TO RETURN PARTS

When returning parts for inspection or replacement, our Return Goods Notice and Return Goods Tag must always be used. These are furnished the dealer, and full explanation of the necessary procedure will be found on each Return Goods Notice.

The information requested is absolutely necessary, and delay in receiving credit will always be the result of incomplete information in case these forms are not used.

When making claim for replacement of parts claimed defective, each part should be properly cleaned and tagged and returned to us, charges prepaid.

Parts returned will be credited only when adjudged faulty by the factory, and when claim is made in accordance with our instructions.

It is understood and agreed that our warranty, as published by us in our selling agreement, is null and void on any DURANT, RUGBY or STAR model where parts not made or sold by us have been used in replacement.

TELEGRAPHIC CODES

The Code Should Not Be Used When Ordering Parts by Mail

For the convenience and expense-saving in ordering parts by telegraph, we have used code words of 10 letters, to which the numerals 1, 2, 3, 4, 5, 6, 7, 8, 9, 0 are applicable.

When an order can be sent in a regular ten-word wire or a fifty-word night letter, we suggest that the code not be used, as nothing would be gained by so doing.

Telegraph companies will not accept night letters or day letters where code words are used.

The code word is DURAMOTIVE for DURANT, RUGBY and STAR parts, and the letters represent the figures just given. By using this system the figures of the part wanted are applied to the letters of the code word as they follow in sequence, and whatever combination this makes is the word to be used in the wire. For example:

D U R A M O T I V E

WARRANTY

Part No.	atsa rije of asologija ligila dalijen majes vije ila	Code
4361	Pring recreased the lieu of all origins warran	AROD
9282	es er lielglities on our part.	VUIU
9034	illico di belle es inscribel con di se est.	VERA
1785	tes indicates as economical test	DTIM

In case a standard part is desired, separate prefix letter with x.

discours servedo

n dun ob a W

radio to latera

Example: C-1 2 4 1 Hub Bolt % x 2"—16 U.S.S.

CxD U A D

abiano bemila

elitraried a establish stock outroot disade bilineauso as absent of the CODE PHRASES

	ners and the contract of the c
EXPRESS	Ship by express to
AMERICAN	Ship by American Express to
SOUTHEASTERN	Ship by Southeastern Express to
RADIUM	Ship our order No by express instead of freight
BEWARE	Ship our order No by freight instead of express
HELP	Trace shipment of our order No
ATTENTION	Carriers have been instructed to trace shipment of our order No
FREIGHT	Ship by freight to
PARCEL	Ship by parcel post to
GRAMO	Have you shipped the parts ordered in our telegram of?
норе	When will you ship the parts ordered in our telegram of?
QUERY	When did you ship the parts ordered in our letter of?
WAVER	Cancel our order by telegram of
CANDLE	Cancel our order by letter of
ADVERB	Add to our order by telegram of
ADCRAFT	Add to our order by letter of
LARGO	How and when did you ship our order?

WARRANTY

We warrant each new **DURANT**, **RUGBY** or **STAR** motor vehicle sold by us to be free from defects in material under normal use and service, our obligation under this warranty being limited to making good at our factory any part or parts thereof which shall within ninety (90) days after delivery of such vehicle to the original purchaser be returned to us, transportation charges prepaid, and which our examination shall disclose to our satisfaction to have been thus defective; this warranty being expressed in lieu of all other warranties expressed or implied and of all other obligations or liabilities on our part.

This warranty shall not apply to any vehicle which shall have been repaired or altered outside of our factory in any way, so as, in our judgment, to affect its stability or reliability, nor which

has been subject to misuse, negligence or accident.

We do not make any guaranty against, and we assume no responsibility for, any defect in metal or other material, or any part, device, or trade accessory that cannot be discovered by ordinary factory inspection.

It is understood and agreed that our Standard Warranty as shown above is null and void on any DURANT, RUGBY or STAR model where parts not made or sold by us are used in replacement or otherwise.

DURANT MODELS

- A-Four Cylinder-Touring, Roadster, Sedan, Coupe, Coach and B. M. Coupe
- B-Six Cylinder-Touring, Roadster, Sedan and Coupe
- M2—Four Cylinder—Commercial Chassis, Touring, Sport Roadster, Convertible Business Roadster, Sedan 4 Door, Sedan 2 Door, and Coupe
- M4—Four Cylinder—Touring, Sport Roadster, Sedan 4 Door, Sedan 2 Door, Coupe, Cabriolet, Deluxe Roadster and Deluxe Sedan
- 55-Six Cylinder-Touring, Brougham, Sedan 4 Door, Sedan 2 Door and Coupe
- 60—Six Cylinder—Touring, Sport Roadster, Sedan 4 Door, Sedan 2 Door, Coupe, Deluxe Cabriolet, Deluxe Roadster and Deluxe Sedan
- 65—Six Cylinder—Touring, Roadster, Brougham, Sedan 4 Door, Sedan 2 Door, Coupe and Cabriolet
- 75—Six Cylinder—Sedan 4 Door and Brougham
- 614-Six Cylinder-Sedan, 4 Door and Coupe

STAR MODELS

- C-Four Cylinder-Touring, Roadster, Sedan, Coupe and Commercial
- CC-Four Cylinder-Commercial
- F-Four Cylinder-Touring, Roadster, Sedan, Coach, Coupe and Coupster
- L-Six Cylinder-Fleetruck Chassis
- M—Four Cylinder—Commercial Chassis, Touring, Roadster, Coupster, Coupe, Coach and Sedan
- M2—Four Cylinder—Commercial Chassis, Touring, Sport Roadster, Convertible Business Roadster, Sedan 4 Door, Sedan 2 Door, and Coupe
- R—Six Cylinder—Touring, Roadster, Coupster, Coupe, Cabriolet, Coach, Sedan and Landau Sedan

RUGBY MODELS

- S4—Four Cylinder—Commercial Chassis, Convertible Business Roadster, and Panel Delivery
- X-Four Cylinder-Chassis with Cowl
- L-Six Cylinder-Chassis with Cowl and Chassis with Cab
- T-Six Cylinder-Chassis and Panel Delivery.

Part No.	Part Name	Price	Part No.	Part Name	Price
1007	Clutch Pressure Ring		1095	Lever Adjuster (Left)	\$0.75
1010	Rear Spring Clip Plate	.80	1096	Drive Pin	.08
1011	Oil Pump Body	4.50	1097	Universal Joint Yoke Center	1.25
1012 1013	Oil Pump Cover	.70	1098 1099	Lever Adjuster Wing Screw Bearing Adjuster Lock	.05
1013	Oil Pump GearOil Pump Drive Gear	.50	1101	Thrust Washer Pin	.04
1015	Oil Pump Idler Gear Shaft		1106	Spring Bumper	.10
1016	Oil Pump Packing Nut	.25	1111	Windshield Side Arm Collar	.04
1017	Generator Gasket	.02	1114 1116	Starter Bracket Bolt Nut	.04
1018 1019	Ball Bearing Double Row No. 305 Fly Wheel Bolt	$6.10 \\ .10$	1117	Step Hanger Brace	.15
1020	Bearing Cap Stud	.30	1118	Step Hanger (Center)	1.00
1022	Front Axle "I" Beam		1119	Starting Crank Bracket	. 50
1023	Center Bearing Cap	1.00	1120	Drive Pinion Sleeve	.60
1024	Center Bearing (Upper)	1.30	1121 1122	Drive Gear Washer	.07
1025 1027	Center Bearing (Lower) Differential Pinion Shaft	$\frac{1.30}{1.10}$	1123	Universal Joint Yoke Spacer	.35
1028	Differential Pinion Spacer	1.85	1124	Gasoline Cap Gasket	.08
1030	Valve Guide		1130	Rear Motor Support	8.50
1031	Oil Suction Pipe		1133	Front Spring Clip Plate	.25
1032 1033	Valve Rocker Arm Bushing		1135 1139	Battery Bracket	.16
1034	Valve Stem KeyValve Spring Cup	.04	1140	Radiator Bracket (Right)	.16
1035	Valve Push Rod Adj. Nut	.15	1141	Steering Gear Housing	8.00
1036	Tie Rod Yoke Ball	.50	1142	Housing Bushing (Outer)	.40
1037	Steering Knuckle Bushing		1143	Housing Bushing (Inner)	$\frac{.40}{2.20}$
1038 1040	Steering Arm Bushing Tie Rod Yoke Bolt		1145 1146	Pitman ArmPitman Arm Bolt	.10
1041	Differential Pinion		1147	Steering Gear Housing Cover	.80
1042	Oil Pump Body Gasket	.02	1148	Housing Cover Gasket	.02
1043	Oil Pump Cover Gasket		1149	Worm Wheel Thrust Screw	$.10 \\ .02$
1044	Thrust Bearing Lock		1150 1151	Worm Wheel Thrust Screw Washer Worm Wheel Thrust Screw Nut	.05
1045 1046	Differential Side Gear		1151	Steering Main Tube	5.50
1047	Cylinder Head Bolt (Short)		1154	Main Shaft Nut	.25
1048	Manifold Gasket	.02	1155	Worm Adjusting Nut	1.30
1049	Tie Rod Yoke		1156	Adjusting Nut Packing	.05
1051 1052	Rear Axle Shaft		1160 1161	Steering Worm Key	
1052	Valve SpringOil Pump Gear Shaft		1162	Main Tube Casing Bushing	.12
1054	Clutch Thrust Bearing		1163	Control Sector Bracket	.95
1055	Fly Wheel Nut Lock	.03	1164	Control Sector	.65
1056	Clutch Lifting Lever		1165	Throttle Lever Friction Shoe	1.10
1058 1059	Clutch Spring	.16	1166 1167	Friction Shoe Spring	The second secon
1060	Clutch Friction Ring		1168	Throttle Tube	1.15
1061	Clutch Collar	4.80	1169	Spark Lever	1.10
1062	Front Spring Shackle		1170	Horn Button	
1067 1069	Clamp Screw Nut LockLatch Rod Spring Cap		1171 1172	Horn Button Washer Spark Lever Friction Shoe	
1070	Drive Gear Retainer		1173	Spark Tube	1.15
1071	Idler Gear Bushing	.25	1174	Horn Wire	. 55
1072	Drive Gear Retainer Gasket	02	1175	Steering Mast Jacket	
1073	Main Drive Gear Bushing		1176	Steering Mast Jacket Bushing Instrument Board Bracket	
1074 1075	Sliding Gear (L. and R.)		1177 1178	Clutch Shaft Bearing	The second second
1075	Idler Gear ShaftSliding Gear Spacer		1182	Cam Shaft Gear	
1077	Countershaft Spacer		1183	Crank Shaft Gear	3.85
1078	Countershaft Sleeve Key	02	1184	Generator Gear	2.90
1079	Sliding Gear (H. and Int.)		1185	Rocker Arm Shaft Cap (Center)	.90
1080 1081	Second Speed Gear		1186 1187	Rocker Arms Shart Cap (Center) Rocker Arm Shart Cap (End)	
1082	Low Speed Gear		1188	Valve	1.05
1083	Countershaft Sleeve Bushing	25	1189	Cam Shaft Thrust Bearing	2.40
1084	Countershaft	50	1190	Manifold Gasket	
1085	Transmission Spline Shaft		1191	Cylinder Head Gasket Piston Ring (Std.)	
1087 1088	Differential CaseLatch Rod Spring		1192 1193	Front Bearing Cap	
1089	Ball Bearing No. 1306.		11.00	Note: Caps returned for new bearings will be	1221
1090	Ball Bearing No. 1207	4.60		accepted at full credit, less a charge of \$1.25 list	L MEST
1091	Front Wheel Hub Flange		1104	for new bearing.	. 65
1092 1093	Ball Bearing No. 1209		1194 1195	Front Bearing (Upper) Front Bearing (Lower)	
1093	Thrust Bearing Lock PinLever Adjuster (Right)		1196	Rear Bearing Cap	
1034	Level Aujuster (Itight)		1100	Tion Tomme Cabiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiiii	W

Part No.	Part Name	Price	Part No.	Part Name	Price
1197	Rear Bearing (Upper)		1304	Tail Lamp	
1198	Rear Bearing (Lower)	1.25	1305	Ammeter	
1199	Cylinder Head Cover	3.85	1307	Front Fender Apron Clip	.05
$\frac{1200}{1203}$	Valve Push Rod Cover Timing Gear Case Gasket	$\frac{2.90}{.03}$	1310 1311	Door Lock (Right) Door Lock (Left)	.65
1204	Timing Gear Case Cover	1.90	1313	Transmission Oil Guard (Front)	.05
1205	Timing Gear Case Cover Gasket	.12	1314	Transmission Oil Guard (Rear)	.03
1206	Tire Carrier Iron (Lower)	1.10	1315	Transmission Case Cover	5.50
1207	Tire Carrier Iron (Upper)	1.10	1316	Clutch Shaft	.90
1211	Steering Wheel		1318	Clutch Shaft Lever Clamp	.07
1212	Oil Filler Tube	.40	1319	Clutch Shaft Lever	1.10
1213 1214	Spring BoltSteering Knuckle King Pin	.80 .65	1321 1325	Transmission Case Stud (Small) Drive Oiler	$.05 \\ .04$
1215	Thrust Washer (Lower)	.35	1326	Grease Nipple Dust Cap	.06
1216	Thrust Washer (Upper)	.30	1327	Grease Nipple	.12
1220	Pull Rod Adjuster Nut	.05	1328	Speedometer Housing Gasket	.02
1221	Demountable Rim Wedge	.13	1329	Piston Pin Lock	.04
1222	Rear Wheel Hub	4.00	1330	Lighting and Ignition Switch	4.00
1223 1226	Piston Pin (Standard) Starting Motor Bracket	$\frac{.90}{1.85}$	1333 1337	Brake Ratchet Plate Screw	$03 \\ 10.00$
1227	Fly Wheel Underpan	.60	1338	Rear Fender (Left)	10.00
1228	Valve Tappet	1.30	1339	Side Apron (Left)	3.75
1229	Front Wheel Hub	4.50	1340	Side Apron (Right)	3.75
1230	Hub Cap	. 50	1341	First Top Bow	.80
1232	Radiator Outlet Hose	. 55	1345	Front Fender (Left)	14.00
1234 1235	Radiator Complete		1346	Front Fender (Right)	
1236	Valve Push RodVacuum Tank	$\frac{.45}{13.50}$	1348 1349	Hood Catch Bracket	$\frac{1.30}{.40}$
1238	Head Lamp (Right)		1350	Hood Catch Bracket	.40
1239	Head Lamp (Left)	6.00	1351	"Lift the Dot" Stud (Single)	.03
1240	Pedal Shaft Bracket (Outside)	.35	1352	Gear Shifter Fork	.85
1243	Clutch Pedal	1.40	1353	Shifter Shaft (L. and R.)	.35
1245	Shifter Lever Cap	.75	1354	Shifter Shaft (H. and Int.)	. 35
1246 1247	Shifter Lever Spring Cap Shifter Lever Spring	.07	1359 1360	Lock Plunger Spring (1¾ long) Brake Band Plate	.04
1248	Lock Plunger	.15	1362	"Durable Dot" Stud	.03
1249	Gear Shifter Lever Cap Screw	.07	1363	Timing Gear Case Screw	.08
1250	Universal Joint Spider (Front)	2.50	1364	Horn Bracket	.16
1251	Universal Joint Spider (Rear)	2.50	1365	Robe Rail Complete	1.70
1252	Universal Joint Disc	1.45	1367	Headlamp Tie Rod	.45
1253 1254	Cam Bracket Bushing Internal Brake Cam	$\frac{.25}{1.05}$	1369 1372	Rubber GrommetShifter Lever	$\frac{.02}{2.10}$
1255	Internal Brake Shoe Spring	.08	1373	Spark Tube Cam	.65
1256	Internal and External Brake Band Re-		1374	Throttle Tube Cam	.65
341	lease Spring $(1\frac{1}{2}" long)$.06	1375	Single Fuse Block	.18
1257	Internal Brake Cam Lever (Left)	.90	1376	Dash Lamp Complete	1.00
1259 1260	Bevel Drive Pinion and Shaft	8.00 9.00	1378 1379	Exhaust Pipe Flange	.35
1261	Ring Gear Drive Pinion Housing Oil Ring	.30	1380	Exhaust Pipe Gasket	.75
1262	Drive Pinion Bearing Spacer	.80	1382	Water Pump Shaft	1.60
1264	Drive Pinion Housing	3.75	1383	Water Pump Shaft Bearing	.60
1265	Water Pump Body	5.00	1384	Water Pump Shaft Bearing Nut	.04
1266	Water Pump Gasket	.03	1388	Universal Joint Yoke (Rear Axle)	7.75
1267	Water Pump Pulley Nut	.07	1389	Universal Joint Spider Plate	.50
1268 1269	Water Pump Packing Nut	.30 .05	1390 1391	Speedometer Housing Top Prop Nut, 1/16"	$\frac{2.00}{.06}$
1271	Oil Pan Gasket (End)	.05	1393	Cam Screw	.04
1272	Oil Pan Gasket (Side)	.05	1394	Escutcheon Plate	.18
1274	Valve Tappet Guide Plate	.15	1395	Trans. Spline Shaft Thrust Washer	.12
1275	Valve Tappet Guide Plug	.07	1396	Oil Pump Coupling Sleeve	.25
1276 1277	Valve Tappet Guide Spring	.03	1397 1398	Oil Pump Coupling Spring Universal Joint Yoke	.06
1278	Radiator Brace		1399	Universal Joint Disc Bolt (Long)	$7.75 \\ .06$
1279	Water Outlet and Fan Bracket	2.75	1400	Universal Joint Disc Bolt (Medium)	.05
1281	Fan Belt	1.30	1401	Universal Joint Disc Bolt (Short)	.04
1282	Rear Axle Truss Rod	.65	1403	Piston with Pin (Std.)	4.50
1283	Hand Brake Latch Rod	.35	1409	Speedometer Pinion	2.10
1284	Brake Ratchet Pawl	.12	1410	Speedometer Gear	3.00
1285 1286	Hand Brake Ratchet Swivel Joint Bushing	.20	1411 1412	Front Motor Screw (Short) "Durable Dot" Stud	.06
1287	Swivel Joint Pin	.02	1413	"Durable Dot" Button	.02
1288	Water Outlet Gasket	.02	1414	"Durable Dot" Stud	.02
1291	Battery Strap	. 60	1415	"Lift the Dot" Socket	.04
1303	Oil Pressure Gauge	2.00	1416	Carburetor	17.50

Part No.	Part Name	Price	Part No.	Part Name	Price
1417		\$0.20	1518	Motor Support Block	\$0.35
1419	Door Striker Plate	.17	1519	Starter Bracket Shell Bolt	.20
1421	Gasoline Tank Pipe	1.25	1520	Rear Motor Bolt	.13 .25
1422 1423	External Brake Band Anchor Plate	.35	1524 1525	Rear Spring Clip	9.00
1423	Rear Wheel Brake Drum	$3.50 \\ .01$	1526	Running Board Moulding (Outer)	.50
1425	Connecting Rod Shim	.04	1527	Running Board Moulding (Inner)	.25
1429	Accelerator Rocker Arm	.35	1529	Clutch Pedal Return Spring	.16
1430	Shut-off Cock	.30	1531	Hub Cap Wrench	.65
1432	Brake Cross Shaft Lever	.40	1532	External Brake Band (Right)	4.50
1434	Brake Idler Lever Bolt	.17	1533	External Brake Band (Left)	4.50
1435	Drive Pin with Nut	.10	1535	Service Pull Rod (Rear)	. 55
1439 1440	Steering Worm (Used with No. 1440).	2.90	1536	Brake Idler Lever Emergency Brake Pull Rod (Front)	.40
1440	Worm Wheel	$6.25 \\ .75$	1537 1538	Service Brake Pull Rod (Front)	.45
1442	Accelerator Push Rod Sleeve	.20	1539	Emergency Brake Pull Rod (Rear)	The state of the s
1443	Accelerator Foot Rest	.30	1546	Hose Clamp	
1444	Accelerator Button	.25	1549	Front Bearing Shim	.10
1445	Accelerator Foot Rest Sleeve	.30	1550	Center Bearing Shim	
1447	Internal Brake Band	3.25	1551	Rear Bearing Shim	
1448	External Brake Adjusting Rod	.65	1554	Universal Joint Spline Flange	
1449	Internal Brake Band Lining	1.45	1558	Swivel Joint Bushing	The state of the s
1450 1451	External Brake Band LiningExternal Brake Adjuster	1.55	1561 1562	Bow Socket (Left)	
1452	External Brake Adjusting Rod Nut	.12	1564	Fan Hub Gasket	
1453	Jam Nut	.05	1565	Tonneau Heel Carpet	the second second
1454	External Brake Band Spring	.05	1567	Steering Worm (R. D.)	3.75
1455	Control Tube Anchor Cap	.16	1568	Worm Wheel (R. D.)	
1456	Control Tube Anchor Plate	.02	1569	Pitman Arm (R. D.)	
1457	Ratchet Pawl Bolt Nut	.07	1571	Steering Gear Housing (R. D.)	6.75
1458	Ratchet Pawl Bolt	.05	1573	Fly WheelCrankshaft	14.50
1459 1460	Underpan (Left) Underpan (Right)	.95	1574 1581	Magneto Chain Guard Stud	.40
1462	Control Tube Anchor Spacer	.04	1582	Magneto Chain Guard Wing Nut	.19
1464	Throttle Control Tube	.50	1583	Magneto Drive Chain	
1465	Spark Control Tube	.50	1584	Magneto Drive Sprocket	1.70
1467	Spark Control Wire	.05	1585	Magneto Shaft Nut	19
1468	Throttle Control Wire	.13	1586	Magneto Sprocket Coupling	
1470	Spark Control Return Spring	.11	1591	Door Bumper	04
1472	Instrument Board Bolt	.09	1592	Door Bumper Plate	
1473 1475	Top Prop Nut Lock Demountable Clincher Rim	4.00	1599 1600	Exhaust Pipe Coupling	
1478	Demountable Rim Bolt Nut ($\frac{7}{16}$ "—20	4.00	1601	"Lift the Dot" Stud (Double)	
1110	S.A.E.)	.05	1602	Propeller Shaft	The second secon
1481	Brake Cross Shaft Bracket (Left)	.60	1603	Universal Joint Flange Yoke	. 2.30
1482	Brake Cross Shaft Bracket (Right)	.60	1604	Universal Joint Flange	
1483	Brake Cross Shaft Lever	.40	1605	Universal Joint Sleeve Yoke	
1484	Front Wheel Complete		1606	Universal Joint Outside Casing	
1485 1487	Rear Wheel Complete	.08	1608 1609	Universal Joint Dust CapOil Plug	
1489	Adjusting Nut Lock Nut	.07	1610	Joint Casing Spring Retainer Bolt	
1490	Front Cross Member	7.00	1611	Joint Bushing	
1491	Brake Pedal Spring	.25	1612	Joint Casing Spring Retainer	75
1492	Brake Pedal Spring Clip	.04	1613	Univ. Joint Casing Spring	
1495	Rear Motor Support Bracket (Left)	.25	1614	Univ. Joint Flange Yoke Bolt	
1496	Rear Motor Support Bracket (Right)		1615	Univ. Joint Retainer Bolt Nut	
1500	Spring Bracket Bushing	. 35	1616	Univ. Joint Flange Yoke Bolt Nut	
1501	Spring Bolt Elbow	.07	1617	Univ. Joint Flange (Trans. End)	
1502 1503	Rear Spring Front Bracket		1618 1620	Univ. Joint Packing Ring Univ. Joint Inside Casing	
1505	Spring Bolt	.18	1621	Univ. Joint Cross Bushing Ring	
1506	Clutch Friction Sector	.20	1624	Radiator Filler Cap Use N	
1507	Rear Spring Complete		1626	Radiator Filler Can Gasket	07
1508	Rear Spring Shackle	90	1628	Tubular Back Bone	. 10.50
1509	Front Spring Shackle (Inside)	25	1629	Exhaust Pipe Sleeve	30
1510	Front Spring Shackle (Outside)	20	1630	Exhaust Pipe Clamp	
1511	"Lift the Dot" Clinch Stud		1631	Exhaust Pipe(Picht)	
1512	Front Spring Rear Bracket	90	1632	Ext. Brake Toggle Lever (Right)	
1513 1514	Starting Crank Special Nut	65	1633 1635	Ext. Brake Toggle Lever (Left) Timing Gear Case	The second second
1515	Hood Sill (Left)	1.85	1636	Cam Shaft	. 14.50
1516	Hood Sill (Right)		• 1638	Cam Shaft Thrust Plate	65
1517	Radiator Splash Apron		1639	Drain Cock	

Part No.	Part Name	Price	Part No.	Part Name	Price
1640	Connecting Rod Complete	\$7.00	1777	Head Lamp Glass	\$0.55
	Note: Rod returned for new bearing will be		1778	Tail Lamp Plug Connector Socket	.40
	accepted at full credit (less a charge of \$2.25	The state of	1779	Tail Lamp Red Semaphore	.20
1200	list for new bearing.)	0.0	1780	Tail Lamp Semaphore Retaining Ring	.07
1641	Pinion Housing Shim (.005" Thick)	.06	1785	Rear Side Curtain (Left)	2.80
1644	Emergency Brake Lever Shaft	.10	1786 1789	Rear Side Curtain (Right)	2.80
1645 1647	Bearing Cap Stud Pin	1.10	1790	Clutch Plate and Shaft.	.02
1648	Steering Gear Bracket Clamp Oil Pump Shaft Key	.04	1794	Door Hinge Complete (Right)	8.25
1649	Front Wheel Bearing Dust Collar	.50	1795	Door Hinge Complete (Left)	.45
1650	Front Motor Screw	.15	1796	Lighting and Ignition Switch Key	.12
1652	Rear Wheel Hub Felt Oil Ring	.15	1797	Crank Shaft Pulley	2.25
1653	Wheel Puller Screw	.25	1802	Transmission Case	13.25
1654	Tire Carrier Iron (Side)	1.25	1803	Radiator Shell	6.50
1655	Tire Carrier Iron (Center)	1.25	1804	Valve Rocker Arm	.95
1659 1660	Fly Wheel Nut Lock	.03	1805 1807	Internal Cam Bracket with Bushing Rear Axle Housing (Left Half)	.90 20.25
1675	Pedal Adjusting ScrewBall Joint—Heavy	.25	1808	Rear Axle Housing (Right Half)	
1678	Oil Pump Cover	.40	1818	Rear Spring Clip	.09
1680	Oil Pump Drive Shaft	.80	1822	Front and Rear Spring Bushing	.40
1681	Oil Pump Driven Gear Shaft	.20	1830	Steering Knuckle (Right)	7.50
1682	Steering Knuckle Spindle Washer	.07	1831	Steering Knuckle (Left)	7.50
1683	Oil Pump Cover Gasket	.01	1832	Steering Knuckle Arm	2.10
1684	Magneto	40.00	1834	Main Drive Gear with Bushing, Sleeve	0 85
1685	Lighting and Ignition Switch (R.D.).	$\frac{4.00}{.02}$	1837	and Nut (7½2") long	6.75
1691 1693	Oil Pump Body GasketOil Pressure Gauge Pipe	.50	1842	Countershaft Sleeve Front Floor Carpet	$\frac{1.70}{5.00}$
1698	Throttle Rod—Upper (R.D.)	.50	1844	Shifter Lever Grip	.35
1708	Windshield Side Arm (Right)	5.50	1845	Water Pump Shaft Pulley	1.70
1709	Windshield Side Arm (Left)	5.50	1846	Rear Spring Horn (Right)	2.50
1712	Windshield Upper Glass	5.25	1847	Rear Spring Horn (Left)	2.50
1713	Windshield Lower Glass	4.50	1849	Demountable Rim Bolt Nut	.08
1714	Windshield Handle Screw	.10	1850	Internal Brake Cam Lever (Right)	.90
1715	Windshield Glass Clip	.17	1851 1866	Univ. Joint (Transmission End)	
1716 1717	Windshield Wing Nut Windshield Pivot Cup	.25	1867	External Brake Support Clip (Right) Windshield Side Arm (Left)	$\frac{.25}{5.50}$
1718	Windshield Pivot Plug	.13	1868	Windshield Side Arm (Right)	5.50
1719	Windshield Glass Clip Plug	.13	1879	Ball Bearing No. 1201	2.50
1720	Windshield Pivot Stud	.11	1880	Ball Bearing No. 1203	2.75
1723	Windshield Handle	.16	1885	Rear Door Complete—(Left)	14.75
1725	Windshield Glass Clip Screw	.03	1886 1887	Rear Door Complete—(Right) Universal Joint Spider Plate	
1726 1728	Windshield Pivot Plain Washer Tie Rod Yoke	1.60	1888	Universal Joint Driving Washer	.90
1731	Carburetor Float Complete	1.00	1898	Third Top Bow	.80
1732	Carburetor Inlet Valve Complete	1.00	1899	Second Top Bow	.80
1733	Carburetor Inlet Seat	.40	1900	Fourth Top Bow	1.30
1734	Carburetor Inlet Seat Gasket	.05	1901	External Brake Band Support Clip	.25
1735	Carburetor Inlet Screen	.15	1902 1903	Transmission Case Cover Gasket Running Board Nut	.02
1736 1737	Carb. Inlet Connection Nut Gasket Carburetor Inlet Connection Nut	.05	1904	Running Board Complete (Right)	4.75
1738	Carburetor Inlet Connection Nut	.50	1905	Running Board Complete (Left)	4.75
1739	Carburetor Nozzle Screw Plug Gasket	.05	1906	Steering Connecting Rod Adjusting	14.14
1741	Carburetor Float Bowl Cover	.30		Nut Steering Connecting Rod Spring Seat.	.20
1742	Carburetor Float Bowl Cover Screw .	.05	1907	Steering Connecting Rod Spring Seat.	.10
1743	By-Pass Adjusting Needle	.25	1908	Steering Connecting Rod Ball Seat	.10
1745	Carburetor By-Pass Plug	.20	1909	Steering Connecting Rod Spring	.16
1746 1748	Carburetor Plug Screw Gasket	.05	1911 1912	Demountable Rim Bolt Demountable Rim Wrench	.12
1748	Carburetor By-Pass Tube Assembly . Gas Restriction Nozzle	.15	1913	Front Wheel Complete	
1751	Carburetor Nozzle Air Tube Gasket .	.05	1914	Rear Wheel Complete	
1755	Carburetor Nozzle Sleeve Gasket	.05	1915	Demountable S. S. Rim	5.00
1756	Carburetor Lower Plug Screw	.05	1916	Demountable Rim Wedge	.16
1757	Carburetor Lower Plug Screw Gasket.	.05	1917	Demountable Rim Bolt Nut	.07
1758	Carburetor Upper Plug Screw	.05	1918	Clutch Spring Retainer	.15
1759	Carburetor Upper Plug Screw Gasket.	.05	1919 1920	Bow Socket (Left)	4.75
1760 1761	Carburetor Throttle Shutter Carburetor Shutter Shaft	.25	1920	Steering Connecting Rod (R. D.)	$\frac{4.75}{5.00}$
1761	Carburetor Shutter Shaft Screw	.05	1922	Steering Connecting Rod	2.25
1764	Carburetor Throttle Lever Set Screw.	.05	1923	Steering Connecting Rod Plug	.55
1766	Choke Wire Connecting Screw	.05	1924	Steering Connecting Rod Plug	.45
1767	Carburetor Choke Wire Connection	.05	1925	Steering Connecting Rod Ball Seat	.15
1772	No. 2A 20 Ampere Fuse	.05	1926	Steering Connecting Rod Spring Seat.	.15
1775	Head Lamp Focus Screw	2.10	1927 1928	Steering Connecting Rod Spring Oil Level Gauge	.10
1776	Head Lamp Rim	4.10	1020	on motor daugo	.00

Part No.	Part Name	Price	Part No.	Part Name	Price
1931	Tube Compression Lip	\$0.65	2039	Front Side Curtain (Left)	\$3.85
1932	Tail Lamp Wire Clip	. 03	2040	Front Side Curtain (Right)	3.85
1935	Hood Catch Bracket Spacer	.04	2041	Center Side Curtain (Left)	3.25
1936 1937	Rear Curtain Light	$\frac{5.50}{1.90}$	2042 2043	Center Side Curtain (Right)	$\frac{3.25}{2.80}$
1938	Rear Curtain Light Glass	1.90	2044	Rear Side Curtain (Right)	2.80
1940	Curtain Rod Socket	.10	2045	Top Complete Less Side Curtains	55.00
1942	Curtain Rod—(Front Right)	.25	2046	Front Side Curtain (Right)	3.60
1943	Curtain Rod—(Front Left)	.25	2047	Front Side Curtain (Left)	3.60
1948	Head Lamp Plug Connector	.75	2048	Center Side Curtain (Right)	3.25
1950 1951	Curtain Rod (Rear Right) Curtain Rod (Rear Left)	.25 .25	2049 2050	Center Side Curtain (Left)	$\frac{3.25}{2.50}$
1952	Clutch Cover Plate Complete		2051	Rear Spring Horn (Left)	2.50
1953	Tire Carrier Wedge	.25	2055	Windshield Upper Panel with Glass	16.50
1954	Oil Pump Drive Bar	.07	2056	Windshield Lower Panel with Glass	16.50
1955	Rear Wheel Complete	15.00	2059	Windshield Upper and Lower Pivot	. 65
1956 1957	Front Wheel Complete	.90	2060 2061	Windshield Wing Nut	$\frac{.30}{.40}$
1958	Demountable Rim Bolt	.10	2062	Windshield Side Arm Stud	.11
1959	Demountable Rim Lock Stud Screw	.10	2063	Door Handle (Outside)	1.60
1960	Demountable Rim Wrench	. 50	2064	Top Dust Cover	7.00
1961	Demountable Straight Side Rim	3.50	2065	Door Check Strap	2.50
1962 1964	Clutch Lifting Lever Instrument Board Bracket	1.20	2066	Door Locking Device Lever	.55 .10
1965	Clutch Shaft Yoke	.50 1.00	2068	Door Striker Plate	1.10
1966	Oil Delivery Pipe	3.25	2070	Corner Lamp Switch	1.20
1967	Door Handle (Outside)		2071	Door Hinge (Upper) L. F. and R. Rear	. 60
1968	Front Door Post Upholstery (Right)	. 55	2072	Door Hinge (Upper) R. F. and L. Rear	. 60
1969 1970	Front Door Post Upholstery (Left)	. 55	2076	Door Hinge (Lower) Right Front	.60
1972	Door Flap Front Door Upholstery (Right)	$\begin{array}{c} 1.05 \\ 2.50 \end{array}$	2077 2078	Door Hinge (Lower) Left Rear Door Hinge (Lower) Right Rear	.60
1973	Rear Door Upholstery (Left)	2.50	2079	Body Hook Bolt	.18
1974	Rear Door Upholstery (Right)	2.50	2080	Door Bumper Retainer	.10
1975	Magneto Shaft Nut Lock	.10	2081	Door Bumper	.12
1976	Gasoline Tank Strap Bolt	.08	2082	Door Window Regulator Handle	1.90
1977 1978	Clutch Collar Thrust Bearing	$\frac{5.75}{2.95}$	2083 2084	Door Lock Lever Handle	$\begin{array}{c} .70 \\ .25 \end{array}$
1979	Oil Pressure Gauge Pipe	.50	2086	Door Post Dove Tail (Female)	.60
1980	Throttle Idler Lever	.55	2088	Door Striker Plate (Outer Half)	.10
1981	Spark Idler Lever	. 55	2089	Corner Lamp Switch Plate	. 55
1984	Rear Fender (Right)	10.00	2090	Door Pull to Handle	1.60
1985 1986	Rear Fender (Left)	10.00	2091 2093	Door Lock (Front Right)	$\frac{3.00}{.10}$
1987	Rear Fender (Left)	10.00	2095	Door Lock (Front Left—Rear Right).	3.00
1988	Accelerator Bracket	.35	2096	Door Lock (Rear Left)	3.00
1989	Steering Knuckle Bushing	.35	2097	Brake Flange Clamp Nut	.05
1990	Windshield Weather Strip	. 50	2113	Front Spring First Leaf	3.50
1991 1996	Gasoline Tank Support	2.50	2130 2131	Piston Pin (.005" Oversize) Tie Rod	$\frac{.90}{1.80}$
1330	(Touring and Roadster)	40.00	2133	Internal Brake Shoe	.30
2001	"Lift the Dot" Stud	.03	2134	Oil Pan Complete	7.00
2005	Expansion Plug	.13	2137	Carburetor Choke Knob	.90
2006	Tail Lamp Bracket		2138	Carburetor Choke Guide	.95
2007	Oil Pressure Gauge	$\frac{3.50}{2.00}$	2139 2140	Carburetor Choke Guide Nut Universal Joint Bearing Pin	1.90
2009	Rear Spring Horn (Left)	$\frac{2.50}{2.50}$	2141	Universal Joint Disc Bolt	.20
2010	Rear Spring Horn (Right)	2.50	2143	Front Spring Axle Clip	.25
2013	Service Bushing.	.40	2144	Oil Pump Coupling Sleeve	.25
2016 2017	Rear Floor Carpet	4.00	2145	Oil Pan Trough	$\frac{1.95}{1.35}$
2017	Gasoline Tank Gauge Cap Gasoline Tank Gauge Complete	.20	2147 2148	Tire Carrier Side Iron Tire Carrier Center Iron	$\frac{1.35}{1.35}$
2019	Gasoline Tank Filler Cap	.25	2150	Oil Suction Pipe	.45
2020	Bair Top Holder Stud	.25	2154	Head Lamp Bracket	.80
2024	Head Lamp Reflector	1.80	2164	Rear Spring Horn (Right)	3.50
2027 2029	Demountable Rim Lock Stud Screw	.10	2165	Rear Spring Horn (Left)	$\frac{3.50}{.20}$
2029	Gasoline Tank Gauge Gasket		2166 2167	Rear Spring Horn Bushing Front Spring Bracket (Left)	1.00
2031	Gasoline Tank Gauge Glass Use	11.25	2168	Front Spring Bracket (Right)	1.00
2033	Top Deck Complete	12.00	2169	Front Spring Bracket Bushing	.20
2034	Needle Valve Adjusting Screw	.40	2176	Rear Spring Bracket	3.10
2035 2036	Stuffing Box Gland	.25	2185 2187	Radiator Complete	$\frac{55.00}{8.50}$
2036	Back Curtain Complete	.15	2188	Radiator Filler Cap	.70
2038	Carburetor Stuffing Box Packing	.05	2189	Radiator Filler Cap Gasket	.07
	_				

Part No.	Part Name	Price	Part No.	Part Name	Price
2192	Radiator Hood Ledge Moulding	\$0.45	2317	Gasoline Tank Filler Gasket	\$0.06
2193	Radiator Hood Rest (Left)	.30	2320	Head Lamp Tie Rod	.40
2195	Front Universal Joint		2352 2353	Emergency Brake Pull Rod (Front)	.35
2197 2198	Radiator Hose	$\frac{.20}{4.00}$	2362	%6" S.A.E. Yoke Universal Joint Bushing	.30
2201	Steering Cross Tube	4.25	2363	Universal Joint Bushing Lock Ring	.05
2203	Steering Cross Tube End	3.50	2364	Universal Joint Journal	1.70
2205	Steering Cross Tube End Pin	. 60	2365	Universal Joint Yoke (Front)	6.25
2206	Steering Cross Tube End Pin Bushing	. 60	2366	Universal Joint Yoke (Rear)	5.00
2207 2208	Steering Cross Tube End Pin Nut Steering Knuckle (Right)	$\frac{.07}{7.25}$	2367 2371	Torque Ball	$\frac{2.50}{4.90}$
2209	Steering Knuckle (Left)	7.25	2391	Head Lamp	7.75
2210	Steering Knuckle Arm (Right)	5.00	2392	Head Lamp Door	2.60
2211	Steering Knuckle Arm (Left)	9.50	2393	Reflector Complete	2.30
2215 2216	Steering Knuckle Pin	$\frac{1.50}{1.50}$	2411 2412	Pinion Adjuster (Front)	$\frac{1.10}{7.25}$
2217	Pin Bushing (Upper) Pin Bushing (Lower)	1.15	2412	Pinion Adjuster (Rear) Pinion Adjuster Lock	.40
2218	Pin Bushing Dust Ring		2414	Pinion Adjuster Lock Gasket	.07
2219	Pin Dust Shield		2417	Rear Axle Brake Spider (Left)	14.50
2220	Drive Pin		2418	Rear Axle Brake Spider (Right)	
2227 2228	Thrust Washer (Upper)		2419 2420	External Brake Band and Lining External Brake Band Anchor	5.50
2229	Thrust Washer (Lower)		2421	External Brake Anchor Pin	.75
	Note: On Cars No. 100 to 4112 inclu-	71.00	2422	External Brake Band End (Upper)	.40
	sive the following parts are required:	4.000	2423	External Brake Band End (Lower)	. 50
	1 3346 Gas Tank Bracket (Right)		2424	External Brake Band Lining	.95
	1 3347 Gas Tank Bracket (Left) 1 2643 Gas Tank Hanger		2425 2426	External Brake Band Stop Screw External Brake Band Spring (Rear)	.16
	2 2601 Tire Carrier "U" Bolt		2427	Ext. Brake Band Stop Screw Bushing	.08
	3 Hex. Cap Screws, ½"-20x 1/8" S.A.E	•	2428	Ext. Brake Contracting Lever (Right)	1.15
	3 Lock Washer, ½"		2429	Ext. Brake Contracting Lever (Left)	1.15
	4 Hex. Cap Screws, 5/16"-24x11/8" S.		2430 2431	External Brake Contracting Link	$\frac{1.10}{.60}$
	A. E. 4 Lock Washers, 5/16"		2432	External Brake Adjusting Rod External Brake Adjusting Rod Nut	.35
	4 Lock Washers, 5/16" 4 Hex Nuts, 5/16"-24 S.A.E.		2433	External Brake Adjusting Rod Pin	.15
2230	Thrust Washer Shield		2434	External Brake Adjusting Rod Spring	
2232	Rear Axle Housing	81.00	2435	External Brake Adjusting Rod Stop.	. 60
2234 2235	Rear Axle Housing Cover Plug Rear Axle Housing Gasket	.16	2436 2438	Internal Brake Band and Lining Internal Brake Release Spring	$\frac{5.00}{.07}$
2240	Drive Pinion Housing	33.00	2443	Internal Brake Toggle Lever	1.10
2241	Rear Axle Torque Tube Baffle	.15	2444	Internal Brake Toggle Connecting Link	
2243	Differential Case		2446	Internal Brake Toggle Link	.15
2246 2247	Rear Axle Drive Gear Rivet Differential Side Gear		2447	Connecting Rod Complete Note: Rod returned for new Bearing will be	10.00
2248	Differential Spider			accepted at full credit less a charge of \$3.25	
2249	Differential Pinion	1.60	- 4	list for new bearing.	frij.
2250	Differential Carrier		2449 2450	Connecting Rod Shim	.13
2251 2253	Differential Carrier Stud Differential Bearing Adjusting Nut		2455	Piston Complete with Pin Fan Blades	
2254	Differential Bearing Adj. Nut Lock	.07	2456	Fan Pulley and Hub	3.50
2256	Differential Bearing Cap Screw	.25	2459	Fan Spindle	3.85
2257	Rear Axle Shaft	13.00	2460	Fan Spindle Eccentric	3.75
2258 2259	Rear Axle Shaft Oil Seal	.20 .15	2462 2463	Fan Belt	$\frac{4.00}{6.00}$
2260	Rear Axle Shaft Oil Seal Washer	.07	2464	Fly Wheel and Friction Ring	20.00
2261	Rear Axle Shaft Nut	.25	2465	Friction Ring	. 50
2263	Rear Axle Shaft Bearing Collar	1.15	2467	Fly Wheel Bolt.	.20
2264 2265	Rear Axle Shaft Bearing Packing Bearing Packing Retainer	.85	2470 2471	Water Pump Body Water Pump Pulley	5.50
2266	Bearing Packing Spring		2472	Water Pump Pulley Lock Nut	.16
2267	Rear Axle Shaft Bearing Retainer		2474	Water Pump Shaft	10.50
2268	Rear Axle Shaft Bearing Retainer Lock	.15	2476	Water Pump Bushing	2.50
2269	Rear Axle Drive Pinion Shaft		2481 2482	Generator Drive Gear Washer Water Pump Inlet Gasket	.40
2270 2272	Rear Axle Drive Pinion Shaft Nut Rear Axle Drive Pinion Key		2486	Water Pump Oil Return Line	.25
2275	Distributor Shaft Gear		2488	Tube Elbow, 3/16"	.16
2285	External Brake Band Guide	.07	2491	Slotted Hex Head Cap Screw	. 13
2287	Starting Crank Complete		2493 2495	Water Manifold HoseWater Outlet	$\begin{array}{c} .20 \\ 1.35 \end{array}$
2292 2293	Starting Crank CapCarburetor		2496	Hub Cap Wrench	1.10
2298	Carburetor Gasket	.04	2498	Oil Pump Body	3.25
2299	Hot Air Stove	. 85	2499	Oil Pump Bearing Plate	2.75
2310	Gasoline Tank Filler Flange Gasket.		2500 2501	Oil Pump Bearing Plate Gasket Oil Pump Driving Gear	2.25
2316	Gasoline Tank Filler Cap	1.00	2001	on I ump Dilving Geat	4.40

Part No.	Part Name	Price	Part No.	Part Name	Price
2502	Oil Pump Drive Gear	\$5.50	2667	Speedometer Drive Gear	\$3.00
2503	Oil Pump Drive Gear Pin	.07	2673	Spark Lever	1.10
2504	Oil Pump Gear	1.90	2695	Steering Connecting Rod	2.60
2505 2506	Oil Pump Shaft	. 55	2701 2703	Front Wheel CompleteFront Wheel Hub	11 25
2507	Oil Pump Shaft and GearOil Regulator Adjusting Screw	$\begin{array}{c} 3.65 \\ .16 \end{array}$	2705	Front Wheel Dust Washer	.09
2508	Oil Regulator Piston	.25	2706	Front Wheel Bearing Spacer	.40
2509	Oil Regulator Piston Retaining Spring	.07	2728	Clutch Pressure Plate	5.00
2510	Oil Regulator Shaft	. 80	2729	Clutch Driving Disc	3.50
2511	Oil Regulator Spring	.10	2730	Clutch Driven Disc	2.00
2523	Tail Lamp	2.05	2733	Clutch Shaft Nut	$\frac{1.20}{.35}$
2528 2529	Oil Relief TubeOil Suction Line	$\begin{array}{c} .25 \\ .35 \end{array}$	2736 2740	Clutch Spring	7.75
2532	Tail Lamp Support Tube	3.20	2742	Clutch Thrust Bearing	14.50
2533	Tail Lamp Support Base Nut	.10	2743	Clutch Thrust Bearing Retaining Nut.	1.15
2540	Oil Pan		2752	Clutch Control Yoke Center	1.00
2541	Oil Screen	1.95	2760	Oil Guard (Front)	.05
2543	Oil Screen Flange Gasket	.10	2761	Oil Guard (Rear)	9.25
2544 2545	Oil Pan Gasket (Right)	.40	2769	Drive GearBall Bearing Single Row No. 1210	7.00
2545 2547	Oil Pan Gasket (Left)	.40	2770 2771	Drive Gear Bushing	.50
2552	Exhaust Manifold Bolt (Short)	.13	2772	Drive Gear Retainer	1.35
2553	Exhaust Manifold Bolt (Long)	.40	2774	Gear Shifter Fork (High and Int.)	1.65
2554	Exhaust Manifold Gasket (Center)	.05	2776	Gear Shifter Shaft (Low and Reverse).	.80
2555	Exhaust Manifold Gasket (End)	.75	2780	Idler Gear Shaft	. 65
2556	Exhaust Fitting	1.80	2781	Idler Gear (Front)	$\frac{4.35}{4.35}$
2557 2558	Exhaust Fitting Gasket	.08	2782 2784	Idler Gear (Rear)Idler Cover	.10
2559	Exhaust Fitting FlangeExhaust Pipe Gasket	.40	2786	Spline Shaft	6.75
2560	Exhaust Pipe Casket		2788	Ball Bearing Single Row No. 1307	6.00
2561	Exhaust Pipe Sleeve	.45	2790	Sliding Gear (High and Intermediate).	6.75
2562	Exhaust Pipe Clamp	.25	2794	Countershaft Drive Gear	4.00
2587	Rear Wheel Complete	22.00	2795	Low Speed Gear	4.25
2588	Rear Wheel Hub	6.50	2796	Second Speed Gear	$\frac{4.00}{4.75}$
2589 2590	Rear Wheel Hub Extension		2797 2798	Countershaft Sleeve Bushing	.55
2591	Rear Wheel Brake Drum	$\frac{5.00}{.15}$	2810	Steering Wheel Key	.02
2592	Hub Cap	. 80	2815	Steering Worm Adjusting Nut	1.50
2593	Demountable Straight Side Rim	4.00	2816	Steering Worm Wheel	5.50
2594	Demountable Rim Bolt	.10	2819	Worm Ball Retainer with Balls	.45
2598	Tire Carrier	16.00	2826	Worm Ball Race—Self Aligning	.35
2601	Tire Carrier "U" Bolt		2827 2828	Worm Ball Race—Plain Steering Worm (3 Grooves)	2.50
2602 2603	Tire Carrier Body Bracket Tire Carrier Wedge		2829	Steering Worm Key	.07
2604	Tire Carrier Wedge Stud		2830	Mast Jacket	4.15
2606	Front Spring Bushing	.40	2832	Steering Wheel Tube	6.25
2607	Front Spring Shackle	.40	2834	Pitman Arm	2.35
2608	Spring Bolt		2837	Spark Control Lever	.35 .45
2609	Spring Bolt		2839 2843	Throttle Control Lever	
2611 2612	Front Spring BumperFront Spring Clip	$\frac{.25}{.25}$	2846	Control Bracket Tube Bushing	.25
2615	Rear Spring Bushing		2852	"Lift the Dot" Stud	.03
2617	Spring Bolt		2854	Oil Pressure Gauge	2.25
2618	Spring Pin	. 50	2862	Front Fender (Right)	13.00
2621	Rear Spring Clip	.35	2863	Front Fender (Left)	
2627	Cylinder Head Gasket	1.90	2866	Door Check Strap	
2628 2630	Cylinder Head Stud		2867 2868	Curtain Rod (Right)	~~
2631	Cylinder Head Cover Gasket		2870	Rear Fender (Right)	
2639	Timing Gear Cover	14.25	2871	Rear Fender (Left)	8.25
2640	Timing Gear Cover Gasket	. 60	2872	Rear Fender Tail Piece (Right)	. 55
2641	Camshaft Gear		2873	Rear Fender Tail Piece (Left)	
2642	Crankshaft Gear		2874	Rear Fender (Right)	
2644	Generator Gear		2875	Rear Fender (Left)	13.50
2645 2646	Valve Spring (Outer)		2880 2881	Rear Fender (Right)	13 50
2647	Valve Spring (Outer)	40	2882	Rear Fender (Right)	13.50
2648	Valve Spring Cup	75	2883	Rear Fender (Left)	13.50
2649	Valve Spring Cup Wedge		2884	Rear Fender Tail Piece (Right)	. 55
2650	Valve Stem Guide	1.20	2885	Rear Fender Tail Piece (Left)	
2651	Valve Rocker Arm		2886	Side Apron (Right)	
2654	Valve Rocker Arm Adjusting Stud		2887 2888	Side Apron (Left)	7.00
2659 2660	Curtain Rod (Left)		2889	Running Board (Left)	7.00
-300				The state of the s	

Part No.	Part Name	Price	Part No.	Part Name	Price
2895	Fender Bracket		3420	Tail Lamp Bracket	\$0.70
2898	Hood Catch	1.75	3429	Piston with Pin (.003" oversize)	
2899	Hood Catch Spring	.16	3430	Piston with Pin (.005" oversize)	7.75
2902 2903	Hood Catch Bracket (Front) Hood Catch Bracket (Rear)	$.70 \\ .70$	3431 3435	Piston with Pin (.010" oversize) Piston Pin (.005" oversize)	$7.75 \\ .95$
2904	Hood Sill (Right)		3436	Piston Pin (.010" oversize)	.95
2905	Hood Sill (Left)	2.60	3437	Piston Ring (.010" oversize)	.60
2916	Curtain Rod Socket	.11	3439	Piston Ring (.010" oversize)	. 65
2937	Door Handle (Outside)	2.25	3441	Head Lamp Door Glass	2.20
2939	Right Front Door Locking Handle	7.25	3443	Clutch Hub Bushing	.70
2942	Door Handle Escutcheon Plate (Inside)	.12	3444	Clutch Cover Plate	12.00
2943	Door Handle Screw (Inside)	.25	3446	Clutch Lifting Lever	1.15
2948 2988	Door Bumper	$\frac{.06}{5.35}$	3447 3450	Clutch Collar Special Cap Screw	$\begin{array}{c} 3.25 \\ .04 \end{array}$
3033	"Durable Dot" Socket	.02	3451	Windshield Thumb Screw	.80
3043	Top Holder (Touring)		3455	Hub Extension Lock Ring	.09
3044	Front Seat Cushion		3457	"Lift the Dot" Clinch Plate	.01
3045	Rear Seat Cushion	23.00	3461	Door Moulding (Side)	.70
3049	Starting Crank Jaw		3463	Door Moulding (Lower)	.70
3051	Cam Shaft		3470	Corner Lamp Glass and Rim	1.75
3055	Cam Shaft Bearing (Front)		3472	Rear Side Window CurtainOil Suction Pipe Felt	$\frac{7.25}{.02}$
3056 3058	Cam Shaft Bearing (Center) Cam Shaft Bearing (Rear)	$\frac{.95}{1.15}$	3484 3485	Rear Fender, (Left)	
3065	Crankshaft Bearing Shim (Front)	.16	3486	Rear Fender, (Right)	14.00
3070	Crankshaft Oil Gasket		3488	Rear Side Window Curtain	7.25
3074	Valve Lifter	1.35	3489	Hood Catch Spring	.03
3075	Valve Lifter Guide	1.30	3490	Fan Hub (3¼" Dia.)	1.90
3078 3079	Valve Lifter Roller	. 95	3491	Fan Spindle	2.10
3079	Valve Lifter Roller Pin Valve Rocker Arm Adj. Stud Nut	$.45 \\ .07$	3492 3496	Hand Brake Lever	$\begin{array}{c} 2.55 \\ 3.00 \end{array}$
3084	Valve Push Rod	.75	3516	Curtain Rod (Right)	.25
3085	Valve Push Rod End	.45	3517	Curtain Rod (Left)	.25
3086	Push Rod Inspection Cover Gasket	.16	3518	Oil Pressure Gauge Pipe	. 50
3087	Push Rod Cover Plate Gasket (Front)	.40	3519	Top Strap	
3088	Push Rod Cover Plate Gasket (Rear)	.35	3550 3551	Gauge Glass	.05 .20
3091 3092	Crankshaft Bearing and Cap (Rear) Crankshaft Bearing and Cap (Front)		3554	Oil ThrowerGear Case Oil Deflector	.13
3093	Crankshaft Bearing and Cap (Center)	9.50	3556	Windshield Quadrant (Right)	1.45
3232	Head Lamp Focus Spring	.07	3557	Windshield Quadrant (Left)	1.45
3233	Head Lamp Glass Retaining Spring	.07	3558	Windshield Quadrant Bracket (Right)	2.15
3234	Piston with Pin (.003" oversize)	4 50	3559	Windshield Quadrant Bracket (Left)	2.15
3235 3236	Piston with Pin (.005" oversize)	$\frac{4.50}{4.50}$	3560 3562	Cowl Ventilator Lid	2.90
3245	Piston with Pin (.010" oversize) Windshield Side Arm (Left)	5.70	3563	Casing Spring Retainer Lock Ring Use	
3246	Windshield Side Arm (Right)	5.70	3564	Universal Joint Sleeve Yoke	2.75
3258	Windshield Wing Nut	.35	3565	Universal Joint Cross Bushing	.16
3259	Windshield Pivot Plate Screw	.11	3567	Universal Joint Inside Casing	. 50
3260	Windshield Pivot Screw	.17	3568	Universal Joint Flange Yoke	2.25
3266 3274	Door Glass and Channel R.R. and L.F. Rear Side Window Channel	$9.50 \\ 2.40$	3569 3571	Windshield Weatherstrip Universal Joint Cross	$\begin{array}{c} .65 \\ 1.30 \end{array}$
3283	Front Floor Carpet		3572	Universal Joint Ball Yoke	2.50
3285	Front Heel Carpet		3581	Side Curtain, (Left Front)	
3287	Floor Carpet	16.00	3582	Side Curtain, (Right Front)	3.60
3351	Head Lamp Bracket (Left)	1.10	3583	Side Curtain, (Left Rear)	3.25
3352	Head Lamp Bracket (Right)		3584 3588	Side Curtain, (Right Rear)	$\frac{3.25}{.12}$
3377 3378	Torque Ball Collar		3591	Top Deck	9.00
3379	Left Front Door Complete. Upon Appl		3601	Clutch Shaft	
3381	Left Rear Door Complete. Upon Appl		3602	Clutch Throwout Spider Bushing	.80
3384	Tire Carrier Wedge	. 50	3603	Top Holder	3.20
3385	Tire Carrier Wedge	. 50	3605	Deck Door LockUse Deck Door Key	.15
3388 3389	Right Front Door Lock (Outside) Door and Deck Lock Key	$\frac{2.85}{.75}$	3606 3607	Tail Lamp Support	.45
3403	Piston Ring	.65	3608	Windshield Quadrant Bracket Screw	.03
3404	Deck Lock with Key		3609	Double Idler Gear Complete	4.25
3407	Deck Latch	1.10	3619	Universal Joint Spider	1.45
3408	Universal Joint Spool	3.30	3628	Universal Joint Yoke	$\frac{3.25}{200}$
3409	Piston with Pin (.015" oversize)	4.50	3629 3630	Universal Joint Spool	$\frac{3.30}{3.25}$
3410 3411	Piston with Pin (.020" oversize) Piston Pin (.010" oversize)	4.50	3631	Universal Joint Flange Yoke	2.40
3412	Piston Ring (.010" oversize)	.30	3633	Rear Wheel Hub Extension	1.50
3413	Piston Ring (.020" oversize)	.30	3634	Rear Wheel Hub Extension Shell	.30
3418	Mast Jacket Dash Bracket	.35	3635	Rear Wheel Puller Screw	.20
3419	Mast Jacket Dash Bracket Cap	.18	3636	Dash Lamp Hood	.35

Part No.	Part Name	Price	Part No.	Part Name	Price
3637	Hood Ledge Anti-Squeak	\$0.25	3872	Panel Guard Boss	\$0.25
3655	Locking Device Lever Screw	.01	3873 3875	Panel Guard Washer.	.18
3656 3657	Crankshaft Gear (.002" undersize) Crankshaft Gear (.004" undersize)		3877	Oil Pump BodyOil Pump Drive Shaft	$\frac{4.75}{1.10}$
3658	Crankshaft Gear (.006" undersize)	3.85	3888	Bumper Collar Nut	.40
3659	Camshaft Gear (.002" oversize)	4.50	3890	Rear Curtain Light Binding	.06
3660	Camshaft Gear (.004" oversize)	4.50	3891	Head Lamp (Left) (NP)	
3661	Camshaft Gear (.006" oversize)	4.50	3892 3893	Top Bumper	$.08 \\ .25$
3662	Camshaft Gear (.008" oversize).	4.50	3900	Rear Wheel Hub with Brake Drum	
3663	Camshaft Gear (.010" oversize)	4.50	3901	Wheel Locking Flange	3.20
3664 3665	Generator Gear (.002" undersize) Generator Gear (.004" undersize)	2.90	3902	Wheel Locking Flange Bolt	.40
3666	Generator Gear (.004" undersize)	$\frac{2.90}{2.90}$	3903 3909	Wheel Locking Ring	3.20
3667	Crankshaft Gear (.006" undersize)	16.00	3914	Front Spring Bolt	. 55 . 20
3668	Generator Gear (.006" undersize)	6.15	3915	Instrument Board Bracket Bolt Nut	.08
3670 3698	Shifter Fork (Low and Reverse)	2.10	3918	Kick Plate	. 55
3700	Deck Door Lift Ring Cowl Lamp	$\frac{1.60}{1.75}$	3919	Rear Spring Bolt (Front)	.45
3730	Front Spring.	7.50	3920 3921	Spring Bolt	. 50
3731	Door Handle (Outside)	1.40	3922	Rear Spring Clip Nut.	.05
3733	Cowl Lamp Switch	1.10	3925	Strap Loop 1"	.16
3735 3738	Door Check Strap Loop. Door Glass Channel	.25	3927	Steering Gear Thrust Bearing	.75
3739	Windshield Quadrant Bracket Plunger	$\frac{2.25}{.07}$	3935 3943	Top Complete Less Curtains	90.00
3742	Glass Channel Felt, per foot	35	3944	First Top BowSecond Top Bow	$\frac{4.50}{4.50}$
3752	Regulator Handle Ring.	20	3945	Third Top Bow	4.50
3757	Vacuum Tank Suction Pipe.	. 50	3946	Fourth Top Bow	5.25
3758 3759	Vacuum Tank Suction Tube Tank Suction Tube Clamp	.06	3949	Windshield Side Arm (Left)	14.00
3760	Tank Suction Tube Connector	$.04 \\ .12$	3950 3953	Windshield Side Arm (Right) Axle Shaft Outer Bearing	14.00
3762	Carburetor Tank Feed Pine	.40	3955	Front Wheel Inner Bearing	$\frac{5.85}{3.25}$
3764	Intake and Exhaust Manifold.	8.00	3957	Front Wheel Outer Bearing	3.60
3766	Vacuum Tank Suction Pipe	. 50	3959	Differential Bearing	6.35
3767 3768	Throttle Bell Crank Stud	.04 $.25$	3961	Rear Axle Shaft Outer Bearing	6.50
3769	Vacuum Tank Strap	.35	3962 3963	Front Wheel Inner Bearing Front Wheel Outer Bearing	$\frac{5.35}{4.70}$
3770	Throttle Rod	.07	3966	Drive Pinion Bearing (Rear)	6.50
3771	Intake Riser Gasket, Upper.		3969	Door Pull to Handle with Clip	1.75
3772 3773	Intake Riser Gasket, Lower Carburetor Stud	.06	3970	Tail Lamp Complete	1.60
3774	Carburetor Throttle Lever	.04	3971 3979	Tail Lamp Glass, Inside Drive Pinion Shaft Bearing	$\frac{.25}{5.20}$
3775	Vacuum Tank Strap Bolt	.08	3980	Windshield Top Bracket Screw	.17
3789	Piston (Standard)	4.50	3984	Radiator Complete	48.00
3790	Piston Pin Bushing	.25	3986	Radiator Shell	13.50
3791 3792	Piston (.003" oversize)	$4.50 \\ 4.50$	3988	Alemite Grease Nipple	.35
3793	Piston (.010" oversize)	4.50	3989 3992	Alemite Grease Nipple	$\frac{.30}{21.00}$
3794	Piston (.015" oversize)	4 50	0002	Note: Part Nos. 3993 to 4901 inclusive only	21.00
3795	Piston (.020" oversize)	4.50		used with Differential Pinion Carrier Housing marked "O."	16:4-
3799 3804	Rear Floor Carpet	12.00	9009		
3805	Cap Screw Locking Disc	15.25	3993 3994	Rear Axle Drive Gear Rear Axle Drive Pinion Per Set	28 25
3807	Hot Air Pipe	1.00	9004	9 Teeth	20.20
3808	Manifold Replacement Unit	14.50	3996	Rear Axle Drive Pinion Shaft Collar	.70
3816 3819	Back Panel Guard	1.20	3997	Rear Axle Pinion Shaft Collar Pin	.04
3820	Step Plate	$\frac{1.75}{3.75}$	3998	Rear Axle Drive Pinion Bearing Com-	0 05
3821	Windshield Wing Glass (Left).	3.75	3999	plete	$8.25 \\ 1.70$
3822	Windshield Wing Bracket	8.75	4001	Rear Axle Drive Pinion Housing	
3823	Windshield Complete	40.00	4002	Back Panel Guard	1.50
3824 3825	Prop Nut Lock.	.07	4003	License Plate Clamp	.03
3826	Rear Curtain Frame.	$\begin{array}{c} .06 \\ 2.35 \end{array}$	4004 4005	Oil Pan Drain PlugOil Pan Drain Plug Gasket	$.12 \\ .01$
3844	Cowl and Fender Lamp Lens	.20	4006	Main Drive Gear Sleeve.	.16
3845	Cowl and Fender Lamp Rim	.45	4008	Center Tire Carrier Bracket	1.50
3852 3853	Radiator Cap	1.80	4009	Transmission Lock with Key	2.75
3854	Body Hood Moulding (Left)	. 55 . 55	4011 4012	Transmission Lock Spring	.02
3856	Front Wheel Complete (Disc)	15.00	4013	Transmission Lock Key	$\begin{array}{c} .35 \\ 5.25 \end{array}$
3857	Rear Wheel Complete (Disc).	17.00	4014	Side Tire Carrier Bracket	2.75
3860	Tire Carrier Bracket Nut	.05	4016	Rear Wheel Felt Flange	. 50
3866 3867	Head Lamp (Right) Cowl Lamp	10.00	4017	Front Wheel Hub	4.50
000	от минри	2.25	4018	Front Wheel Hub Flange	1.00

Part No.	Part Name	Price	Part No.	Part Name	Price
4019	Rear Wheel Hub	\$4.00	4209	Steering Knuckle (Left)	\$8.75
4020	Rear Wheel Brake Drum	$\frac{3.75}{2.10}$	4210 4211	Steering Knuckle King Pin Front Brake Shoe (Inner)	1.75
4021	Front Fender LampFly Wheel Guard	1.35	4212	Front Brake Shoe (Outer)	1.75
1026 1028	Tire Carrier Bracket (Right)	5.50	4213	Front Brake Drum Cover (Left)	1.35
1029	Tire Carrier Bracket (Left)	5.50	4214	Front Brake Shaft Lever (Inner)	.80
4057	Door Pull to Handle	1.60	4215	Clamp Bolt	.05
4065	Floor Mat	4.00	4216	Front Brake Shaft (Right)	$\frac{1.40}{1.40}$
4079	Rear Axle Shaft Outer Bearing Ad-	9 95	4217 4218	Front Brake Shaft (Left) Front Brake Fork Lever (Right)	$\frac{1.40}{2.20}$
4000	juster Outer Bearing Adjuster Lock	$\frac{2.25}{.09}$	4219	Front Brake Fork Lever (Left)	2.20
4080 4081	Hub Cap Wrench		4223	Front Brake Shaft Support Bushing	.12
4082	Felt Washer Retainer		4225	Windshield Wing Glass (Left)	2.75
4083	Valve Push Rod	.40	4226	Windshield Wing Glass (Right)	2.75
4084	Valve Push Rod Adjusting Nut	.25	4232	Front Wheel Complete	15.00
4085	Drive Pinion Oil Sling	.08	4233 4234	Front Wheel Complete Front and Rear Wheel Disc	$\frac{17.00}{7.50}$
4086	Tail Lamp Connector Plug	10.00	4234	Front Wheel Hub	4.50
4095	Rear Fender (Left)	10.00	4236	Front Wheel Brake Drum	3.50
4096	Demountable Rim Wedge		4237	Hub Extension Shell	.30
4098	Brake Cam Bracket Bushing	-	4238	Wheel Clamp Ring	.75
4099	Vacuum Tank Float		4239	Wheel Hub Bolt Nut (Outer)	.10
4100	Vacuum Tank Valve		4241	Front Wheel Hub Bolt	.18
4101	Vacuum Tank Screen	.35	4242	Rear Wheel Complete	
4108	Rear Axle Tube Felt Retainer	16	4243 4244	Rear Wheel Brake Drum	
4109	Rear Axle Tube Felt Retainer Washe Expansion Plug, 1"	.05	4245	Rear Hub Extension	
4120 4126	Heater Pipe (Inlet)		4246	Rear Wheel Grease Felt Flange	
4127	Heater Pipe (Inlet)		4247	Rear Wheel Hub Extension Shell	.30
4133	Heater Valve Body	5.00	4248	Rear Wheel Brake Drum Spacer	.16
4139	Rubber Grommet	.02	4249	Rear Wheel Hub Bolt	.1
4141	Piston Pin (.015" oversize)		4250	Demountable Rim	$\frac{3.00}{.18}$
4142	Breather Tube		4251 4252	Demountable Rim Bolt	
4145	Cylinder Head Cap Screw	and the state of t	4253	Tail Lamp Support Strap	
	Note: Parts Nos. 4146-4163 inclusive are use only in California.	u teat	4254	Tire Carrier Bracket (Right)	
4146	Top Complete	.100.00	4255	Tire Carrier Bracket (Left)	
4147	Top Deck	. 20.00	4256	Center Tire Carrier Bracket	
4165	Oil Pan Drain Yoke	65	4258	Tire Carrier Bracket (Right)	
4166	Oil Pan Drain Rod Anchor		4259	Tire Carrier Bracket (Left)	
4168	Oil Pan Drain Cock		4260 4261	Tire Carrier Bracket (Right) Tire Carrier Bracket (Left)	
4169	Camshaft Bushing (Front)	. 1.15	4262	Center Tire Carrier Bracket	
4172 4173	Cylinder Block	100.00	4263	Piston Pin (.020" oversize)	
4174	Crankshaft	. 22.50	4265	Steering Gear Housing Bushing	
4175	Oil Pan	. 8.00	4269	Front Brake Pull Rod	
4176	Oil Pan Gasket (Rear)	05	4270	Steering Worm	
4177	Crankshaft Rear Bearing (Upper)			Steering Gear Housing	
4178	Rear Bearing Shim	$\begin{array}{cc} . & .13 \\ . & 7.75 \end{array}$	4272 4274	Steering Worm WheelSteering Main Tube Bushing (Lower	
4184	Rear Bearing Cap with Bearing		4279	Steering Worm Adjusting Nut Bushing	
	Note: Cap returned for new Bearing will b accepted at full credit less a charge of \$2.0	0	4280	Front Spring.	
	list for new bearing.		4281	Rear Spring	. 10.5
4185	Starting Motor Bracket	. 1.70	4289	Front Brake Pull Rod (Rear)	4
4186	Piston with Pin (Standard)	. 7.25	4290	Rear Spring	. 10.5
4187	Piston with Pin (.003" oversize)	. 7.25	4299	Demountable Rim Lock Stud	
4188	Piston with Pin (.005" oversize)	. 7.25 . 7.25		Idler Gear BushingCountershaft	
4189	Piston with Pin (.010" oversize) Piston with Pin (.015" oversize)	7.25		Battery Inspection Door	
4190 4191	Piston with Pin (.015 oversize)			Front Brake Pull Rod (Front)	
4191	Piston Ring (Plain) (Standard)	30		Univ. Joint Inside Casing with Plug	7
4193	Piston Ring (Plain) (.010" oversize)	30	4311	Rear Hub Felt Retainer	2
4194	Piston Ring (Plain) (.020" oversize)	30		Steering Gear Housing Bushing Lock	
4195	Piston Ring (Grooved) (Standard)	30		Special Slotted Nut	
4196	Piston Ring (Grooved) (.010" oversize	$\frac{1}{2}$.30		Bearing Retainer Gasket	
4197	Piston Ring (Grooved) (.020" oversize	e) .30 30		Drive Shaft Retainer Gasket Piston with Pin (.023" oversize)	
4200	Brake Shoe Lining	10		Transmission Case Cover Oil Guard.	
4201 4202	Front Brake Fork			Crankshaft Gear (.002" oversize)	
4202	Brake Fork Bracket Bushing	16	4328	Crankshaft Gear (.004" oversize)	. 3.
4204	Front Brake Lever Release Spring	07		Crankshaft Gear (.006" oversize)	
4206	Steering Knuckle Arm (Right)	5.00		Bearing Retainer Gasket (Front)	
4207	Steering Knuckle Arm (Left)	. 5.00		Main Drive Gear Bearing Spacer Main Drive Gear Retainer Gasket	
4208	Steering Knuckle (Right)				

Part No.	Part Name	Price	Part No.	Part Name	Price
4334	Transmission Case with Studs (R.D.).		5062	Rear Wheel Brake Drum	\$4.00
4335	Transmission Case with Studs	8.25	5063	Steering Connecting Rod (R. D.)	2.25
4336 4337	Main Drive Gear	$\frac{5.70}{2.25}$	5064 5065	Demountable Rim	5.00
4338	Front Spring First Leaf	2.25	5066	Demountable Rim Bolt Demountable Rim Bolt Nut Use No.	.10
4342	Front Wheel Complete	17.00	5067	Demountable Rim Clamp	.16
4343	Front Wheel Complete	15.00	5068	Radiator Complete	
4344	Rear Wheel Complete.	17.00	5069	Radiator Core	38.50
4345 4346	Generator Gear (.002" oversize) Generator Gear (.004" oversize)	2.90	5070	Radiator Shell	10.00
4347	Generator Gear (.004 oversize)	$\frac{2.90}{2.90}$	5071 5072	Propeller Shaft	
4348	Demountable Rim Wedge	.15	5073	Universal Joint Yoke Plug.	$\frac{4.25}{.07}$
4349	Exhaust Pipe Gasket Sleeve	.17	5074	Universal Joint Casing	2.25
5000	Frame Complete	75.00	5075	Universal Joint Casing Gasket	.12
5001 5002	Clutch Shaft Support (Left)		5076	Universal Joint Casing Bushing	. 80
5003	Front Spring Horn (Left)	$\frac{2.50}{2.00}$	5077 5078	Universal Joint Casing Bushing Gasket Universal Joint Casing Pin	.07
5004	Front Spring Horn (Right)	2.00	5079	Universal Joint Casing Nut	.40
5005	Rear Spring Hanger (Front)	3.25	5080	Universal Joint Casing Washer	.12
5006	Rear Spring Hanger (Rear)	2.75	5081	Universal Joint Thrust Washer	.06
5007 5008	Tire Carrier CradleUse Tire Carrier Rim Seat	5433	5082	Universal Joint Thrust Washer	.06
5009	Tire Carrier Rim Clamp	. 50 . 45	5083 5084	Universal Joint Flange (Axle End) Universal Joint Flange (Trans. End)	$\frac{3.25}{3.50}$
5010	Tire Carrier Rim Clamp Nut	.15	5085	Universal Joint Flange Yoke	$\frac{3.50}{3.75}$
5011	Front Spring Complete	3.60	5086	Universal Joint Flange Key	.07
5012 5013	Spring First Leaf BushingUse		5087	Universal Joint Flange Bolt	.12
5014	Front Spring Center Bolt	.15	5088 5089	Universal Joint Flange Bolt Nut Fan Hub	.06
5015	Rear Spring Center Bolt	.15	5090	Fan Spindle	$\frac{3.00}{2.40}$
5016	Rear Spring Shackle	1.90	5091	Fan Spindle Thrust Washer	.30
5017	Front Spring Clip	.30	5092	Fan Belt	2.00
5018 5019	Front Spring Clip BlockFront Spring Seat	.90	5093	Fan Bracket	1.25
5020	Rear Spring Pin	. 50	5094 5095	Grease NippleCarburetor Complete	.35
5021	Rear Spring Clip	.55	5096	Carburetor Throttle Lever	50
5022	Rear Spring Clip Nut	.14	5097	Carburetor Choke Guide Tube. Use	23214
5023 5024	Rear Spring Clip Plate. Front Axle "I" Beam	1.25	5098	Carburetor Choke Wire Use	
5025	Steering Knuckle (Left)	12 50	5099 5100	Exhaust Pipe	$\frac{1.10}{.17}$
5026	Steering Knuckle (Right)	12.50	5101	Motor Underpan (Left)	.80
5027	Steering Knuckle Bushing	.15	5102	Gasoline Filter	2.25
5028 5029	Steering Knuckle Spindle Washer	.05	5103	Gasoline Filter Tube Union	.16
5030	Steering Knuckle Thrust Washer Steering Knuckle Thrust Bearing	.02	5104 5105	Clutch Cover Plate	$\frac{10.00}{3.40}$
5031	Steering Knuckle King Pin	.55	5106	Clutch Collar	3.40
5032	Steering Knuckle King Bolt Gasket.	.01	5107	Clutch Pedal	1.60
5033	Expansion Plug (Upper)	.03	5108	Clutch Pedal Shaft	.80
5034 5035	Expansion Plug (Lower)Use Steering Knuckle King Pin Locking Pin	4120 .05	5109 5110	Transmission Case (Front)	14.00
5036	Steering Knuckle Stop Screw	.03	5111	Transmission Support Bolt	.18
5037	Steering Arm (Left)	4 80	5112	Transmission Cap (Front)	2.95
5038	Steering Arm (Right)	2.30	5113	Transmission Cap Gasket (Front)	.02
5039 5041	Tie Rod Complete	6.75	5114	Transmission Cap (Rear)	9.50
5042	Tie Rod Spring Tie Rod Spring Seat	$\begin{array}{c} .05 \\ .25 \end{array}$	5115 5116	Transmission Cap Gasket (Rear) Transmission Case Cover	$02 \\ 14.00$
5043	Tie Rod Spring Seat Adjusting Washer	.09	5117	Transmission Case Cover Gasket	.02
5044	Tie Rod Ball Stud	. 60	5118	Transmission Interlock Plate Pivot	.35
5045 5046	Tie Rod Ball Stud Nut Tie Rod Dust Cover (Large)	.06	5119	Transmission Interlock Plate Stud	.20
5047	Tie Rod Dust Cover (Large)	.12	5120 5121	Transmission Interlock Spring Gear Shift Lever	$\begin{array}{c} .03 \\ 4.25 \end{array}$
5048	Tie Rod Dust Cover Felt Washer	.05	5122	Gear Shift Lever Grip	.55
5049	Tie Rod Dust Cover Spring	.09	5123	Gear Shift Lever Grip Guide Pin	.10
5050	Front Wheel Complete		5124	Gear Shift Lever Spring	.06
5051 5052	Front Wheel Hub Flange	3.00 .65	5125 5126	Gear Shift Lever Dust Cap Gear Shift Lever Cover	. 50
5053	Front Wheel Inner Bearing Complete.	5.20	5126	Shifting Shaft (1st and 2nd Speed)	$\frac{.17}{3.25}$
5054	Front Wheel Outer Bearing Complete	3.70	5128	Shifting Shaft (3rd and 4th Speed)	3.25
5055	Front Wheel Cork Retainer (Inner)	.07	5129	Shifting Shaft (Reverse)	3.25
5056 5057	Front Wheel Cork Retainer (Outer) Front Wheel Cork Washer	.07	5130	Shifting Fork Shaft	. 55
5058	Front Wheel Cork Retainer Lock Ring	.09	5131 5132	Shifting Fork (1st and 2nd Speed) Shifting Fork (3rd and 4th Speed)	$\frac{2.40}{3.00}$
5059	Hub CapUse	5432	5133	Shifting Fork Screw	.15
5060	Rear Wheel Complete	27.50	5134	Shifting Fork (Reverse)	2.40
5061	Rear Wheel Hub	4.50	5135	Lock Plunger (3rd and 4th Speed)	. 80

Part No.	Part Name	Price	Part No.	Part Name	Price
5136	Lock Plunger (1st, 2nd and Reverse)	\$0.55	5211	Steering Gear Housing Bushing	\$0.50
5137	Lock Plunger Spring	.03	5212	Steering Gear Housing Cover	4.25
5138	Lock Plunger Key		5213	Steering Gear Housing Cover Gasket	.08
5139 5140	Transmission Case Gasket Main Drive Shaft (Front)		5214	(Brass) Steering Gear Housing Cover Gasket	.00
5141	Main Drive Shaft Sleeve (Front)	.50	Mar Mill	_(Cork)	.03
5142	Oil Guard (Front)	.09	5215	Housing Cover Stud	.06
5143	Drive Shaft Front Sleeve Gear		5216	Housing Adjusting Sleeve	.40
5144	Front Sleeve Gear Ring	.30	5217	Housing Adjusting Sleeve Nut	$.04 \\ .12$
5145	Front Roller Bearing Front Sleeve Gear Spacer	$\frac{3.00}{2.00}$	5218 5219	Housing Adjusting Stud Housing Washer	.04
5146 5147	Front Sleeve Gear Race		5220	Worm Wheel	7.00
5148	Front Roller Bearing Race Pin	.03	5221	Worm Wheel Nut	.19
5149	Drive Shaft Front Roller	.10	5222	Worm Wheel Thrust Washer	.15
5150	Drive Shaft Front BearingUs	e 1089	5223 5224	Worm Wheel Thrust Block Pitman Arm	$\frac{.06}{2.70}$
5151 5152	Drive Shaft Front Thrust Washer Drive Shaft Front Thrust Washer Pin		5225	Steering Gear Thrust Bearing	1.05
5153	Drive Shaft Front Cup Gear		5226	Steering Gear Worm	3.75
5154	Cup Gear Roller Bearing Race		5227	Steering Gear Worm Key	.07
5155	Cup Gear Bearing Retainer Washer	.16	5228	Steering Gear Main Shaft	2.75
5156	Cup Bearing Retainer Washer Pin		5229 5230	Main Shaft Nut	.18
5157	Main Drive Shaft Rear	16 00	5231	Steering Gear Adjusting Nut	4.00
5158 5159	Main Drive Shaft Rear Bearing	3.90	5232	Adjusting Nut Bushing	.60
5160	Countershaft	10.25	5233	Adjusting Nut Felt Washer	.06
5161	Countershaft Lock Collar		5234	Adjusting Screw	3.00
5162	Countershaft Bushing (Rear) Countershaft Bushing (Front)		5235 5236	Mast Jacket, with Bushing Mast Jacket Bushing	.50
5163 5164	Countershaft Drive Gear		5237	Steering Wheel	6.00
5165	Countershaft Thrust Washer		5238	Throttle Control Tube	1.45
5166	Sliding Gear (1st and 2nd speed)		5239	Spark Control Tube	1.45
5167	Expansion Plug		5240 5241	Stationary TubeStationary Tube Silencer	$\frac{1.80}{.14}$
5168 5169	Reverse Gear Shaft	$\frac{1.00}{13.75}$	5242	Stationary Tube Clamp	.18
5170	Reverse Gear Bushing		5243	Stationary Tube Clamp Washer	.02
5171	Reverse Gear Shaft Key	.04	5244	Spark Lever (Lower)	. 50
5172	Speedometer Pinion		5245	Throttle Lever (Lower)	. 50
5173	Speedometer Gear		5246 5247	Steering Gear Control Base Control Cap with Nut	.35
5174 5175	Hand Lever Latch Rod		5248	Control Cap NutUse N	
5176	Hand Lever Ratchet Pawl		5249	Control Cap Plate	.20
5177	Hand Lever Ratchet		5250	Control Cap Stud	.08
5178	Foot Brake PedalService Brake Cross Shaft		5251 5252	Control Cap Stud Nut	
5179 5180	Emergency Brake Cross Shaft		5253	Lever Washer	
5181	Emergency Brake Shaft Bracket	40	5254	Throttle Control Lever Plate	.06
5182	Service Brake Shaft Bracket		5255	Spark Control Lever Plate	
5183	Emergency Brake Shaft Bracket Shin Service Brake Shaft Bracket Shim		5256 5257	Control Lever Compression Plate Bowen Oiler No. 0	
5184 5185	Service Grake Shaft Bracket (Front).	4.0	5258	Main Shaft Bushing (Lower)	50
5186	Service Cross Shaft Bracket (Rear)	45	5259	Steering Gear Bracket	2.75
5187	Idler Lever Support Bracket		5260	Mast Jacket Bracket	1.45
5188	Idler Lever Support Bracket Shim Emergency Cross Shaft Lever (Front)	04	5261 5262	Steering Connecting Rod Connecting Rod Plug (Front)	
5189 5190	Service Cross Shaft Lever (Inner)	55	5263	Connecting Rod Plug (Rear)	.11
5191	Emergency Brake Idler Lever	50	5264	Connecting Rod Spring and Ball Seat.	.11
5192	Service Brake Idler Lever	30	5265	Connecting Rod Spring	.12
5193	Head Lamp	5.75	5266 5267	Transmission Oil Pump Rotor Transmission Oil Pump Vane	
5194 5195	Lighting and Ignition SwitchUs Battery Bracket	50	5268	Transmission Oil Pump Spring	.05
5196	Horn		5269	Carburetor Nozzle	. 60
5197	Horn Wire	. 1.10	5270	Carburetor Choke Lever	.75
5198	Horn Button	20	5271 5274	Radiator Name Plate	$\frac{.75}{7.25}$
5199 5200	Horn Button Insert Horn Button Spring	04	5275	Rear Fender (Left)	7.25
5202	Rubber Grommet		5276	Side Apron (Right)	5.25
5203	Hand Lever Pull Rod	45	5277	Side Apron (Left)	5.25
5204	Oil Gauge Pipe	45	5278 5279	Running Board (Right)	5.25 5.25
5205 5206	Hub Cap Wrench Brake Pedal Pull Rod		5280	Hood Sill Spacer	.15
5207	Emergency Brake Pull Rod (Rear)	45	5281	Clutch Pedal Hook Spring	.15
5208	Service Brake Pull Rod (Rear)	45	5282	Thrust Block Adjusting Screw	.07
5209	Brake Pull Rod		5283 5284	Spark Control TubeAccelerator Rod	1.35
5210	Steering Gear Housing	. 4.10	0204	110001014001 1001	

Part No.	Part Name	Price	Part No.	Part Name	Price
5285	Throttle Operating Rod	\$0.14	5353	Spark Lever (Lower) (R. D.)	\$0.50
5286 5287	Rear Axle Housing	80.00	5354	Pinion Housing	
5288	Rear Axle Housing Drain Plug, 1"	$\frac{1.70}{.12}$	5355 5356	Pinion Housing GasketDrive Pinion and Shaft	.15
5289	Rear Axle Housing Drain Plug Gasket	.02	5357	Pinion Adjusting Nut	.25
5290	Rear Axle Housing Drain Plug. 3/"	.10	5358	Pinion Adjusting Nut Washer	.10
5291	Rear Axle Truss Rod	1.00	5359	Pinion Shaft Nut	.11
5292	Truss Rod Nut	.06	5360	Pinion Ball Bearing No. 308	10.20
5293	Differential Case	9.75	5361	Pinion Bearing Spacer	.35
5294 5295	Differential Pinion Shaft Differential Pinion Shaft Set Screw	1.25	5362	Pinion Bearing Retainer	1.30
5296	Differential Pinion	$\frac{.20}{2.50}$	5363 5364	Pinion Bearing Oil Guard	.02
5297	Differential Pinion Spacer	.60	5365	Pinion Bearing Adjusting Nut. Adjusting Nut Set Screw	4.20
5298	Differential Side Gear	6.25	5366	Adjusting Nut Lock	.07
5299	Differential Bearing	6.65	5367	Hexagon Head Cap Screw	.08
5300	Differential Bearing Cap	2.25	5368	Pinion Leather Washer Retainer	.07
5301	Differential Bearing Cap Screw	.07	- 5369	Leather Washer	.50
5302	Differential Bearing Adjusting Nut	1.00	5370	Leather Washer Retainer Spring	.06
5303 5304	Diff. Bearing Adjusting Nut Lock	.04	5371	Head Lamp Reflector	2.25
5305	Bevel Ring Gear	22.00	5372	Head Lamp Rim	2.50
5306	Rear Axle Shaft Axle Shaft Outer Bearing	10.00	5373 5374	Head Lamp Rim Lock Screw	.17
5307	Axle Shaft Washer Retainer (Inner)	.06	5375	Head Lamp Rim Lock Screw Spacer Head Lamp Glass	.20
5308	Axle Shaft Washer Retainer (Outer)	.06	5376	Head Lamp Focus Screw	.10
5309	Axle Shaft Outer Bearing Washer	.00	5377	Head Lamp Focus Spring	.10
	(Cork)	.11	5378	Head Lamp Door Catch Spring	.17
5310	Bearing Adjusting Nut	1.70	5379	Head Lamp Glass Retaining Spring	.10
5311	Bearing Adjusting Nut Lock	.06	5380	Head Lamp Plug Connector	.85
5312	Bearing Adjusting Nut Retainer	.08	5382	Dash Support Bracket (Right)	.11
5313	Bearing Adj. Nut Retainer Washer	00	5383	Dash Support Bracket (Left)	.11
5314	(Leather)Bearing Adjusting Nut Spring	.60	5384	Throttle Lever (Lower) (R. D.)	. 50
5315	Rear Axle Shaft Wheel Key	.08	5385 5386	Steering Gear Housing (R. D.) Steering Gear Housing Cover (R. D.)	4.75
5316	Internal Brake Band Complete	8.50	9900	Use No	5919
5317	Internal Brake Lining	3.00	5387	Steering Gear Worm Wheel (R. D.)	6.50
5318	Internal Brake Shoe	.75	5388	Steering Gear Worm (R. D.)	3.50
5319	Internal Brake Shoe Spring	.06	5389	Clutch Pedal (R. D.)	4.50
5320	Internal Brake Cam	1.60	5390	Clutch Pedal Shaft (R. D.)	.90
5321 5322	Internal Brake Cam Bushing	.30	5391	Foot Pedal Shaft (R. D.)	.55
5323	Internal Brake Cam Spacer Internal Brake Cam Lever	.06	5392	Foot Pedal Shaft Bracket (R. D.)	2.00
5324	Internal Brake Cam Lever Adjuster	.80 .40	5393 5395	Transmission Case Cover (R. D.) Throttle Rod Trunnion	
5325	Internal Brake Band Guide	1.00	5396	Motor Underpan—(Right) (R.D.)	.05 .75
5326	Internal Brake Bank Guide Stud	.60	5397	Spark Control Tube (R. D.)	.75
5327	Internal Brake Band Comp. Spring	.03	5398	Throttle Control Tube (R. D.)	.75
5328	Internal Brake Band Comp. Spring		5399	Foot Brake Pedal (R. D.)	2.00
2000	Adjusting Screw	.17	5400	Service Brake Cross Shaft (R. D.)	1.50
5329 5330	External Brake Band Complete (Left)	13.00	5401	Emergency Cross Shaft Bracket (R.D.)	.50
5331	External Brake Band Complete (Right) External Brake Band Lining	13.00	5402	Hand Brake Lever (R. D.)	3.25
5332	External Brake Band Release Spring .	$\frac{3.25}{.05}$	5403 5404	Hand Brake Lever Latch Rod (R. D.). Hand Brake Lever Ratchet (R. D.).	.60
5333	Ext. Brake Release Spring Retainer	.00	5405	Lever Support Bracket (R. D.)	.60
	(Upper)	.03	5406	Lever Support Bracket Shim (R. D.).	.04
5334	Ext. Brake Release Spring Retainer		5407	Service Brake Pedal Pull Rod (R. D.)	.60
	(Lower)	.03	5408	Service Brake Idler Lever (R. D.)	4.00
5335	External Brake Release Spring Spacer	.25	5409	Radiator Complete	45.00
5336	Ext. Brake Release Spring Spacer Coupling Pin	90	5410	Radiator Shell	6.00
5337	External Brake Support Clip (Left)	.30	5412	Steering Arm (Right) (R. D.)	6.75
5338	External Brake Support Clip (Right).	.20	5413 5414	Steering Arm (Left) (R. D.) Front Spring	$\frac{2.50}{4.15}$
5339	External Brake Lever Shaft	.60	5415	Demountable Rim	4.00
5340	Tail Lamp Bracket	.35	5416		12.50
5341	External Brake Band Lever (Left)	1.70	5417	Rear Wheel Complete	22.00
5342	External Brake Band Lever (Right)	1.70	5418	Demountable Rim Clamp	.08
5343	External Brake Conn. Link (Left)	.30	5419	Demountable Rim Bolt, (½")	.07
5344 5345	External Brake Conn. Link (Right)	.30	5420	Demountable Rim Bolt Nut	.04
	External Brake Toggle Lever (Left) External Brake Toggle Lever (Right).	1.40	5421	Demountable Rim Wrench	.45
5346	PARTIE PIECE I UZZIE LEVEL (KIGHT)	1.40	5422 5423	Fan Drive Pulley Ball Seat Adjusting Plug	2.25
5346 5347	External Brake Adjusting Rod			THE THEAT ATTENDED FIRST	100
5346 5347 5348	External Brake Adjusting Rod	1.40		Transmission Interlock Plate	
5347 5348 5349	External Brake Adjusting Rod Ext. Brake Adj. Rod Torsion Spring External Brake Adjusting Rod Nut.	.06	5429	Transmission Interlock Plate	.45
5347 5348 5349 5350	External Brake Adjusting Rod Ext. Brake Adj. Rod Torsion Spring External Brake Adjusting Rod Nut External Brake Band Guide			Transmission Interlock Plate	.45
5347 5348 5349	External Brake Adjusting Rod Ext. Brake Adj. Rod Torsion Spring.	.06	5429 5430	Transmission Interlock Plate	.45

Part No.	Part Name	Price	Part No.	Part Name	Price
5434	Tool Kit	\$2.85	5508	Front Pri., Aux. and Sec. Shoe As-	
5435	Gasoline Filter Vacuum Tank Plug	.45		sembly	10.50
5436	Ball Stud Dust Cover	.11		relining will be accepted for full credit less a	
5437	Ball Stud Dust Cover Spring	.07	5509	charge of \$3.90 list for relining. Front Pri. and Aux. Shoe Lining	
5438	Ball Stud Dust Cover Washer	.06	9903	(Export Only)	1.00
5439	Exhaust Pipe (65½" long)	1.85	5510	Front Sec. Shoe Lining (Export Only)	1.25
5440	Rear Axle Shaft Spacer	$1.55 \\ .12$	5511	Front Brake Lining Rivet	.01
5441	Adjusting Nut Lock Screw	A CONTRACTOR OF THE PARTY OF TH	5512	Front Pri. and Aux. Shoe Spring	.30
5442	Underpan (Left)		5513	Front Sec. Shoe Spring	.16
5443	Underpan (Left) (R. D.) External Brake Yoke Pin	100000	5514	Front Shoe Spacer Pin Washer (Inner)	.01
5444	Clutch Spring Retainer		5515 5516	Front Shoe Spacer Pin Spring Front Shoe Spacer Pin Washer (Outer)	.01
5445 5446	Choke Tube Clamp Bracket	.25	5517	Front Brake Articulating Pin	.20
5447	Carburetor Body, Upper Half	4.25	5518	Front Backing Plate (Right)	4.50
5448	Carburetor Choke Lever Use No.		5519	Front Backing Plate (Left)	4.50
5449	Carburetor Throttle Lever Use No.		5520	Brake Backing Plate Bolt	. 03
5450	Demountable Rim Tool	1.60	5521	Rear Axle Housing	
5451	Bevel Ring Gear	18.00	5522	Propeller Shaft	14.00
5452	Drive Pinion and Shaft	12.50	5523	Universal Joint Flange (Tran. End)	3.50
5453	Oil Filtrator Gasket (R. D.)		5524 5525	Front Wheel Complete Front Wheel Brake Drum	5.25
5454	First Leaf BushingOil Filtrator Tube (R. D.)		5526	Front Drum Bolt and Nut	.09
5455 5457	Oil Filtrator Flange (R.D.)	1.80	5527	Wheel Brake Drum Hole CoverUse	
5458	Filtrator Bracket Screw (R.D)		5528	Wheel Hub Cap	.30
5459	Reverse Gear Bushing	. 60	5529	Rear Wheel Complete	
5460	Reverse Sliding Gear	14.00	5530	Rear Wheel Brake Drum	
5461	Main Drive Shaft (Rear)	27.00	5531	Rear Brake Drum Bolt and Nut	.16
5462	Sliding Gear	13.75	5532	Demountable Rim Bolt	.10
5463	Countershaft	10.00	5533	Radiator Complete	
5464	Transmission Cap (Rear)		5534 5535	Radiator Shell	2.00
5465 5466	Carburetor Body, Upper Half Carburetor Throttle Lever		5536	Foot Brake Pedal (R. D.)	2.00
5468	Carburetor Choke Lever		5537	Pedal Shaft Bracket (R. D.)	1.00
5469	Carburetor Choke Tube Clamp	7 7 7 7	5538	Brake Cross Shaft	1.60
0100	Bracket	.30	5539	Brake Cross Shaft (R. D.)	1.60
5470	Shifting Shaft		5540	Cross Shaft Bracket (Center)	.30
5471	Demountable Rim Clamp Ring	1.20	5541	Cross Shaft Bracket (Outer)	. 60
5472	Drive Pinion and Shaft	15.75	5542	Cross Shaft Bracket Bushing	.11
5473	Bevel Ring Gear	.15	5543 5544	Brake Pedal RodBrake Pedal Rod (R. D.)	.50
5474	Vacuum Tank Feed Pipe Elbow Frame Complete		5545	Hand Brake Lever Pull Rod	.50
5477 5478	Front Spring Horn (Right)		5546	Hand Brake Lever Pull Rod (R. D.)	.40
5479	Front Spring Horn (Left)		5547	Front Brake Rod (Front)	.2
5480	Steering Knuckle (Right)		5549	Rear Brake Pull Rod (Front)	.4
5481	Steering Knuckle (Left)		5550	Rear Brake Pull Rod (Rear)	.30
5482	Steering Arm (Right)		5551	Front Brake Rod End Clevis	.4
5483	Steering Arm (Left)	4.50	5552	Cross Shaft Lever (Outer)	
5484	Steering Arm (Right) (R. D.) Steering Arm (Left) (R. D.)	4.50 3.00	5553 5554	Over-running Link	
5485 5486	Front Control Lever (Right)		5555	Idler Lever, Front (Left)	
5487	Front Brake Control Shaft	2 25	5556	Brake Idler Lever (Rear)	
5488	Trunnion for "U" Joint	. 1.45	5557	Idler Lever Bracket (Left)	.20
5489	Trunnion Pin Locking Pin	01	5558	Idler Lever Bracket (Right)	.2
5490	Front Brake Trunnion Pin		5559	Ball End Complete	1.9
5491	Front Brake Cam and Shaft	. 2.90	5560	Ball End Bracket (Right)	.3
5492	Front Brake Carrier Bracket		5561	Ball End Bracket (Left)	.3
5493	Front Carrier Bracket Key "U" Joint Cover	06 36	5562 5563	Mast Jacket Bracket Clamp	.1
5494	"U" Joint Cover Cap	14	5564	Rear Fender (Right)	
5495 5496	Control Shaft Cap Spring		5565	Rear Fender (Left)	
5497	Control Shaft Spring Retainer		5566	Side Apron (Right)	5.5
5498	Shaft Spring Retainer Ring	And the second	5567	Side Apron (Left)	5.5
5499	Front Carrier Bracket Bolt	09	5568	Running Board Complete (Right)	5.2
5500	Front Carrier Bracket Nut		5569	Running Board Complete (Left)	5.2
5501	Carrier Bracket Nut Spring		5570	Hood Complete	13.0
5502	Front Reinforcement Plate (Right)		5571	Floor Mat (Rubber)	2.0
5503	Front Reinforcement Plate (Left)	. 1.45	5572 5573	Demountable Rim Wrench	2.0
5504	Front Brake Anchor Pin Washer	05	5574	Hub Cap Wrench	.7
5505	(Outer) Front Brake Sec. Anchor Pin Washe	r	5575	Front Bumper	2.7
0000	(Inner)	02	5576	Front Bumper Bolt	0
A ANNAL STATE			5577	Front Bumper Bracket (Left)	1.0
5506	Front Brake Anchor Pin Link	10	9911	Trone Bumper Bruches (Bers)	1.0

STAR

Part No.	Part Name	Price	Part No.	Part Name	Price
5579	Bumper Bracket Spacer		20022	Front Wheel Hub	\$3.50
5580	Hood Hinge Bracket (Front)	. 50	20023	Front Wheel Hub Flange	. 50
5581	Tie Rod Complete	7.00	20024	Demountable Rim	
5582	Brake Square Nut and Ball Use No.		20025	Demountable Rim Bolt	. 10
5583 5584	Steering Knuckle Stop Screw Nut	1.70	20026	Front Wheel Retainer Lock Wire	
5585	Rear Brake Cam and Shaft	.16	20027 20029	Front Wheel Retainer (Outer)	
5586	Rear Brake Carrier Bracket	.95	20029	Front Wheel Retainer (Inner) Hub Cap	
5587	Rear Backing Plate (Left)	3.95	20034	Rear Wheel Hub	3.00
5588	Rear Backing Plate (Right)	3.95	20035	Rear Wheel Brake Drum	3.00
5589	Rear Reinforcement Plate (Left)	1.45	20036	Front Wheel Complete	9.00
5590	Rear Reinforcement Plate (Right)		20037	Rear Wheel Complete, Wood	
5591	Rear Pri., Aux. and Sec. Shoe Assembly.		20038	Rear Axle Shaft Outer Bearing Oil Washer (Steel)	1777
77	Note: Brake Shoe Assembly returned for relining will be accepted for full credit less a		20039	Rear Axle Shaft Outer Bearing Oil	8 E 14 M
	charge of \$4.50 list for relining.	A 100 A	20044	Washer (Leather)	1.8
5592	Rear Pri. and Aux. Shoe Lining		20049	Rear Cross Member	
	(Export Only)	1.20	20050	Gasoline Tank Support (Front)	
5593	Rear Sec. Shoe Lining (Export Only).	1.40	20051	Gasoline Tank Support (Rear)	
5594	Rear Pri. and Aux. Shoe Spring	.45	20052	Front Spring Horn (Right)	
5595	Rear Secondary Shoe Spring		20053	Front Spring Horn (Left)	1.10
5596	Rear Brake Control Lever (Right)	1.25	20054	Rear Spring Horn (Right)	1.1
5597 5598	Rear Brake Control Lever (Left)	1.25	20055	Rear Spring Horn (Left)	1.1
5599	Rear Brake Anchor Pin Link Special Alemite Fitting		20057	Front Spring Bracket	.9
5600	Carriage Bolt, 1/4"—20x11/8	.16	20060	Rear Spring Bracket	1.1
5601	Front Backing Plate Oil Guard	.45	20062	Hood Catch Clip	7.0
5602	Rear Backing Plate Oil Guard	.90	20063 20064	Muffler and Tubular Backbone	
5603	Door Complete (Left)Upon Appl	lication	20065	Step Hanger	
5604	Door Complete (Right)Upon Appl	lication	20068	Gasoline Tank Support (Left) Front and Rear Spring Bolt	.6
5605	Back Window Glass	2.50	20069	Front Spring Axle Clip	
5606	Windshield Frame and Glass	18.50	20070	Front Spring Axle Clip Bolt	.1
5607	Windshield Frame and Glass (R. D.).	17.50	20071	Rear Spring (7 Leaves)	5.0
5608	Cab Body Complete Upon App	lication	20072	Rear Spring Shackle	.9
5609	Cab Body Complete (R.D.) Upon App.		20073	Rear Spring Clip Plate	.14
5610	Seat Cushion (Right)	8.00	20083	Front and Rear Spring Bushing	
5611	Seat Cushion (Left)	8.00	20084	Front Spring Center Bolt with Nut	
5612	Carburetor Complete	20.00	20097	Spring Center Bolt with Nut	.0
5613 5614	Carburetor Air Horn	arror.	20100	Steering Gear Instrument Board Bracket	.8
	(R. D.)	.50	20101	Steering Wheel	4.2
5615	Steering Adjusting Nut Bushing		20102	Steering Connecting Rod Complete	1.6
5616	Steering Adjusting Nut Spring Washer		20106	Oil Pressure Gauge	2.0
5617 5618	Steering Gear Housing Stud Sleeve	.60	20107	Oil Pressure Gauge Pipe, with Nuts	. 5
5619	Adjusting Stud Sleeve Lock Ring Steering Gear Housing Adjusting Stud	.20	20108	Gasoline Tank Complete	
5620	Steering Gear Adjusting Screw Nut		20109	Gasoline Tank Complete	6.5
5621	Steering Worm Wheel Adjusting Screw		20111	Gasoline Tank Filler Cap with Gasket	
5622	Steering Gear Adjusting Screw		20112	Gasoline Tank Filler Cap	
5623	Steering Gear Housing Cover Gasket		20112	Gasoline Tank Strap Complete	
5624	Steering Gear Housing Cover	4.25	20114	Gasoline Tank Strap Complete	
5625	Steering Gear Housing (L. D.)	4.75	20117	Carburetor Throttle Valve Lever	
5626	Steering Gear Housing (R. D.)	4.75	20118	Carburetor Throttle Valve Lever	
5627	Universal Joint Flange		20119	Intake Manifold Extension	
20000	Front Axle "I" Beam	24.00	20120	Carburetor Feed PipeUse No	. 2250
20001	Steering Knuckle (Left)	6.50	20122	Gasoline Line, with Nuts	
20002	Steering Knuckle (Right)	6.50	20123	Gasoline Line, with Nuts	1.4
20003	Steering Knuckle Bushing (Lower)	. 12	20124	Exhaust Pipe	
20004	Thrust Washer Dowel	01	20125	Deck Door Lock Striker Plate	
20005	Thrust Washer (Lower)	.16	20135	Gasoline Tank Filler Cap Gasket	
20006	Thrust Washer (Upper)	.16	20136	Piston with Pin (.003" oversize)	
20007	Steering Knuckle Bushing (Upper)		20139	Clutch Plate and Shaft Complete	5.0
20008	Steering Knuckle King Pin		20140	Clutch Friction Sector	. 1
20009 20010	Steering Knuckle King Pin Set Screw Steering Knuckle Dust Cap	05	20142	Clutch Pressure Ring Bolt	
20010			20143 20145	Clutch Pressure Ring	$2.9 \\ .0$
20011	Steering Knuckle Bearing Washer Steering Knuckle Spindle Washer		20145	Clutch Spring Retainer	.1
20012	Steering Bearing Adjusting Nut	.14	20147	Clutch Cover Plate Complete	6.7
20015	Steering Arm Bushing		20149	Top Deck with Side Quarters	6.2
20017	Tie Rod End Pin Nut	.08	20150	Clutch Lifting Lever	
20018	Steering Arm Ball	.80	20151	Clutch Collar	
20019	Steering Arm Ball Nut	.13	20152	Piston with Pin (.005" oversize)	
20020	Rear Fender (Right)	6.50	20155	Piston with Pin (.010" oversize)	2.4
				Clutch Pedal Support	

Prices subject to change without notice

Part No.	Part Name	Price	Part No.	Part Name	Price
20157	Clutch Shaft Bracket Support		20287	Ball Bearing.	\$4.00
20158 20159	Clutch Shaft Yoke	. 50 . 95	20288 20289	Spline Shaft Bearing Retainer Gasket (Rear)	$\frac{3.25}{.02}$
20160	Service Brake Strap Complete	1.05	20290	Bearing Retainer (Rear)	1.45
20161	Fan Spindle	.95	20292	Transmission Case Cover	1.40
20162	Fan Hub	1.05	20293 20294	Transmission Case Cover Gasket	.02
20163	Fan Blade Complete Fan Washer (Felt)	.95	20294	Gear Shift LeverGear Shift Lever	$\frac{2.00}{2.25}$
20164 20165	Fan Spindle Nut	.09	20296	Shift Lever Grip	.25
20166	Fan Belt	.45	20297	Shift Lever Guide Pin	.04
20168	Fan Washer (Fibre)	.07	20298	Shift Lever Cap	.04
20169	Radiator Complete Radiator Shell with Name Plate	6.50	20299 20300	Shift Lever Spring	.06
20170 20171	Radiator Bracket Cap	.07	20301	Lock Plunger Spring	
20172	Door and Window Lifting Arm Spring		20302	Lock Plunger	.16
20174	Split Rivet	.01	20303 20304	Shifting Shaft Shifting Fork (Low and Reverse)	.15
20176 20179	Radiator Outlet Pipe	.60	20304	Shifting Fork (High and Intermediate)	.90
20180	Radiator Filler Cap Gasket	.07	20306	Transmission Interlock Plate	.40
20181	Rear Axle Housing Complete	30.00	20307	Universal Joint Coupling Hub	1.50
20182	Rear Axle Housing Cover	1.15	20308 20309	Universal Joint Coupling Liner Universal Joint Coupling Cover	.18
20183 20186	Rear Axle Housing Cover Gasket Battery Bracket	$.05 \\ .40$	20310	Universal Joint Coupling Cover	$\frac{1.05}{.03}$
20187	Battery Strap Complete	.40	20311	Universal Joint Coupling Bushing	.03
20190	Headlamp	5.00	20312	Radiator and Body Hood Lace	.10
20193	Headlamp Bracket (Left) Headlamp Bracket (Right)	$\frac{1.25}{1.25}$	20313 20314	Body Cowl Rail	.90 .85
20194 20195	Headlamp Tie Rod	.40	20314	Instrument Board	3.00
20203	Brake Pull Rod	.35	20318	Bearing Housing Shim	.10
20206	Lighting and Ignition Switch	2.00	20319	Toe Board Support (Left)	.20
20207	Ammeter	$\frac{1.50}{.05}$	20320 20321	Toe Board Support (Right) Front Door Hinge (Upper)	.20 .35
20210 20212	Radiator Name Plate	.65	20322	Front Door Hinge (Lower)	.35
20213	Rear Spring (Nine Leaves)	6.00	20323	Door Lock (Left)	.80
20215	Foot Brake Pedal Complete	.95	20324 20325	Door Lock (Right)	.80
20216 20218	Brake Pull Rod Clevis Front Service Pull Rod	.40 .45	20326	Rear Door Hinge (Upper)	.05 .55
20219	Turnbuckle		20327	Rear Door Hinge (Lower)	. 55
20220	Hex. Nut (L. H. Thread)	.03	20328	Door Striker Plate	.06
20221	Brake Cross Shaft Bracket		20330 20336	Rear Door Bumper	.05 1.15
20222 20223	Brake Shaft Center Bearing Service Brake Cross Shaft	.65	20340	Top Iron (Right)	.50
20224	Emergency Brake Cross Shaft	. 80	20341	Top Iron (Left)	. 50
20227	Hand Brake Lever	2.15	20346	Deck Door Hinge.	. 55
20229 20232	Hand Brake Lever Ratchet Pawl Hand Brake Lever Latch Rod Cap	$\frac{.25}{.20}$	20347 20348	Front Fender Complete (Left) Front Fender Complete (Right)	8.50 8.50
20232	Hand Brake Lever		20351	Running Board (Left)	3.25
20234	Hand Brake Lever Latch Rod	.25	20352	Running Board (Right)	3.25
20235	Hand Brake Lever Latch Rod	$.25 \\ .04$	20353 20354	Side Apron (Left)	$\frac{3.50}{3.50}$
20236 20238	Hand Brake Lever Ratchet Pawl Bolt. Hand Brake Lever Ratchet		20355	Side Apron (Left)	3.50
20239	Service Brake Strap Complete	1.05	20356	Side Apron (Right)	3.50
20240	Emergency Brake Strap Complete	1.05	20357	Radiator Splash Apron	
20241	Service Brake Strap Adjusting Yoke	1.10	20358 20359	Rear Fender (Right)	$6.00 \\ 6.00$
20242 20243	Throttle Lever	1.10	20360	Rear Fender (Right)	
20244	Control Rod Trunnion		20361	Rear Fender (Left)	10.00
20245	Throttle Rod Trunnion Front	.30	20362	Rear Fender (Right)	
20246	Spark LeverSpark Rod	1.10 .15	20363 20368	Rear Fender (Left)	11.00
20247 20248	Control Lever Clip		20369	Rear Fender Iron (Left)	
20249	Control Guide Bar	.16	20371	Hood Complete	8.50
20250	Accelerator Rod	.25	20372	Hood Catch Spring	
20251	Throttle Return SpringOil Pressure Gauge Pipe	.15 .35	20373 20374	Hood Catch Spring	
20256 20260	Transmission Case Stud	.05	20375	Underpan (Left)	.90
20261	Transmission Case Stud	.04	20376	Front Door Upholstery (Right)	.80
20262	Transmission Case with Studs	6.50	20377	Front Door Upholstery (Left)	.80
20275	Expansion Plug	$\frac{.04}{4.00}$	20378 20379	Rear Door Upholstery (Right) Rear Door Upholstery (Left)	.80 .80
20276 20280	Bearing Retainer Gasket (Front)		20380	Escutcheon Plate	.03
20281	Bearing Retainer (Front)	.75		First Top Bow	
20282	Rear Spring Clip	$\frac{.30}{3.70}$	20382 20383	Second Top BowThird Top Bow	.90
20284	Rear Wheel Bearing Housing Transmission Oil Guard (Rear)			Fourth Top Bow	.90
20286	Transmission on Guard (Rear)			LA TOUR TOP BOW COME.	

20395 Back Curtain Inner Frame	Part No.	Part Name	Price	Part No.	Part Name	Price
28938 Back Curtain Light Lens. 90 26552 Front Floor Mat. \$2.15 28938 Back Curtain Light Lens. 90 26552 Front Floor Mat. \$2.15 28938 Back Curtain Light Lens. 90 26552 Front Floor Mat. \$2.25 28939 Windshield Complete. 90 90 28555 Left Front Side Curtain. 3.25 28939 Windshield Lower Panel Complete 10.00 26552 Left Front Side Curtain. 3.25 289400 Windshield Lower Panel Complete 10.00 26562 Filman Arm. 1.90 280401 Windshield Cower Glass. 4.50 26563 Filman Arm. 1.90 280401 Windshield Cower Glass. 4.50 26563 Filman Arm. 1.90 280401 Windshield Side Arm (Right). 2.25 26663 Steering Gear Housing Cover. 4.50 280404 Windshield Side Arm (Right). 2.25 26665 Steering Gear Worm Adjusting Nut. 6.5 280407 Windshield Side Arm (Right). 2.25 26660 Steering Gear Worm Adjusting Nut. 6.5 280407 Windshield Floor Advanced Length Side Side Side Side Side Side Side Side		Back Curtain Inner Frame	\$0.40	20591	Top Deck with Side QuartersUse	21422
20398 Windshield Complete 30,00 20595 Left Front Side Curtain 2,25 20398 Windshield Complete 10,00 20595 Left Front Side Curtain 2,25 20400 Windshield Lower Panel Complete 10,00 20595 Left Front Side Curtain 2,25 20400 Windshield Lower Panel Complete 10,00 20595 Left Front Side Curtain 2,25 20400 Windshield Lower Glass 4,50 20402 Pitnan Arm Nit. 1,00 20402 Windshield Lower Glass 4,50 20402 Pitnan Arm Nit. 1,00 20403 Windshield Side Arm (Right) 2,25 20606 Steering Gear Housing Cover 45 20406 Windshield Side Arm (Right) 2,25 20606 Steering Gear Housing Cover 45 20406 Windshield Curtain Fastener 11 20608 Steering Gear Worm Wheel 1,15 20406 Windshield Charles Tastener 11 20608 Steering Gear Worm Wheel 1,15 20409 Windshield Charles Top Stud 2,25 20606 Steering Gear Worm Wheel 1,15 20409 Windshield Charles Top Stud 2,25 20606 Steering Gear Worm Wheel 1,15 20409 Windshield Charles Top Stud 2,25 20606 Steering Gear Worm Key 1,20 20413 Top Floider Bushing 6,6 20615 Steering Gear Worm Key 1,20 20413 Top Floider Bushing 6,6 20615 Steering Gear Worm Key 1,20 20419 Tail Lamp Support 4,5 20616 Steering Gear Main Shaft Nut 3,0 20419 Tail Lamp Support 1,10 20619 Horn Button 2,00 20419 Tail Lamp Support 1,10 20619 Horn Button 2,00 20422 Headlamp Reflector 1,5 20617 Steering Gear Main Shaft Nut 3,0 20422 Headlamp Reflector 1,5 20622 Worm Wheel Thrust Washer 0,2 20443 Top Bow Socket (Left) 4,25 20622 Worm Wheel Thrust Washer 0,2 20443 Top Bow Socket (Left) 4,25 20622 Worm Wheel Thrust Washer 0,2 20443 Top Bow Socket (Left) 4,25 20622 Worm Wheel Thrust Washer 0,2 20443 Top Bow Socket (Left) 4,25 20622 Worm Wheel Thrust Washer 0,3 20442 Top Bow Socket (Left) 4,25 20622 Worm Wheel Thrust Washer 0,3 20442 Top Bow Socket (Left) 4,25		Back Curtain Outer Frame				\$2.15
20399 Windshield Upper Panel Complete 10.00 20596 Tonneau Floor Carpet 2.50 20400 Windshield Upper Panel Complete 10.00 20596 Tonneau Floor Carpet 2.50 20401 Windshield Upper Glass . 4.50 20596 Tonneau Floor Carpet 2.50 20401 Windshield Upper Glass . 4.50 20596 Tonneau Floor Carpet 2.50 20401 Windshield Upper Glass . 4.50 20596 Tonneau Floor Carpet 2.50 20401 Windshield Sids Arm (Right) . 2.25 20596 Steering Gear Housing Cover . 5.00 20404 Windshield Sids Arm (Right) . 2.25 20596 Steering Gear Worm Moles! . 1.15 20406 Windshield Sids Arm (Right) . 2.25 20596 Steering Gear Worm Adjusting Nut . 6.5 20407 Windshield Privot Stud . 2.5 20590 Worm Adjusting Nut Packing . 0.2 20407 Windshield Privot Stud . 2.5 20590 Worm Adjusting Nut Lock . 1.15 20409 Windshield Orne Man Top Stud . 2.5 20591 Worm Adjusting Nut Lock . 1.15 20409 Windshield Orne Man Top Stud . 2.5 20591 Worm Adjusting Nut Lock . 1.15 20419 Windshield Orne Man Top Stud . 2.5 20591 Worm Adjusting Nut Lock . 1.15 20419 Windshield Orne Man Top Stud . 2.5 20591 Steering Gear Main Shaft . 2.00 20415 Horn . 2.5 20591 Worm Adjusting Nut Lock . 1.15 20591 Worm Adjusting Nut Lock . 2.0 20591 Worm Wheel Trust Washer . 2.0 20591 Worm Adjusting Nut Lock . 2.5 20591 Worm Adjusting N		Back Curtain Light Lens				
200400 Windshield Lower Panel Complete 10.00 200602 Pitman Arm Nut. 1.90 200401 Windshield Lower Panel Complete 10.00 200602 Pitman Arm Nut. 1.90 200402 Windshield Lower Glass 4.50 200603 Pitman Arm Nut. 1.90 200402 Windshield Lower Glass 4.50 200603 Pitman Arm Nut. 1.90 200402 Windshield Curet and Fastener 2.50 200604 Steering Gear Housing Cover 5.50 200404 Windshield Curetain Fastener 2.11 200609 Worm Adjusting Nut Packing 0.2 200408 Windshield Curetain Fastener 2.11 200609 Worm Adjusting Nut Packing 0.2 200408 Windshield Privot Acorn Nut 10 200609 Worm Adjusting Nut Packing 0.2 200408 Windshield Privot Stud 2.5 200610 Steering Gear Worm 1.45 200408 Windshield Privot Stud 2.5 200610 Steering Gear Worm 1.45 200408 Windshield Privot Stud 2.5 200610 Steering Gear Worm Key 0.0 200412 Tool Polder 2.50 200412 Tool Polder 2.50 200412 2004		Windshield Complete				
20401 Windshield Lower Glass 4.50 20602 Pitman Arm Nut.sing 5.10 20402 Windshield Lower Glass 4.50 20603 Steering Gear Housing 5.10 20402 Windshield Curtain Fastener 11 20608 Steering Gear Worm Wheel 1.55 20404 Windshield Curtain Fastener 11 20608 Steering Gear Worm Wheel 1.55 20407 Windshield Pivot Stud. 25 20610 Worm Adjusting Nut 2020409 Windshield Pivot Stud. 25 20610 Worm Adjusting Nut Packing 6.02 20409 Windshield Pivot Stud. 25 20611 Steering Gear Worm Mylore 1.40 20419 Windshield One-Man Top Stud. 20 20611 Steering Gear Worm Mylore 1.40 20419 Windshield One-Man Top Stud. 20 20611 Steering Gear Worm Key 20 20410 Windshield One-Man Top Stud. 20 20611 Steering Gear Worm Key 20 20411 Horn Joder Bushing 8.75 20616 Steering Gear Worm Key 20 20412 Handlamp Support. 4.5 20613 Steering Gear Worm Key 20 20413 Wedge 1.5 20618 Steering Gear Worm Key 20 20420 Rim Wedge 1.5 20618 Steering Gear Worm Key 20 20421 Handlamp Reflector 1.65 20618 Steering Gear Worm Key 20 20422 Rim Wedge 1.5 20618 Steering Gear Worm Key 20 20423 Handlamp Reflector 1.65 20618 Steering Gear Warm Key 20 20424 Rim Wedge 1.5 20618 Steering Gear Warm Key 20 20425 Rim Wedge 1.5 20618 Steering Gear Warm Key 20 20426 Rim Wedge 1.5 20618 Steering Gear Warm Key 20 20427 Handlamp Reflector 1.65 20618 Steering Gear Warm Key 20 20428 Rim Wedge 1.5 20618 Steering Gear Warm Key 20 20429 Rim Wedge 1.5 20618 Steering Gear Warm Key 20 20421 Handlamp Reflector 1.65 20618 Steering Gear Worm Key 20 20422 Rim Wedge 1.5 20618 Steering Gear Worm Key 20 20423 Handlamp Reflector 1.65 20618 Steering Gear Worm Key 20 20424 Rim Wedge 1.5 20618 Steering Gear Worm Key 20 20425 Rim Wedge 2.5 20618 Steering Gear Worm Key 20 20426 Rim Wedge				and the second s		
204012 Windshield Upper Glass		Windshield Lower Panel Complete	10.00		Pitman Arm	
20404 Windshield Side Arm (Left) 2.25 20606 Steering Gear Worm Wheel 1.15 20404 Windshield Curtain Fastener 11 20608 Steering Gear Worm Wheel 1.15 20407 Windshield Pivot Stud. 25 20606 Steering Gear Worm Adjusting Nut 20409 Windshield Pivot Stud. 25 20610 Worm Adjusting Nut Packing 0.92 20408 Windshield Pivot Stud. 25 20610 Worm Adjusting Nut Packing 0.92 20419 Windshield One Man Top Stud 20 20611 Steering Gear Worm Adjusting Nut Packing 0.92 20419 Windshield One Man Top Stud 20 20611 Steering Gear Warm Korg. 0.62 20411 Top Holder Bushing 0.62 20612 Steering Gear Main Shaft 2.00 20415 Top Holder Bushing 0.62 20612 Steering Gear Main Shaft 2.00 20416 Tom 8.75 20618 Steering Gear Main Shaft 2.00 20417 Wedge 1.5 20618 Steering Gear Mast Jacket Bushing 5.00 20412 Headlamp Door 1.10 20619 Horn Button 5.00 20412 Headlamp Reflector 1.55 20623 Horn Button 5.00 20412 Headlamp Reflector 1.55 20623 Horn Button Screw 5.00 20412 Top Bow Socket (Left) 4.25 20622 Worm Wheel Thrust Washer 2.00 20413 Propeller Shaft 9.00 20625 20414 Universal Joint Yoke 8.35 20623 200447 Universal Joint Yoke 2.75 20622 Vorm Wheel Thrust Washer 2.00 20412 Universal Joint Talney Yoke 2.75 20627 Stutt Off Cock 3.0 20413 Propeller Shaft 2.00 20623 200447 Universal Joint Flange Yoke 2.75 20627 Stutt Off Cock 3.0 20415 Carburetor Float Uso No. 22804 20635 Fluino Bearing Shim 0.5 20416 Carburetor Thorttle Evers Green (Long) 20625 20626 20626 20626 20418 Carburetor Thorttle Evers Green (Long) 20625 20626 20419 Carburetor Float Lever Prime 20626 20626 20410 Carburetor Float Lever Prime 20626 20411 Carburetor Float Lever Prime 20626 20412 Carburetor Float Shaft Gasket 0.5 20413 Carburetor Float Shaft Gasket 0.5 20414 Carburetor Float Shaft Gasket 0.5		Windshield Upper Glass	4.50		Pitman Arm Nut	
20404		Windshield Lower Glass			Steering Gear Housing Cover	
204047 Windshield Curtain Fastener		Windshield Side Arm (Right)	2.25		Steering Gear Worm Wheel	
20408 Windshield Pivot Acorn Nut.		Windshield Curtain Fastener	11		Steering Gear Worm Adjusting Nut	
20408 Windshield Pivot Stud. 25 20610 Worm Adjusting Nut Lock. 12 20412 Top Holder Bushing 3.06 20615 Steering Gear Worm. 2.0 20413 Top Holder Bushing 3.06 20615 Steering Gear Worm Key. 2.0 20413 Top Holder Bushing 3.06 20615 Steering Gear Worm Key. 2.0 20413 Top Holder Bushing 3.06 20615 Steering Gear Worm Key. 2.0 20413 Top Holder Bushing 3.06 20615 Steering Gear Worm Key. 2.0 20419 Tail Lamp Support. 3.4 20419 Tail Lamp Support. 3.5 20619 Tolder Mark 20419 Tail Lamp Support. 3.6 20420 Rim Wedge. 1.5 20618 Steering Gear Mast Jacket Bushing. 5.0 20421 Headlamp Door. 1.10 20619 Horn Button Screw 0.0 20422 Headlamp Reflector. 1.65 20620 Horn Button Screw 0.0 20422 Headlamp Reflector. 1.65 20622 Horn Button Screw 0.0 20423 Top Bow Socket (Right) 4.25 20624 Throttle Rod. 2.0 20431 Propeller Shaft. 4.25 20624 Throttle Rod. 2.0 20431 Propeller Shaft. 2.5 20624 Throttle Rod. 2.0 20431 Propeller Shaft. 2.5 20624 Throttle Rod. 3.0 20442 Universal Joint Flange Yoke. 2.7 5 20627 Shut Off Cock. 3.0 20444 Universal Joint Flange Yoke. 2.7 5 20627 Shut Off Cock. 3.0 20445 Carburetor Nozele. 2.6 20627 Shut Off Cock. 3.0 20445 Carburetor Nozele. 2.6 20628 Shut Off Cock. 3.0 20445 Carburetor Throttle Shaft. 2.5 20624 Throttle Rod. 3.0 20445 Carburetor Throttle Shaft Gasket 0.5 20637 Drive Pinion Adjusting Nut Lock. 0.5 20453 Carburetor Choke Lever 3.0 20462 Carburetor Choke Lever 3.0 20464 Drive Pinion Shaft Key. 3.0 20463 Carburetor Choke Lever 3.0 20464 Drive Pinion Shaft Key. 3.0 20464 Carburetor Choke Lever Shortle Cock Shaft. 2.0 20641 Drive Pinion Shaft Key. 2.0 20445 Carburetor Choke Lever Shortle Cock Shaft 3.0 20641 Drive Pinion Shaft Key. 3.5 20461 Carburetor Choke Lever Shortle Cock Shaft 3.0 20641 Drive Pinion Shaft Key. 3.5 20641 Carburetor Choke Lever Shortle Cock Shaft 3.0 20641 Drive Pinion Shaft Key. 3.5 20641 Carburetor Choke Lever Pin. 3.0 20641 Drive Pinion Shaft Key. 3.5 20641 Carburetor Choke Lever Pin. 3.0 20641 Carburetor Float Lever Lever More 3.0 20645 Carburetor Float Switch Key. 3.0 20645 Carburetor		Windshield Pivot Acorn Nut.			Worm Adjusting Nut Packing	
20413 Top Holder .		Windshield Pivot Stud				
20413 Top Holder Bushing		Windshield One-Man Top Stud			Steering Gear Worm You	
20419 Tail Lamp Support		Ton Holder Rushing			Steering Gear Main Shaft	
20419 Tail Lamp Support		Horn	3.75		Steering Gear Main Shaft Nut	
20421 Headlamp Door.		Tail Lamp Support	.45		Steering Gear Mast Jacket	
20429 Headlamp Reflector.		Rim Wedge				
20429 Top Bow Socket (Left)		Headlamp Door				
20431 Propeller Shaft		Top Bow Socket (Left)				
20432 Universal Joint Yoke		Top Bow Socket (Right)			Throttle Rod	
20449 Carburetor Choke 2.75 20627 Shut Off Cock 3.0 20445 Carburetor Float Use No. 22804 20635 Pinion Bearing Shim 0.5 20456 Carburetor Inlet Screen 0.5 20636 Drive Pinion and Shaft 7.50 20456 Carburetor Invottle Shaft 2.5 20637 Drive Pinion Adjusting Nut 0.5 20458 Carburetor Throttle Shaft 0.5 20638 Drive Pinion Adjusting Nut 0.5 20459 Carburetor Throttle Shaft 0.5 20638 Drive Pinion Adjusting Nut 0.6 0.5 20459 Carburetor Chottle Lever Screw (Long) 0.5 20640 Drive Pinion Felt Washer 0.5 20463 Throttle Lever Screw (Short) 0.5 20641 Drive Pinion Felt Washer 0.5 20464 Carburetor Choke Lever 0.5 20641 Drive Pinion Jam Nut 0.5 20465 Carburetor Choke Shaft 2.0 20643 Drive Pinion Shaft Key 0.8 20465 Carburetor Choke Shaft 2.0 20643 Drive Pinion Shaft Key 0.8 20466 Carburetor Choke Lever Strew 0.5 20646 External Brake Support (Left) 1.05 20467 Carburetor Choke Lever Spring 2.0 20646 External Brake Support (Left) 1.05 20467 Carburetor Choke Lever Pin 0.5 20646 External Brake Toggle Lever (Left) 3.5 20473 Land Lever 20648 20648 External Brake Toggle Lever (Left) 3.6 20473 Switch Resistance Unit 3.0 20649 External Brake Lever Link 3.6 20473 Switch Resistance Unit 3.0 20649 External Brake Lever Link 3.6 20473 Neelle Valve Adjusting Screw 3.6 20650 External Brake Lever Link 3.6 20473 Drive Drino Post Lever Pinion Screw 3.6 20650 External Brake Lever Link 3.6 20473 Drive Drino Post Lever Pinion Screw 3.6 20650 External Brake Lever Link 3.6 20474 Switch Resistance Unit 3.0 20649 External Brake Lever (Left) 3.6 20475 Drive Drino Post Lever 3.6 20650 External Brake Lever (Left) 3.6 20471 Drive Drino Post Lever 3.6 20650 External Brake Lever (Left) 3.6 20472 Switch Resistance Unit 3.0 20650 External Brake Lever (Left) 3.6 20473 Drive Dri		Propeller Shaft			Spark Control Rod	
20445		Universal Joint Yoke			Accelerator Rod	.30
20452 Carburetor Float		Carburator Complete			Tool Wit	1.65
20453 Carburetor Nozzle		Carburetor Float Use No.	22804		Pinion Bearing Shim	
20456 Carburetor Inlet Screen 05 20637 Drive Pinion Adjusting Nut Lock 05 20458 Carburetor Throttle Shaft Gasket 05 20638 Drive Pinion Adjusting Nut Lock 05 20459 Carburetor Chrottle Shaft Gasket 05 20639 Drive Pinion Felt Washer Retainer. 105 20463 Throttle Lever Screw (Chort) 05 20641 Drive Pinion Felt Washer Retainer. 105 20464 Carburetor Choke Lever 30 20642 Drive Pinion Baft Key 08 20455 Carburetor Choke Shaft 20 20643 Drive Pinion Shaft Nut 25 20466 Carburetor Choke Shaft 20 20643 Drive Pinion Shaft Nut 20467 Carburetor Choke Lever Stop Screw 05 20644 External Brake Support (Left) 1.05 20468 Carburetor Choke Lever Stop Screw 05 20645 External Brake Support (Left) 20469 Carburetor Choke Lever Pin 05 20647 External Brake Support (Left) 20471 Carburetor Inlet Needle 20 20646 External Brake Proggle Lever (Left) 20472 Switch Resistance Unit 30 20649 External Brake Lever Link 20473 Inlet Seat 35 20650 External Brake Lever Pin 20474 Inlet Seat 35 20650 External Brake Lever Pin 20482 By Pass Adjusting Needle Sleeve 20 20653 External Brake Brake Dever Pin 20483 By Pass Adjusting Needle Spring 50 20653 External Brake Band 20494 Carburetor Float Lever Pinion Screw 20 20653 External Brake Band 20495 Pyass The Assembly 20 20653 External Brake Band 20496 Carburetor Float Lever Pinion Screw 20 20653 External Brake Lever (Left) 20491 Carburetor Float Lever Pinion Screw 20 20653 External Brake Lever (Left) 20492 Carburetor Float Lever Pinion Screw 20 20653 External Brake Lever (Left) 20493 Piston with Pin (.015" oversize) 20	20453	Carburetor Nozzle	.45		Drive Pinion and Shaft	7.50
20469 Carburetor Throttle Lever Screw (Long)		Carburetor Inlet Screen	.05	and the second second		
20462 Throttle Lever Screw (Long)		Carburetor Throttle Shaft		20 - 12 - 12 - 12		
20463		Throttle Lever Screw (Long)				
20464 Carburetor Choke Lever 30 20642 Drive Pinion Shaft Key .08 20466 Carburetor Choke Shutter 05 20643 Drive Pinion Shaft Nut .25 20466 Carburetor Choke Lever Stop Screw 05 20644 External Brake Support (Right) 1.05 20467 Carburetor Choke Lever Spring 20 20645 External Brake Toggle Lever (Right) 35 20471 Carburetor Inlet Needle Use No. 222205 20646 External Brake Toggle Lever (Left) 35 20472 Switch Resistance Unit 30 20649 External Brake Lever Link 35 20473 Inlet Seat 35 20650 External Brake Lever Link 36 20477 Needle Valve Adjusting Screw 40 20651 External Brake Lever Pin 13 20480 Rear Spring Center Bolt 06 20652 External Brake Band 40 20483 By Pass Adjusting Needle Sleeve 20 20653 External Brake Anchor 20 20484 By Pass Tube Assembly 75 20654 External Brake Band Lining 60 20484 By Pass Tube Assembly 75 20655 Internal Brake Congle Shaft (Left) 90 20490 Carburetor Float Lever 25 20656 Internal Brak		Throttle Lever Screw (Short)		March 2012	Drive Pinion Jam Nut	
20465 Carburetor Choke Shatt. 20 20466 Carburetor Choke Shutter 05 20467 Carburetor Choke Lever Stop Screw 05 20468 External Brake Support (Left) 1.05 20469 Carburetor Choke Lever Spring 20 20646 External Brake Support (Left) 1.05 20471 Carburetor Choke Lever Pin 05 20647 External Brake Coggle Lever (Left) 35 20472 Switch Resistance Unit 30 20649 External Brake Lever Link 35 20473 Inlet Seat 35 20650 External Brake Lever 60 20473 Inlet Seat 35 20650 External Brake Lever 60 20473 Inlet Seat 35 20650 External Brake Lever 60 20473 Inlet Seat 35 20650 External Brake Lever 13 20474 Internal Brake 20 20653 External Brake Camsion Rod Spring 13 20482 By Pass Adjusting Needle Spring 05 20654 External Brake Lever Rod		Carburetor Choke Lever			Drive Pinion Shaft Key	
20467 Carburetor Choke Lever Spring 20 20646 External Brake Toggle Lever (Right) 35 20469 Carburetor Choke Lever Pin 05 20647 External Brake Toggle Lever (Right) 35 20471 Carburetor Inlet Needle Use No. 22206 External Brake Toggle Lever (Left) 35 20473 Inlet Seat 30 20648 External Brake Lever Link 35 20473 Inlet Seat 35 20650 External Brake Lever Pin 13 20474 Needle Valve Adjusting Screw 40 20651 External Brake Lever Pin 13 20480 Rear Spring Center Bolt 06 20652 External Brake Band 40 20483 By Pass Adjusting Needle Sleeve 20 20653 External Brake Anchor 20 20484 By Pass Adjusting Needle Spring 05 20654 External Brake Toggle Shatt (Left) 90 20491 Carburetor Float Lever Pinion Screw 10 20655 Internal Brake Toggle Shatt (Right) 90 20492 Carburetor Float Lever Pinion Screw 10 20657 Internal Brake Lever (Right) 55 20493 Seat Cushion 850 20659 Internal Brake Lever (Right) 55 20493 Siston with Pin (.015° oversize) 2.45 206	A SHARE TO SHARE THE	Carburetor Choke Shaft	0.00			
20468 Carburetor Choke Lever Spring 20 20646 External Brake Toggle Lever (Right) 35 20471 Carburetor Choke Lever Pin 05 20647 External Brake Toggle Lever (Left) 35 20472 Switch Resistance Unit 30 20649 External Brake Lever Link 36 20473 Switch Resistance Unit 35 20659 External Brake Lever Link 36 20477 Needle Valve Adjusting Screw 40 20651 External Brake Lever Pin 18 20477 Needle Valve Adjusting Screw 40 20651 External Brake Lever Pin 18 20482 Bay Pass Adjusting Needle Sleeve 20 20652 External Brake Band 4 00 20482 By Pass Adjusting Needle Sleeve 20 20653 External Brake Band 4 00 20483 By Pass Adjusting Needle Spring 05 20654 External Brake Band Lining 60 20484 By Pass Tube Assembly 75 20655 Internal Brake Toggle Shaft (Left) 90 20490 Carburetor Float Lever Pinion Screw 10 20657 Internal Brake Toggle Shaft (Right) 90 20491 Carburetor Float Lever Pinion Screw 10 20657 Internal Brake Lever (Right) 90 20492 Carburetor Float Bowl Cover 20 20653 Internal Brake Lever (Right) 90 20494 Switch Key 12 20666 Internal Brake Lever (Right) 90 20494 Switch Key 12 20666 Internal Brake Lever (Right) 80 20494 Switch Key 12 20666 Internal Brake Lever (Right) 80 20494 Switch Key 12 20666 Internal Brake Lever (Right) 80 20494 Switch New 10 207 Oversize 2 45 20661 Internal Brake Band Lining 3 30 20534 Bow Socket (Right) 3 50 20665 Internal Brake Band Lining 3 30 20534 Bow Socket (Left) 3 50 20664 Differential Pinion 90 20561 Piston Ring (010° oversize) 20 20666 Differential Pinion 90 20561 Piston Ring (010° oversize) 20 20667 Differential Brake Band Lining 85 20558 Right Front Side Curtain 3 20 20670 Differential Brake Reside 3 7 20583 Front Seat Cushion 9 00 20677 Rear Axle Shaft Nut 10 20583 Front Seat Cushion 9		Carburetor Choke Shutter			External Brake Support (Right)	
20469 Carburetor Choke Lever Pin.		Carburetor Choke Lever Spring			External Brake Toggle Lever (Right).	
20472 Switch Resistance Unit. 30 20649 External Brake Lever. 60 20473 Inlet Seat. 35 20650 External Brake Lever Pin. 18 20477 Needle Valve Adjusting Screw 40 20651 External Brake Tension Rod Spring 04 20480 Rear Spring Center Bolt. 06 20652 External Brake Tension Rod Spring 04 20482 By Pass Adjusting Needle Sleeve 20 20653 External Brake Band 40 20483 By Pass Tube Assembly 75 20655 Internal Brake Toggle Shaft (Left) 90 20494 Carburetor Float Lever 25 20656 Internal Brake Toggle Shaft (Right) 90 20491 Carburetor Float Bowl Cover 20 20657 Internal Brake Lever (Left) 55 20492 Carburetor Float Bowl Cover 20 20657 Internal Brake Lever (Right) 20657 20493 Seat Cushion 8 50 20659 Internal Brake Lever (Right) 20657 20493 Switch Key 12 20669 In		Carburetor Choke Lever Pin	.05	20647	External Brake Toggle Lever (Left)	
20473 Inlet Seat	100000000000000000000000000000000000000	Carburetor Inlet Needle Use No.	22205		External Brake Lever Link	
20477 Needle Valve Adjusting Screw 40 20651 External Brake Tension Rod Spring 04 20480 Rear Spring Center Bolt 06 20652 External Brake Band 4.00 20483 By Pass Adjusting Needle Spring 05 20654 External Brake Band Lining 60 20484 By Pass Tube Assembly 75 20655 Internal Brake Anchor 20 20494 By Pass Tube Assembly 75 20655 Internal Brake Toggle Shaft (Left) 90 20491 Carburetor Float Lever Pinion Screw 10 20657 Internal Brake Lever (Left) 55 20492 Seat Cushion 8.50 20658 Internal Brake Lever (Right) Use No. 20657 20494 Switch Key 12 20660 Internal Brake Link 08 20498 20530 Piston with Pin (015" oversize) 2.45 20661 Internal Brake Band with Lining 3.0 20534 Bow Socket (Right) 3.50 20662 Internal Brake Band Lining 8.5 20534 Bow Socket (Left) 3.50 <	The second secon	Switch Resistance Unit		100000000000000000000000000000000000000		
20480 Rear Spring Center Bolt 06 20652 External Brake Band 4 00 20482 By Pass Adjusting Needle Sleeve 20 20653 External Brake Band Lining 60 20484 By Pass Tube Assembly 75 20655 External Brake Anchor 20 20490 Carburetor Float Lever 25 20656 Internal Brake Toggle Shaft (Left) 90 20491 Carburetor Float Lever Pinion Screw 10 20656 Internal Brake Lever (Left) 55 20492 Carburetor Float Bowl Cover 20 20658 Internal Brake Lever (Right) Use No. 20657 20493 Seat Cushion 8.50 20659 Internal Brake Lever (Right) Use No. 20657 20498 Piston with Pin (015" oversize) 2.45 20661 Internal Brake Connecting Link 0.5 20533 Piston with Pin (020" oversize) 2.45 20661 Internal Brake Band with Lining 3.00 20536 Piston Pin (010" oversize) 2.45 20661 Internal Brake Band with Lining 3.00 20537 <td></td> <td>Needle Valve Adjusting Scrow</td> <td></td> <td></td> <td></td> <td></td>		Needle Valve Adjusting Scrow				
20482 By Pass Adjusting Needle Sleeve 20 20653 External Brake Band Lining 60 20483 By Pass Adjusting Needle Spring 05 20654 External Brake Anchor 20 20484 By Pass Tube Assembly 75 20655 Internal Brake Toggle Shaft (Left) 90 20491 Carburetor Float Lever Pinion Screw 10 20656 Internal Brake Toggle Shaft (Right) 90 20492 Carburetor Float Lever Pinion Screw 10 20657 Internal Brake Lever (Left) 55 20493 Seat Cushion 8 50 20659 Internal Brake Lever (Right) Use No. 20657 20494 Switch Key 12 20660 Internal Brake Connecting Link 05 20498 Piston with Pin (.015" oversize) 2 45 20661 Internal Brake Release Spring 08 20533 Piston with Pin (.020" oversize) 2 45 20662 Internal Brake Band Lining 3 30 20536 Piston Pin (.010" oversize) 2 45 20662 Internal Brake Elease Spring 08 20536 Pi	The second secon		The second second	1, 7, 2, 2, 2, 2, 2, 2, 2, 2, 2, 2, 2, 2, 2,		A 100 CO
20484 By Pass Tube Assembly 75 20655 Internal Brake Toggle Shaft (Left) 90 20490 Carburetor Float Lever 25 20656 Internal Brake Toggle Shaft (Right) 90 20491 Carburetor Float Lever Pinion Screw 10 20657 Internal Brake Lever (Left) 55 20492 Carburetor Float Bowl Cover 20 20658 Internal Brake Lever (Right) Use No. 20657 20493 Seat Cushion 8 50 20659 Internal Brake Lever (Right) Use No. 20657 20494 Switch Key 12 20660 Internal Brake Connecting Link 05 20498 Piston with Pin (015" oversize) 2 45 20661 Internal Brake Release Spring 08 20533 Piston with Pin (020" oversize) 2 45 20662 Internal Brake Band with Lining 3 30 20534 Bow Socket (Right) 3 50 20661 Internal Brake Band Lining 8 50 20539 Piston Ring (100 oversize) 40 20664 Differential Case 5 50 20543 Bo		By Pass Adjusting Needle Sleeve		A STATE OF THE STA	External Brake Band Lining	
20490 Carburetor Float Lever 25 20656 Internal Brake Toggle Shaft (Right) 90 20491 Carburetor Float Lever Pinion Screw 10 20657 Internal Brake Lever (Left) 55 20492 Carburetor Float Bowl Cover 20 20658 Internal Brake Lever (Right) Use No. 20657 20493 Seat Cushion 8 50 20659 Internal Brake Link 03 20494 Switch Key 12 20660 Internal Brake Connecting Link 05 20498 Piston with Pin (.015" oversize) 2 45 20661 Internal Brake Release Spring 08 20533 Piston with Pin (.020" oversize) 2 45 20662 Internal Brake Band with Lining 3 30 20534 Bow Socket (Right) 3 50 20663 Internal Brake Band Lining 8 5 20536 Piston Pin (.010" oversize) 40 20664 Differential Case 50 20543 Bow Socket (Left) 3 50 20665 Differential Pinion 36 20558 Right Front Side Curtain 3 25	The second secon	By Pass Adjusting Needle Spring	.05			
20491 Carburetor Float Lever Pinion Screw 10 20657 Internal Brake Lever (Left) . 55 20492 Carburetor Float Bowl Cover 20 20658 Internal Brake Lever (Right) Use No. 20657 20493 Seat Cushion 8 50 20659 Internal Brake Link . . .03 20494 Switch Key 12 20660 Internal Brake Connecting Link . .05 20498 Piston with Pin (.015" oversize) 2 45 20661 Internal Brake Connecting Link . .05 20533 Piston with Pin (.020" oversize) 2 45 20662 Internal Brake Connecting Link .05 20534 Bow Socket (Right) 3 50 20662 Internal Brake Connecting Link .05 20535 Piston Ring (.010" oversize) 2 45 20662 Internal Brake Connecting Link .05 20543 Bow Socket (Right) 3 50 20663 Internal Brake Link .05 20546 Differential 20		By Pass Tube Assembly	.75		Internal Brake Toggle Shaft (Right)	
20492 Carburetor Float Bowl Cover. 20 20658 Internal Brake Lever (Right). Use No. 20657 20493 Seat Cushion 8 50 20659 Internal Brake Link. 05 20494 Switch Key. 12 20660 Internal Brake Connecting Link. 05 20498 Piston with Pin (.015" oversize) 2 45 20661 Internal Brake Release Spring. 08 20533 Piston with Pin (.020" oversize) 2 45 20662 Internal Brake Band with Lining. 3 30 20534 Bow Socket (Right) 3 50 20663 Internal Brake Band Lining. 8 50 20536 Piston Pin (.010" oversize) 40 20664 Differential Case. 5 50 20543 Bow Socket (Left) 3 50 20665 Differential Pinion Shaft 65 20558 Right Front Side Curtain 3 25 20666 Differential Pinion 90 20567 Piston Ring (.010" oversize) 20 20667 Differential Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Diff. Bearing Adjusting Ring Lock. 02 20579 Left Front Door 13 00 20674 Bevel Ring Gear 7 .25 20580 Right Front Door 13 00 20675 Rear Axle Shaft 3 .5 <td></td> <td>Carburetor Float Lever Pinion Screw</td> <td>10</td> <td>20657</td> <td>Internal Brake Lever (Left)</td> <td></td>		Carburetor Float Lever Pinion Screw	10	20657	Internal Brake Lever (Left)	
20493 Seat Cushion 8 50 20659 Internal Brake Link .03 20494 Switch Key 12 20660 Internal Brake Connecting Link .08 20498 Piston with Pin (.015" oversize) 2 45 20661 Internal Brake Release Spring .08 20533 Piston with Pin (.020" oversize) 2 45 20662 Internal Brake Band with Lining 3	20492	Carburetor Float Bowl Cover	.20		Internal Brake Lever (Right) Use No.	20657
20498 Piston with Pin (.015" oversize) 2.45 20661 Internal Brake Release Spring. .08 20533 Piston with Pin (.020" oversize) 2.45 20662 Internal Brake Band with Lining. 3.30 20534 Bow Socket (Right) 3.50 20663 Internal Brake Band Lining. 85 20536 Piston Pin (.010" oversize) 40 20664 Differential Case. 5.50 20543 Bow Socket (Left) 3.50 20665 Differential Pinion Shaft. 65 20558 Right Front Side Curtain. 3.25 20666 Differential Pinion. 90 20567 Piston Ring (.010" oversize) 20 20667 Differential Side Gear. 3.75 20567 Piston Ring (.020" oversize) 20 20667 Differential Bearing Adjusting Ring. 45 20579 Left Front Door. 13.00 20674 Bevel Ring Gear. 7.25 20580 Right Front Door. 13.00 20675 Rear Axle Shaft Thrust Washer. 65 20581 Left Rear Door. 13.00 20676		Seat Cushion	8.50		Internal Brake Link	1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2
20533 Piston with Pin (.020" oversize) 2 45 20662 Internal Brake Band with Lining 3 30 20534 Bow Socket (Right) 3 50 20663 Internal Brake Band Lining 35 20536 Piston Pin (.010" oversize) 40 20664 Differential Case 5 50 20543 Bow Socket (Left) 3 50 20665 Differential Pinion Shaft 65 20543 Biston Ring (.010" oversize) 20 20666 Differential Pinion 90 20543 Piston Ring (.010" oversize) 20 20667 Differential Pinion 90 205461 Piston Ring (.010" oversize) 20 20667 Differential Side Gear 3 .75 20567 Piston Ring (.020" oversize) 20 20670 Differential Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Bevel Ring Gear 7 .25 20580 Right Front Door 13 00 20674 Bevel Ring Gear 7 .25 20581 Left Rear Door 13 00 20675 Rear Axl		Switch Key				
20534 Bow Socket (Right) 3 50 20663 Internal Brake Band Lining 85 20536 Piston Pin (010" oversize) 40 20644 Differential Case 5 50 20543 Bow Socket (Left) 3 50 20665 Differential Pinion Shaft 65 20558 Right Front Side Curtain 3 25 20666 Differential Pinion 90 20561 Piston Ring (010" oversize) 20 20667 Differential Side Gear 3 .75 20567 Piston Ring (020" oversize) 20 20670 Differential Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Diff. Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Diff. Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Diff. Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Bevel Ring Gear 7 .25 20588 Right Front Door 13 00 <		Piston with Pin (020" oversize)	2.40			3.30
20536 Piston Pin (010" oversize) 40 20644 Differential Case. 5.90 20543 Bow Socket (Left) 3 50 20665 Differential Pinion Shaft 65 20558 Right Front Side Curtain 3 25 20666 Differential Pinion 90 20561 Piston Ring (010" oversize) 20 20667 Differential Side Gear 3.75 20567 Piston Ring (020" oversize) 20 20670 Differential Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Diff. Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Diff. Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Diff. Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Bevel Ring Gear 7 25 20583 Right Front Door 13 00 20675 Rear Axle Shaft 3 85 20584 Right Rear Door 13 00 20676 <td></td> <td>Bow Socket (Right)</td> <td>3.50</td> <td></td> <td></td> <td>. 85</td>		Bow Socket (Right)	3.50			. 85
20558 Right Front Side Curtain 3 25 20666 Differential Pinion 90 20561 Piston Ring (010" oversize) 20 20667 Differential Side Gear 3.75 20567 Piston Ring (020" oversize) 20 20670 Differential Bearing Adjusting Ring 45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Diff. Bearing Adjusting Ring Lock 02 20579 Left Front Door 13 00 20674 Bevel Ring Gear 7.25 20580 Right Front Door 13 00 20675 Rear Axle Shaft 3.85 20581 Left Rear Door 13 00 20676 Rear Axle Shaft Thrust Washer 65 20582 Right Rear Door 13 00 20677 Rear Axle Shaft Nut 10 20583 Front Seat Cushion 9 00 20678 Wheel Key 05 20584 Rear Seat Cushion 10 00 20681 Throttle Lever 90 20585 Left Front Side Curtain 3 25 20682 Spark Lever 90		Piston Pin (.010" oversize)	. 40	20664		
20561 Piston Ring (010" oversize) 20 20667 Differential Side Gear 3.75 20567 Piston Ring (020" oversize) 20 20670 Differential Bearing Adjusting Ring 45 20579 Pinion Housing and Diff. Carrier 10.50 20671 Diff. Bearing Adjusting Ring Lock 02 20579 Left Front Door 13.00 20674 Bevel Ring Gear 7.25 20580 Right Front Door 13.00 20675 Rear Axle Shaft 3.85 20581 Left Rear Door 13.00 20676 Rear Axle Shaft Thrust Washer 65 20582 Right Rear Door 13.00 20677 Rear Axle Shaft Nut 10 20583 Front Seat Cushion 9.00 20678 Wheel Key 05 20584 Rear Seat Cushion 10.00 20681 Throttle Lever 90 20585 Left Front Side Curtain 3.25 20682 Spark Lever 90 20586 Right Center Side Curtain 3.25 20685 Cylinder Head 7.00		Bow Socket (Left)	3.50	20665		
20567 Piston Ring (020" oversize) 20 20670 Differential Bearing Adjusting Ring .45 20572 Pinion Housing and Diff. Carrier 10 50 20671 Diff. Bearing Adjusting Ring Lock .02 20579 Left Front Door 13 00 20674 Bevel Ring Gear 7.25 20580 Right Front Door 13 00 20675 Rear Axle Shaft 3.85 20581 Left Rear Door 13 00 20676 Rear Axle Shaft Thrust Washer .65 20582 Right Rear Door 13 00 20677 Rear Axle Shaft Nut .10 20583 Front Seat Cushion 9 00 20678 Wheel Key .05 20584 Rear Seat Cushion 10 00 20681 Throttle Lever .90 20585 Left Front Side Curtain 3 25 20682 Spark Lever .90 20586 Right Center Side Curtain 3 25 20684 Cylinder Head Gasket .50 20587		Piston Ring (010" oversige)	3.20			
20572 Pinion Housing and Diff. Carrier 10.50 20671 Diff. Bearing Adjusting Ring Lock. .02 20579 Left Front Door 13.00 20674 Bevel Ring Gear 7.25 20580 Right Front Door 13.00 20675 Rear Axle Shaft 3.85 20581 Left Rear Door 13.00 20677 Rear Axle Shaft Thrust Washer .65 20582 Right Rear Door 13.00 20677 Rear Axle Shaft Nut .10 20583 Front Seat Cushion 9.00 20678 Wheel Key .05 20584 Rear Seat Cushion 10.00 20681 Throttle Lever .90 20585 Left Front Side Curtain 3.25 20682 Spark Lever .90 20586 Right Center Side Curtain 3.25 20684 Cylinder Head .70 20587 Left Rear Side Curtain 3.25 20686 Cylinder Head Gasket .50 20588 Right Front Side Curtain 3.25 20686 Cylinder Head Stud .15 20589		Piston Ring (.020" oversize)	.20		Differential Bearing Adjusting Ring	.45
20579 Left Front Door 13 00 20674 Bevel Ring Gear 7.25 20580 Right Front Door 13 00 20675 Rear Axle Shaft 3.85 20581 Left Rear Door 13 00 20676 Rear Axle Shaft Thrust Washer 65 20582 Right Rear Door 13 00 20677 Rear Axle Shaft Nut 10 20583 Front Seat Cushion 9 00 20678 Wheel Key 05 20584 Rear Seat Cushion 10 00 20681 Throttle Lever 90 20585 Left Front Side Curtain 3 25 20682 Spark Lever 90 20586 Right Center Side Curtain 3 25 20684 Cylinder Head 70 20587 Left Rear Side Curtain 3 25 20686 Cylinder Head Stud 15 20589 Left Center Side Curtain 3 25 20686 Cylinder Head Stud 15 20589 Right Rear Side Curtain 2 50 20688 Valve 40 20590 Right Rear Side Curtain <td< td=""><td>20572</td><td>Pinion Housing and Diff. Carrier</td><td>10.50</td><td>20671</td><td>Diff. Bearing Adjusting Ring Lock</td><td>.02</td></td<>	20572	Pinion Housing and Diff. Carrier	10.50	20671	Diff. Bearing Adjusting Ring Lock	.02
20581 Left Rear Door 13 00 20676 Rear Axle Shaft Thrust Washer .65 20582 Right Rear Door 13 00 20677 Rear Axle Shaft Nut .10 20583 Front Seat Cushion 9 00 20678 Wheel Key .05 20584 Rear Seat Cushion 10 00 20681 Throttle Lever .90 20585 Left Front Side Curtain 3 25 20682 Spark Lever .90 20586 Right Center Side Curtain 3 25 20684 Cylinder Head .7 00 20587 Left Rear Side Curtain 3 25 20685 Cylinder Head Gasket .50 20589 Left Center Side Curtain 3 25 20686 Cylinder Head Stud .15 20589 Left Center Side Curtain 3 25 20687 Valve .40 20590 Right Rear Side Curtain 2 50 20688 Valve Tappet with Adjusting Screw .90		Left Front Door	13.00	20674	Bevel Ring Gear	
20582 Right Rear Door. 13 00 20677 Rear Axle Shaft Nut. 10 20583 Front Seat Cushion. 9 00 20678 Wheel Key. 05 20584 Rear Seat Cushion. 10 00 20681 Throttle Lever. 90 20585 Left Front Side Curtain. 3 25 20682 Spark Lever. 90 20586 Right Center Side Curtain. 3 25 20684 Cylinder Head. 7 00 20587 Left Rear Side Curtain. 2 50 20685 Cylinder Head Gasket. 50 20588 Right Front Side Curtain. 3 25 20686 Cylinder Head Stud. 15 20589 Left Center Side Curtain. 3 25 20687 Valve. 40 20590 Right Rear Side Curtain. 2 50 20688 Valve Tappet with Adjusting Screw. 90					Rear Axle Shaft Thrust Washer	65
20583 Front Seat Cushion 9 00 20678 Wheel Key 05 20584 Rear Seat Cushion 10 00 20681 Throttle Lever 90 20585 Left Front Side Curtain 3 25 20682 Spark Lever 90 20586 Right Center Side Curtain 3 25 20685 Cylinder Head 7 00 20587 Left Rear Side Curtain 2 50 20685 Cylinder Head Gasket 50 20588 Right Front Side Curtain 3 25 20686 Cylinder Head Stud 15 20589 Left Center Side Curtain 3 25 20687 Valve 40 20590 Right Rear Side Curtain 2 50 20688 Valve Tappet with Adjusting Screw 90		Right Rear Door.	13 00			13 5 5 5 5
20584 Rear Seat Cushion 10 00 20681 Throttle Lever .90 20585 Left Front Side Curtain 3 25 20682 Spark Lever .90 20586 Right Center Side Curtain 3 25 20684 Cylinder Head .7 .00 20587 Left Rear Side Curtain 2 50 20685 Cylinder Head Gasket .50 20588 Right Front Side Curtain 3 25 20686 Cylinder Head Stud .15 20589 Left Center Side Curtain 3 25 20687 Valve .40 20590 Right Rear Side Curtain 2 50 20688 Valve Tappet with Adjusting Screw .90		Front Seat Cushion	9.00		Wheel Key	.05
20586 Right Center Side Curtain 3 25 20684 Cylinder Head 7 .00 20587 Left Rear Side Curtain 2 50 20685 Cylinder Head Gasket .50 20588 Right Front Side Curtain 3 25 20686 Cylinder Head Stud .15 20589 Left Center Side Curtain 3 25 20687 Valve .40 20590 Right Rear Side Curtain 2 .50 20688 Valve Tappet with Adjusting Screw .90		Rear Seat Cushion	10.00	20681		
20587 Left Rear Side Curtain 2 50 20685 Cylinder Head Gasket 50 20588 Right Front Side Curtain 3 25 20686 Cylinder Head Stud 15 20589 Left Center Side Curtain 3 25 20687 Valve 40 20590 Right Rear Side Curtain 2 50 20688 Valve Tappet with Adjusting Screw 90		Left Front Side Curtain	3.25		Spark Lever	
20588 Right Front Side Curtain 3 25 20686 Cylinder Head Stud .15 20589 Left Center Side Curtain 3 25 20687 Valve .40 20590 Right Rear Side Curtain 2 50 20688 Valve Tappet with Adjusting Screw .90		Left Rear Side Curtain	2.50		Cylinder Head Gasket	
20589 Left Center Side Curtain		Right Front Side Curtain	3.25		Cylinder Head Stud	.15
Total Treat Place Cultum		Left Center Side Curtain	3.25	20687	Valve	
	20590					.90

Part No.	Part Name	Price	Part No.	Part Name	Price
20689	Valve Tappet Adjusting Screw	\$0.20	20770	Water Pump Rotor Shaft	\$0.45
20690	Valve Tappet Guide	1.25	20771	Water Pump Shaft Coupling	.48
20691	Valve Tappet Guide Spring	.02	20772	Water Pump Shaft Coupling Clamp	.07
20692	Valve Tappet Guide Plug	.10	20775 20776	Water Pump Cover Coalest	. 68
20693	Valve Tappet Guide Screw		20777	Water Pump Cover Gasket	.02
20694	Valve Stem Guide	.35	20778	Water Outlet Pipe with Flange	1.30
20695	Valve Stem Key		20779	Water Outlet Gasket	.0
20696 20697	Valve Spring Cup		20780	Water Outlet Screw	.10
0698	Valve Spring Cup Valve Spring Seat		20781	Fan Bracket	
20699	Valve Chamber Cover		20783	Fan Drive Pulley	1.5
0700	Valve Chamber Cover Baffle		20785	Manifold Stud	.0
0701	Valve Chamber Cover Gasket	.08	20786	Manifold Gasket	.2
20702	Valve Chamber Cover Stud	.07	20787	Generator Drive Sprocket	1.6
0703	Cylinder Block	62.00	20788	Generator Sprocket Cover	
0704	Piston with Pin (Standard)	2.45	20789	Generator Sprocket Cover Gasket	.0
20705	Piston Pin (.005" oversize)		20790	Generator Gasket	.0
20706	Connecting Rod Clamp Screw Lock	.10	20792 20793	Starter Strap Clamp Plate	.5
20707	Piston Ring	.20	20794	Starter Strap Reinforcement	01)4
20708	Connecting Rod Complete		20795	Starting Motor Strap Stud	
	Note: Rod returned for New Bearing will be		20800	Windshield Upper Panel Complete	24 0
	accepted at full credit less a charge of \$2.60 list for new Bearing.		20802	Windshield Weatherstrip	2.3
20709	Connecting Rod Bolt	.12	20803	Windshield Weatherstrip (Top)	.7
20710	Connecting Rod Shim		20804	Windshield Weatherstrip (Side)	.3
20712	Connecting Rod Clamp Screw Lock	.01	20805	Windshield Finger Pull	.1
20713	Crankshaft		20806	Windshield Finger Pull Screw	.0
20714	Crankshaft Nut		20807	Windshield Adjusting Pivot	1.1
20715	Crankshaft Sprocket	1.80	20808	Adjusting Bracket Thumb Screw	8
20716	Crankshaft Front Bearing (Upper)	.70	20810	Windshield Glass (Upper)	7.5
20717	Crankshaft Center Bearing (Upper)	.65	20818	Rear Quarter Glass (Right)	7.5
20718	Crankshaft Rear Bearing (Upper)	1.00	20819	Back Glass	7.5
20719	Bearing Cap with Bearing (Front)	1.80	20822	Right and Left Front Door Moulding	.9
20720	Bearing Cap with Bearing (Center)	2.10	20827 20831	Quarter Window Moulding Door Pull to Handle	.9
20721	Bearing Cap with Bearing (Rear)	2.40	20832	Door Check Strap	1.2
	Note: Bearing Caps returned for rebabbit- ting will be accepted at full credit less a charge		20834	Door Lock	2286
The Party of the P	of \$1.00 list Front, \$ 95 list Center, and \$1.25 list		20835	Door Lock	1.9
ATT	Rear, for rebabbitting.		20836	Door Bumper RetainerUse No.	
20722	Crankshaft Bearing Shim	.06	20837	Door Bumper	.1
20723	Crankshaft Bearing Shim	.10	20862	Door Hinge Pin	.0
20724	Crankshaft Bearing Cap Stud	.25	20863	Door Lock Striker Plate	.1
20727	Filler Block Packing	.03	20864	Lifting Rod with Handle	1.7
20728	Filler Block Gasket	.01	20865	Lifting Rod with Handle	1.7
20729	Filler Block Stud	.07	20866	Lifting Rod Ratchet Plate	
20730 20731	Oil Thrower	.14	20867 20869	Lifting Rod Ratchet Plate	
20732	Camshaft		20870	Lifting Arm with RollerLifting Arm with Roller	$\frac{1.4}{1.4}$
20733	Camshaft Sprocket	2.60	20871	Lifting Arm with Roller	1.4
20735	Camshaft Thrust Plug	.80	20873	Door Weatherstrip	
20736	Oil Relief Valve Spring		20874	Door Weatherstrip Retainer Complete	.8
20739	Chain Case Stud	.07	20875	Rear Quarter Weatherstrip Retainer.	.8
20740	Chain Case Gasket	.08	20876	Lifting Ratchet Rubber	.3
20741	Chain Case Cover Complete	2.90	20877	Lifting Arm Support Rod Spring	.3
20742	Chain Case Cover Gasket	.15	20878	Lifting Arm Support Rod Nut	.0
20743	Timing Drive Chain		20879	Lifting Arm Support Rod Washer	.0
0744	Fly Wheel with Steel Ring Gear		20884	Rear Floor Carpet	5.7
0745	Fly Wheel Bolt		20885	Dome Lamp Glass with Rim	1.8
20747	Oil Pan	3.90	20886	Dome Lamp Reflector	1.6
0748	Oil Pan Gasket		20887	Dome Lamp Switch Lever	F-176
0753	Oil Pump Body		20888	Dome Lamp Connector Plug	0.6
0754	Oil Pump Drive Gear	1.45	20889 20890	Robe Cord	2.4
0755 0756	Oil Pump Drive ShaftOil Pump Driven Gear	1.50	20909	Glass Run Channel (Felt)	2.
0757	Oil Pump Idler Gear Stud	The second second	20919	Left Rear Quarter Glass	
0758	Oil Pump Cover Plate		20933	Dome Lamp Reflector Complete	1.6
20759	Oil Pump Cover Gasket	.01	20934	Deck Lid Hinge	1.6
20760	Oil Pump Gasket	.01	20935	Deck Lid Lock Key	
20761	Oil Pump Suction PipeUse No.		20936	Deck Lid Lock	
20764	Oil Indicator Tube		20937	Deck Lid Lock Striker Plate	1 .2
20765	Oil Indicator Float	.25	20938	Deck Lid Prop Guide	
20766	Water Pump Body		20949	Door Check Strap Loop	. 1
20767	Special Stud	.05	20952	Radiator Filler Cap	.4
20768	Water Pump Body Bushing	.20	20953	Radiator Filler Cap Gasket Tie Rod Adjustable Yoke	.0
20769	mater a mine body basemagnition		20954		1.7

18 (3) (23) 3

Part Part No. Price Part Name Price Part Name
 Back Curtain
 \$5.00

 Back Curtain
 5.00
 21129 20955 21130 20956 Hood Handle...
Hood Handle Rivet.
Timing Chain Rocker Pin.
Timing Chain Seat Pin.
Timing Chain Washer.
Timing Chain Hunting Link. 21131 20957 .04 20959 .01 21132 21133 20960 .03 21134 20961 .03 20962 .01 21135 21136 20963 Timing Chain Hunting Link.
Hub Cap Wrench.
Bearing Oil Retainer Spring...
Rear Spring...
First Top Bow.
Second Top Bow.
Third Top Bow.
Brake Release Spring (Left)...
Brake Release Spring (Right).
Rear Spring Center Bolt.
Valve Tappet Adjusting Screw Nut...
Camshaft Thrust Plug Lock...
Rear Motor Support. .65 21137 20964 .40 20965 . 13 21138 2.25 5.25 21140 20966 2.10 20967 1.00 21141

 Tie Rod
 2.35

 Steering Connecting Rod
 Use No.

 22562

 Universal Joint Flange (Axle End)
 3.75

 Universal Joint Inside Casing
 .70

 Service Brake Strap (Right)
 1.05

 Service Brake Strap (Left)
 1.05

 Rear Wheel Hub
 3.00

 20968 1.00 21142 21143 20969 1.00 20971 21144 .16 21145 .16 20972 21146 21003 .07 21147 21004 .06 Rear Wheel Hub. 3.00
Steering Connecting Rod. Use No. 22924
Rear Axle Shaft Outer Bearing. 4.95 .07 21148 21005 Rear Motor Support.
Choke Rod.
Choke Rod Button.
Steering Gear Housing (R. D.)
Worm Adjusting Nut Lock (R. D.)
Housing Cover (R. D.)
Steering Connecting Rod (R. D.)
Special Hex. Nut.
External Brake Band.
External Brake Tension Rod.
Tension Rod Adjusting Nut.
Accelerator Rod Button. Rear Motor Support..... 6.00 21149 21006 .10 21150 21012 4.75 21151 Differential Bearing Complete.... 21013 12 Pinion Bearing Front Complete.....
Pinion Bearing Rear Complete..... 4.25 21152 21020 5.00 4.95 21021 .12 21153 Pinion Bearing Rear Complete
External Brake Band Lining
Drive Pinion and Shaft.
Ball Bearing No. 1208.
Ball Bearing No. 1405.
Differential Case.
Magneto Chain Guard Base.
Magneto Chain Guard Cover.
Magneto Bell Crank Stud.
Magneto Bell Crank
Spark Control Rod.
Hot Air Stove. 90 21022 .30 21154 7.25 21024 1.65 21156 5.40 21028 21158 .04 6.00 21029 4.00 21159 21161 4.85 21030 .16 .90 21031 .20 21163 1.15 21164 Accelerator Rod Button.... .08 21032 .19 21165 21037 .60 21038 21166 Carburetor Inlet Screen

Carburetor Inlet Connection

Carburetor Inlet Connection Screw...

Carburetor Inlet Connection Gasket

Lamp Connector Plug and Cap...

Steering Worm Thrust Screw Lock Nut

Steering Worm Thrust Screw. 2.15 .11 21167 21039 Spark Control Rod...
Hot Air Stove...
External Brake Band...
Internal Brake Band...
Horn Button...
Differential Side Gear...
Differential Pinion Shaft...
Differential Pinion Spacer... 1.50 21169 21040 .40 3.35 .10 21172 21041 21173 21177 3.35 .05 21042 .50 21043 .25 3.60 21044 .07 21178 21179 .65 .10 21045 Steering Worm Thrust Screw.
Spark and Throttle Control Support.
Rear Door Upholstery (Left).
Rear Door Hinge (Lower).
Instrument Box.
Steering Gear Worm (R. D.).
Rear Fender (Right).
Rear Fender (Left).
Radiator Outlet Pipe (R. D.)
Front Wheel Outer Bearing.
Fly Wheel Under Pan.
Pinion Bearing Shim. .90 21180 21046 .25 Magneto Bracket..... 7.50 .80 21181 21047
 Drive Oiler
 .04

 Rear Wheel Complete
 10.00

 Rear Fender Tail Spacer
 16
 .80 21182 21048 .35 21183 21053 1.30 21184 21054 21185 21055 1.50 21064 10.00 21186 21187 21065 10.00 2.00 21188 21068 21073 .80 21189 21079 Fly Wheel Under Pan.
Pinion Bearing Shim.
Tail Lamp Bracket.
Side Apron (Left)...
Side Apron (Right).
Magneto Driven Sprocket.
Magneto Drive Sprocket...
Magneto Drive Chain.
Lighting and Ignition Switch...
Side Apron Clip Bevel Ring Gear.

Windshield Adjusting Pivot Bracket.

Right Front Door Glass Channel.

Left Front Door Glass Channel.

Left Rear Door Glass Channel.

Left Rear Door Glass Channel. SET .07 21190 21080 1.50 21191 21084 . 50 .95 21192 3.50 21085 21193 .95 21086 3.50 .95 21194 21099 4.25 5.00 21195 .95 21100 Rear Fender Iron (Right)
Rear Fender Iron (Left)
Acorn Head Cap Screw
Hand Brake Lever Latch Rod (R.D.)
Tire Carrier Bracket Nut .75 21202 21101 3.15 21103 21203 4.50 .12 Gasoline Tank Support (Right).
Brake Shaft Bushing.
External Brake Band Pin. .05 21205 21107 .30 21210 21108 .65 .05 21109 .20 21212 Tire Carrier Bracket Nut.
Rear Seat Upholstery.
Seat Upholstery.
Door Dovetail (Male).
Door Dovetail (Female).
Steering Gear Main Shaft Nut.
Lighting and Ignition Switch
Deck Lid Weatherstrip.
Steering Gear Thrust Bearing.
Readiator Brace. 7.50 .05 21214 21110 5.75 .10 21215 Drive Pinion Shaft Nut..... 21111 .30 Brake Shaft Bushing..... 21216 21112 Prinion Bearing Spacer.
Internal Brake Cam (Right).
Internal Brake Cam (Left).
Outer Bearing Adjusting Nut.
Outer Bearing Adjusting Nut Lock.
Pinion Housing Shim...
Rear Axle Felt Washer Retainer. .50 .80 21217 21113 .30 21218 21114 2.50 .75 21219 21115 3.10 21221 21116 1.10 .75 21223 .05 21117 .60 .07 21224 Radiator Brace..... 21118 21225 .50 21119 .10 21226 External Brake Release Spring..... .07 .10 21121 .20 Internal Brake Band Spring..... 21122 .07 21228 21229 3.60 21128 Rear Axle Shaft.....

Prices subject to change without notice

Part No.	Part Name	Price	Part No.	Part Name	Price
21230	Radiator Hood Rod Clip	\$0.10	21348	Front Fender (Right)	\$9.25
21231	Internal Brake Anchor	.19	21349	Side Apron (Left)	3.50
21232	Internal Brake Anchor Bracket	. 10	21350	Side Apron (Right)	3.50
21233	External Brake Eye Bolt	. 19	21351 21352	Running Board (Left)	$4.75 \\ 4.75$
21234 21235	External Brake Toggle Lever (Right).	.45	21353	Rear Fender (Left)	6.25
21236	External Brake Toggle Lever (Left) Front Spring Shackle	.20	21354	Rear Fender (Right)	
21237	Intake and Exhaust Manifold	9.50	21355	Headlamp Complete	4.50
21238	External Brake Band Clip	.04	21356	Headlamp Bracket (Right)	.95
21239	Internal Brake Band Clip	.04	21357	Headlamp Bracket (Left)	.95
21240	Door Dove Tail Spring	.25	21358 21360	Headlamp Tie Rod Tire Carrier Tie Bar	.40 .75
21246	Hub Cap	.25	21361	Radiator Splash Apron	
21247	Service Brake Pull Rod (R. D.)	.35	21362	Front Floor Mat (R. D.)	
21248 21249	Service Brake Pull Rod Yoke (R. D.). Steering Connecting Rod Plug	.40	21363	Top Dust Cover (R. D.)	4.25
21250	Connecting Rod Spring and Ball Seat.	.05	21365	Windshield Upper Panel Complete	
21251	Steering Connecting Rod Spring	.10	21366	Windshield Lower Panel Complete	
21254	Horn Bracket	.25	21367 21368	Windshield Side Arm (Left)	$\frac{2.05}{2.05}$
21255	Connecting Rod Clamp Screw	.13	21369	Windshield Top Stud	.17
21258	Rear Curtain Light Rubber	.15	21370	Windshield Lower Glass	4.50
21259	Pinion Housing with Bearing	11.75	21371	Rear Wheel Grease Felt Flange	. 50
21267	Front Spring Bumper Retainer	.07	21373	Steering Gear Housing	4.00
21268 21275	Front Spring Bumper	.08	21374	Steering Gear Housing Bolt	.15
21276	Internal and External Brake Bracket		21375 21378	Control Sector Bracket	. 95
21278	Top Complete, less Curtains		21379	Throttle Control Lever	.90
21279	Top Complete, less Curtains	30.00	21380	Spark Control Lever	
21282	Radiator Complete	37.50	21383	Throttle Lever (Lower)	. 55
21283	Radiator Shell		21384	Spark Lever (Lower)	. 55
21285	Hood Complete		21385	Instrument Board Bracket (Lower)	. 85
21287 21288	Windshield Complete Drive Pin	.07	21386	Instrument Board Bracket (Upper)	.60
21289	Radiator Name Plate Use No	22630	21387 21388	Instrument Board Bracket Cap Spark Control Bell Crank	.18
21290	Demountable Straight Side Rim	2.50	21389	Spark Control Rod	.40
21291	Front Wheel Hub	4.00	21391	Yoke, 3/6" S.A.E	.25
21292	Front Wheel Hub Flange	.75	21392	Throttle Rod (Short)	.06
21294	Rear Wheel Hub	3.50	21393	Throttle Bell Crank	.40
21295	Front Fender (Left)		21394	Throttle Bell Crank Nut	.20
21296 21298	Rear Wheel Brake Drum Front Wheel Complete	$\frac{3.00}{14.00}$	21395 21396	Throttle Rod (Long)	.10
21299	Rear Wheel Complete	10.00	21397	Throttle Operating Lever (R. D.) Spark Control Rod Complete	.40
21300	Rear Wheel Complete		21400	Rear Fender Tail Spacer	.16
21302	Rear Wheel Complete (Disc)		21401	Rear Fender (Left)	6.75
21303	Radiator Complete		21402	Rear Fender (Right)	6.75
21304	Radiator Shell		21405	Rear Fender (Left)	10.50
21305 21314	Frame Complete Use No. Frame Front Cross Member	1.75	21406 21407	Rear Fender (Right) Rear Fender (Left)	10.00
21315	Frame Front Cross Member		21408	Rear Fender (Right)	10.00
21316	Front Motor Support (Right)	1.30	21409	Rear Fender (Left)	11.00
21317	Front Motor Support (Left)	1.90	21410	Rear Fender (Right)	11.00
21318	Front Motor Support (Right) (R. D.).	1.90	21411	Hood Catch Complete	.30
21319	Front Motor Support (Left) (R. D.)	1.80	21413	Door with Glass (Left Front)Upon	
21320 21321	Transmission Support Starting Crank Bracket	$1.45 \\ 1.00$	91414	Door with Glass (Right Front)	ication
21321	Brake Idler Shaft Bracket	.40	21414	Upon Appl	ication
21323	Radiator Outlet Pipe	.55	21415	Door with Glass (Left Rear) Upon Appl	ication
21325	Tail Lamp Bracket	.75	21416	Door with Glass (Right Rear)	16110
21326	Radiator Brace	.30	46.3	Upon Appl	
21327	Motor Underpan (Left)	.80	21417	Generator Screw	.10
21328	Motor Underpan (Right)		21420	Switch Resistance Unit.	.20
21329 21330	Motor Underpan (Left) (R. D.) Motor Underpan (Right) (R. D.)	.75	21421 21422	Lighting and Ignition Switch Key Top Deck	8.00
21331	Gear Shift Lever (R. D.)	1.80	21423	Top Deck	5.75
21332	Speedometer Gear Housing	2.00	21424	Right Front Side Curtain	3.25
21333	Speedometer Drive Gear	3.00	21425	Left Center Side Curtain	3.25
21335	Speedometer Drive Pinion	2.10	21426	Right Rear Side Curtain	2.50
21340	Brake Idler Shaft	.20	21427	Left Front Side Curtain	3.25
21341	Brake Idler Lever (Left)	.50	21428 21429	Right Center Side Curtain Left Rear Side Curtain	3.25
				Dero Mear Blue Curtain	2.50
21342	Brake Idler Lever (Right)		21/20	Back Clirtain Complete	10
21343	Spark Control Rod (R. D.)	.15	21430 21431	Back Curtain Complete Left Rear Side Curtain	$6.00 \\ 2.50$
21343 21344 21345	Spark Control Rod (R. D.)	.15 .11 .12		Left Rear Side Curtain	2.50 2.50
21343 21344 21345	Spark Control Rod (R. D.) Spark Control Rod	.15 .11 .12	21431	Left Rear Side Curtain	2.50

Part No.	Part Name	Price	Part No.	Part Name	Price
21435	Back Curtain		21526	Door Lock Key	\$0.30
21436	"Lift the Dot" Socket and Clinch Plate	.04	21527	Door Locking Device Inside Lever	.45
21437	"Lift the Dot" Stud Single Rivet Base.	.03	21528 21531	Door Inside Lever Screw	2.25
21438 21439	Pronged RingSteering Gear Mast Jacket	$\frac{.04}{1.80}$	21532	Door Check Strap	1.15
21441	Hood Sill (Left)	1.30	21533	Door Lock	2.00
21442	Hood Sill (Right)	1.30	21534	Door Window Regulator (Right)	7.00
21443	Instrument Board	3.00	21535	Door Window Regulator (Left)	7.00
21444	Instrument Box	1.30	21536	Door Window Regulator Handle Regulator Handle Escutcheon	$\frac{1.15}{.25}$
21445 21446	Door Hinge	$\frac{.75}{1.15}$	21537 21547	Rear Spring Spacer	.80
21447	Carburetor Choke Rod Guide Plate	.02	21548	Steering Gear Housing Bolt	.25
21448	Right Front Door		21549	Throttle Operating Cam (R. D.)	. 55
21449	Left Front Door	10.00	21550	Right Front Door Hinge (Upper)	.95
21450	Right Rear Door		21551	Left Front Door Hinge (Upper)	.95
21451 21452	Left Rear Door	$10.00 \\ .90$	21552 21553	Right Front Door Hinge (Center) Left Front Door Hinge (Center)	.95
21452	Windshield Bracket (Left)	1.15	21554	Right Front Door Hinge (Lower)	.95
21454	Windshield Bracket (Right)	1.15	21555	Left Front Door Hinge (Lower)	.95
21455	Front Seat Cushion	9.00	21556	Right Rear Door Hinge (Upper)	.95
21456	Seat Cushion	9.00	21557	Left Rear Door Hinge (Upper)	.95
21457	Front Door Upholstery (Left)	.90	21558 21559	Right Rear Door Hinge (Center) Left Rear Door Hinge (Center)	.95
21458 21459	Front Door Upholstery (Right) Rear Door Upholstery (Left)	.90 .60	21560	Right Rear Door Hinge (Lower)	.95
21460	Rear Door Upholstery (Right)	.60	21561	Left Rear Door Hinge (Lower)	.95
21461	Rear Door Upholstery (Left)	1.00	21562	Instrument Board Bracket (Upper)	. 55
21462	Rear Door Upholstery (Right)	1.00	21571	Rear Wheel Hub	3.50
21463	Front Seat Upholstery	7.75	21572 21573	Rear Wheel Hub	$\frac{3.50}{3.00}$
21464 21465	Rear Seat Upholstery	$8.25 \\ 7.75$	21575	Universal Joint Flange Bolt	.11
21468	Body Hood Ledge Moulding (Right).	.40	21576	Universal Joint Ball Yoke	2.20
21469	Body Hood Ledge Moulding (Left)	.40	21577	Universal Joint Cross	1.20
21470	Rubber Grommet	.04	21578	Universal Joint Flange Yoke	1.95
21471	Emergency Brake Rod (Rear)	.60	21579	Universal Joint Spacer	2.20
21472	Service Brake Rod (Rear)	. 55	21580 21581	Universal Joint Outside Casing Oil Filler Screen	.45
21473 21474	Brake Rod (Front)	$\begin{array}{c} .45 \\ 8.50 \end{array}$	21582	Front Universal Joint	17.40
21475	Back Window Curtain	9.00	21584	Instrument Board Lamp Shield	.25
21476	Back Window Curtain	9.00	21585	Mast Jacket Bushing (Upper)	.35
21477	Special Step Bolt	.15	21588	Dome Lamp Glass	$\frac{.80}{1.30}$
21478 21479	Univ. Joint Flange Yoke (Trans. End)	$\frac{2.60}{.07}$	21589 21590	Dome Lamp Rim	5.50
21481	Valve Tappet Guide Screw Lock Radiator Splash Apron	1.85	21591	Rear Spring	5.50
21482	Oil Filler Tube	.30	21592	Front Spring	3,00
21483	Oil Filler Cover	.30	21593	Front Spring Shackle	.20
21484	Throttle Valve Lever	.60	21594	Spring Bolt	.40
21487	Brake Shaft Bracket	2.10	21595 21596	Spring Bolt Nut	.05
21488 21491	Hood Catch Bracket Rubber Control Tube Complete	$04 \\ 1.15$	21597	Rear Spring Shackle	.90
21491	Instrument Board Bracket	3.00	21598	Front Spring Axle Clip	.25
21493	Control Tube Complete	1.20	21599	Front Spring Clip Plate	.14
21494	Head Lamp Door	1.10	21600	Front Spring Bumper	.08
21495	Front Wheel Complete		21601 21602	Frame Complete	5.75
21496	Rear Wheel Complete		21603	Front Axle "I" Beam	13.25
21497 21498	Rear Wheel Complete Demountable Straight Side Rim		21604	Rear Spring Bracket	.80
21498	Front Wheel Hub		21605	Front Spring Bracket	.80
21500	Front Wheel Hub Flange	.75	21606	Front Spring Horn (Right) Front Spring Horn (Left)	.95 .95
21501	Head Lamp ReflectorUse No.	22631	21607 21608	Rear Spring Horn (Right)	.95
21502	Head Lamp Lens	. 50	21609	Rear Spring Horn (Left)	.95
21503	Throttle Rod (Upper)	.05	21611	Frame Complete	38.00
21504	Throttle Rod (Lower)	.05 $.05$	21612	Frame Side Member (Right)	
21505 21507	Spark Control Rod (R.D.)	.05	21613	Frame Side Member (Left)	$\frac{11.00}{.40}$
21508	Hood Complete	8.50	21614 21617	Piston Pin (.015" oversize)	.12
21513	Back Panel Guard Spacer	. 13	21630	Valve Tappet Adjusting Screw	.20
21516	External Brake Cam (Right)	.75	21657	Demountable Rim Clamp and Lock	.20
21517	External Brake Cam (Left)	.75	21658	Front Spring Center Bolt	.12
21518	External Brake Lever Tire Carrier Brace	$\frac{.70}{2.75}$	21659	Exhaust Pipe Lock Screw	.06 5.00
21519 21520	Expansion Plug		21661 21663	Steering Gear Housing (R.D.) Door Window Regulator Handle Screw	
21521	Expansion Plug		21664	Steering Knuckle (Right)	7.25
21524	Door Glass	6.75	21665	Steering Knuckle (Left)	7.25
21525	Outside Door Handle with Key	5.00	21666	Steering Arm (Right)	3.85

Part	nelv. I.	hafi	Part	D-13	215
No.	Part Name	Price	No.	Part Name	Price
21667 21668	Steering Arm (Left)	\$3.85 .03	21780 21781	Rear Wheel Complete	15.00
21669	Steering Knuckle King Pin	1.50	21782	Front Wheel Complete	14.00
21670	King Pin Plunger Brake Rod	.06	21783	Rear Wheel Hub	3.50
21671	Special Expansion Plug	.04	21784	Rear Wheel Brake Drum	3.00
21672 21673	Brake Shoe (Inner) with Lining Brake Shoe (Outer) with Lining	$\frac{1.50}{1.50}$	21785 21788	Instrument Board	3.00
21674	Front Brake Fork Lever (Right)	1.05	21789	Door Lock Lever Handle Escutcheon	.16
21675	Front Brake Fork Lever (Left)	1.05	21790	Door Lock (Right)	2.25
21676	Bell Crank Lever (Inner)	1.05	21791	Door Lock (Left)	2.25
21677 21678	Bell Crank Lever Bushing Bell Crank Stud	.10 .16	21792 21793	Outside Door Handle	$\frac{1.30}{1.25}$
21679	Bell Crank Pull Rod	.60	21794	Door Lock Dowel with Set Screw	.50
21680	Bell Crank Lever (Outer)	.40	21795	Door Check Strap	.50
21681	Bell Crank Bracket	. 85	21796 21797	Door Check Strap Loop	.07
21682 21683	Bell Crank (Right)Bell Crank (Left)	.55	21798	Door Bumper	.16 .65
21684	Bell Crank Stud	.25	21799	Left Door Hinge (Upper)	.65
21685	Cross Shaft End Bracket	.40	21800	Right Door Hinge (Center)	. 65
21687	Cross Shaft Cam	.95	21801	Left Door Hinge (Center)	.65
21690 21691	Cross Shaft Center Bearing Cross Shaft Lever (Outer)	$\frac{.95}{1.20}$	21802 21803	Right Door Hinge (Lower) Left Door Hinge (Lower)	.65
21692	Cross Shaft Compression Spring		21804	Door Lock Striker Plate (Outer)	.16
21693	Brake Idler Lever Stud (Rear)	.20	21806	Door Dovetail (Female)	.45
21694 21695	Front Brake Idler Lever Bolt	.20 .75	21807 21808	Windshield Glass	
21696	Brake Idler Lever (Front) Front Brake Bell Crank Rod	.45	21809	Door and Rear Quarter Glass	2.50 9.00
21697	Front Brake Pedal Rod	.45	21810	Glass Channel Lower Felt	.16
21699	Front Brake Rod (Front)	.40	21811	Glass Run Channel	
21700 21701	Front Brake Rod (Rear)	.50 2.15	21818 21823	Door Window Regulator Handle Cowl Ventilator Spring	$\substack{1.70\\.16}$
21703	Hand Brake Lever Ratchet	.25	21824	Top Ventilator Lid and Hinge	.90
21704	Front Wheel Complete		21825	Top Ventilator Lid Handle	.15
21705	Front Wheel Complete	10.00	21827	Door Lock Lever Handle (Inside)	40
21706 21707	Front Brake Drum Front Wheel Complete	3.00	21828 21829	Right Door Complete Upon Appl Left Door Complete Upon Appl	ication
21708	Front Wheel Brake Drum		21831	Windshield Wing Bracket (Left)	8.00
21709	Frame Complete	38.00	21832	Windshield Wing Bracket (Right)	8.00
21710	Frame Complete (R. D.)		21839 21840	Piston Ring, Plain (Standard)	.20
21713 21715	Front Brake Drum Housing Friction Plunger Spring		21841	Piston Ring, Plain (.010" oversize) Piston Ring, Plain (.020" oversize)	.20 .20
21716	Friction Plunger		21842	Piston Ring, Grooved (Standard)	.25
21717	Left Front Door Complete	15.00	21843	Piston Ring, Grooved (.010" oversize).	.25
21718	Right Front Door Complete		21844 21850	Piston Ring, Grooved (.020" oversize).	.25
21719 21720	Left Rear Door Complete		21851	Windshield Pivot Cup Oil Pressure Gauge Elbow	$.12 \\ .12$
21722	Rear Brake Band Stop	.07	21852	Door Glass Channel	1.25
21727	Rear Brake Fork Bracket	.90	21856	Rear Bearing Filler Block Use No.	
21728 21729	Rear Brake Fork (Right)	$\frac{3.00}{3.00}$	21857 21859	Hood Catch Bracket	$\begin{array}{c} .11 \\ .03 \end{array}$
21730	Rear Brake Support (Right)		21860	Brake Shaft Lever	1.00
21731	Rear Brake Support (Left)	2.60	21869	Front Wheel Hub	4.00
21732	Rear Brake Fork Lever	4.0	21870	Mast Jacket Bushing (Lower)	
21734 21735	Windshield Weatherstrip	.65	21871 21872	Door Glass Channel (Left) Door Glass Channel (Right)	
21736	Spring Bushing		21881	Windshield Moulding (Lower)	1.15
21737	Spring Bolt with Nut		21882	Chain Case	5.15
21738 21739	Rear Spring Bolt with Nut		21883 21884	Oil Filler BodyOil Filler Body Cover	.60
21740	Rear Fender (Right)		21885	Oil Filler Body Cover Hinge Pin	. 13
21741	Rear Fender (Left)	10.00	21886	Oil Filler Body Screw	.07
21743	Front Floor Mat	2.15	21887	Pinion Housing Splash Guard	.20
21744 21745	Step Hanger Rear (Right) Step Hanger Rear (Left)	.75 .75	21888 21889	Pinion Housing Splash Guard Washer. Steering Gear Housing Bushing (Outer)	$\begin{array}{c} .25 \\ .13 \end{array}$
21746	Internal Brake Lever	.65	21890	Steering Gear Housing Bushing (Inner)	.16
21747	Spiral Gear and Shaft	1.90	21893	Windshield Glass	11.00
21753	Spiral Gear, Shaft and Yoke		21902	Piston Pin (.003" oversize)	.45
21759 21770	Radiator Complete Tire Carrier Tie Bar		21903 21904	Piston Pin (.005" oversize) Rear Axle Tube Oil Retainer	
21771	Front Wheel Hub Bolt	.15	21905	Hood Body Bracket	.12
21776	Steering Gear Worm (R. D.)	1.50	21907	Piston Ring (Plain) (Standard)	.20
21777 21778	Steering Gear Worm Wheel (R. D.) Steering Gear Worm		21908 21909	Piston Ring (Plain) (.010" oversize) Piston Ring (Plain) (.020" oversize)	.20
21779	Steering Gear Worm Wheel		21910	Piston Ring (Plain) (.020" oversize)	.20
- A85 - A	and the same of the same that a graphy of	8361	3127.6	The second secon	Towns of the

Part No.	Part Name	Price	Part No.	Part Name	Price
21911	Piston Ring (Grooved) (Standard)	\$0.25	21985		\$0.25
21912	Piston Ring (Grooved) (.010" oversize)	.25	21986	Intake and Exhaust Manifold	
21913	Piston Ring (Grooved) (.020" oversize)	.25	21989 21990	Water Pump Rotor Shaft	
21914	Piston Ring (Grooved) (.030" oversize)	.25	21991	Piston Pin Retaining Ring	
21915	Piston Pin (.020" oversize)	.40	21992	Exhaust Pipe Packing Gasket	
21917	Throttle Bell Crank	.30	21993	Steering Knuckle Thrust Washer	
21918	Throttle Bell Crank Nut	.13	21994	Steering Knuckle Thrust Washer	
21919	Throttle Return Spring	.09	21995	Drive Pinion and Shaft	
21920 21921		.11	21997		.40
21921	Bell Crank Trunnion Complete Spark Control Rod	. 50	21998	Radiator Hood Rod Bracket Front Brake Shaft Lever	1.20
21922	Spark Control Rod Complete	.07	21999 22000	Front Axle "I" Beam	
21923	Magneto Bell Crank	.30	22001	Front Brake Fork Lever (Left)	1.30
21925	Magneto Bell Crank Link	.25	22002	Front Brake Fork Lever (Right)	1.30
21926	Accelerator Rod	.14	22003	Front Brake Shaft Bracket	. 55
21927	Steering Knuckle (Left) Use No.	22035	22004	Front Brake Fork	4.00
21928	Steering Knuckle (Right) Use No.	22035	22005	Front Brake Shaft (Left)	
21929	Steering Arm (Left)	2.65	22006	Front Brake Shaft (Right)	1.10
21930	Steering Arm (Right)		22007	Brake Fork Adjuster	1.20
21931 21932	Brake Idler Shaft Bracket. Pedal Shaft	. 65	22008 22009	Brake Shoe Lining	
21933	Clutch Shaft Bracket Support	6.00	22010	Brake Shoe Complete (Internal)	
21934	Idler Lever Stop	.20	22011	Brake Shoe Spring	.07
21935	Exhaust Pipe Flange	.13	22012	Differential Bearing Oil Sling	.04
21936	Exhaust Pipe Sleeve	.30	22013	Pinion Roller Bearing (Inner)	
21937	Throttle Lever	. 55	22014	Pinion Housing	2.40
21939	Mast Jacket Bracket (Upper)	.45	22015	Pinion Roller Bearing (Outer)	4.70
21940	Mast Jacket Bracket Cap (Upper)	.20	22016	Drive Pinion Felt Retainer Drive Pinion Adjusting Nut	.07
21941 21942	Tire Carrier Bracket (Left) Tire Carrier Bracket (Right)	1.60	22017 22018	Drive Pinion Adjusting Nut Drive Pinion Adj. Nut Lock Washer	.07
21942	Tire Carrier Bracket (Left)	$1.60 \\ 1.25$	22019	Drive Pinion Adj. Nut Lock Nut	.18
21944	Tire Carrier Bracket (Right)	1.25	22020	Rear Brake Fork	
21945	Tire Carrier Tie Bar	.25	22021	Emergency Brake Fork Lever	
21946	Tire Carrier Bracket Stud	1.10	22022	Brake Fork Lever Bushing	
21947	Service Brake Rod (Rear)	.45	22023	Service Brake Fork Lever	
21948	Emergency Brake Rod (Rear)	.40	22024	Special Knurled Washer	.13
21949	Brake Pedal Rod	. 55	22025	Front Brake Bell Crank (Left) Front Brake Bell Crank (Right)	.50
21950	Hand Brake Lever Rod Service Brake Rod (Front)	.35	22026 22027	Rear Brake Fork Lever Adjuster	1.00
21951 21952	Emergency Brake Rod (Front)	.55 .45	22028	Cross Shaft Lever (Outer)	1.25
21953	Brake Cross Shaft Bracket	.70	22029	Brake Lever Equalizer Bell Crank	.35
21954	Emergency Brake Cross Shaft	1.30	22030	Front Wheel Brake Drum	3.50
21955	Idler Shaft Lever (Outer)	.90	22031	Rear Wheel Brake Drum	
21956	Service Brake Cross Shaft Lever	692.68	22032	Front Brake Drum Cover	
	(Inner)	.90	22033	Rear Wheel Complete	
21957	Service Brake Cross Shaft (Long)	1.65	22034 22035	Front Wheel Complete Steering Knuckle	8 00
21958 21959	Service Brake Cross Shaft (Short) Hand Brake Lever Bell Crank	.90	22036	Steering Arm, Right	5 25
21959	Brake Idler Shaft	.35 .35	22037	Steering Arm, Left	5.25
21963	Hand Brake Ratchet Pawl	.25	22038	Front Brake Bell Crank Rod	.45
21964	Brake Cross Shaft Lever	.90	22039	Front Brake Rod (Rear)	
21965	Service Brake Equalizer Bar	.35	22040	Brake Fork Adjuster Bushing	
21967	Cross Shaft Bell Crank Spring	.07	22041	Frame Complete	
21968	Idler Shaft Lever (Inner)	.90	22046	Hex. Head Cap Screw	
21969	Service Brake Idler Lever (Left Rear).	.70	22048 22049	Spark Control Rod Complete Spark Control Bell Crank Bracket	.25
21970 21971	Service Brake Idler Lever (Right Rear) Demountable Clincher Rim	$\frac{.70}{2.50}$	22055	Front Wheel Brake Drum	3.00
21972	Front Wheel Complete	9.00	22056	Propeller Shaft	
21973	Rear Wheel Complete	10.00	22057	Universal Joint Flange	
21974	Radiator Hood Rod Bracket	.07	22058	Water Pump Grease Cup	
21975	Pedal Shaft (R. D.)	4.50	22059	Oil Filler Body Baffle	.09
21976	Spark Control Rod (Front)	.45	22060	Starter Strap (Upper)	.00
21978	Cylinder Block	70.00	22061 22062	Starter Strap (Lower)	16
21979	Water Jacket Cover	$\substack{.25\\1.35}$	22063	Transmission Retainer Gasket (Front)	$\tilde{0}$ 2
21980 21981	Camshaft Bushing (Front)	.02	22064	Brake Cross Shaft Lever Rod (R. D.).	
21982	Water Jacket Cover Gasket	.03	22065	Service Brake Countershaft (R. D.)	
21983	Cylinder Head	7.35	22066	Service Brake Countershaft Lever	00155
21984	Connecting Rod Complete	4.80	7754	(R. D.)	.80
			22067	Pedal to Cross Shaft Lever Rod (R. D.) Frame Complete	35 00
	Note: Rod returned for new Bearing and Bushing will be accepted at full credit less a		22068 22069	Rear Wheel Complete	15.00
	charge of \$2.60 list for new Bearing and Bushing.		22070	Front Wheel Complete	
	A STATE OF THE RESIDENCE OF THE PROPERTY OF TH				7 mg/361 x 7 /2

Speedometer Drive Pinion. 2,10 222076 Windshield Upper Glass 3,75 22206 Carburetor Inlet Valve Seat. Use No. 22 222078 Windshield Upper Glass 5,25 22206 Carburetor Inlet Valve Seat. Use No. 22 222088 Raw Wheel Brake Drum. 3,50 22207 Carburetor Surfing Box Gland Gasket 222085 Drake Idler Shaft. 3,00 22207 Carburetor Surfing Box Gland Gasket 222087 Carburetor Surfing Box Gland Gasket 222088 Drake Box Gland Lining 1.15 Carburetor Nozzle Head Screw 222089 Drake Box Gland Gasket 22210 Carburetor Nozzle Head Screw 22209 External Brake Band (Left) 4.00 22211 Carburetor Nozzle Head Screw 22209 External Brake Band (Left) 4.00 22211 Carburetor Nozzle Head Screw 22209 External Brake Band (Left) 4.00 22211 Carburetor Nozzle Head Screw 22209 External Brake Band (Left) 4.00 22211 Carburetor Nozzle Head Screw 22209 External Brake Band (Left) 4.00 22211 Carburetor Nozzle Head Screw 22209 External Brake Band (Left) 4.00 22211 Carburetor Nozzle Head Screw 22221 Carburetor Nozzle Head Screw 222221 Carburetor Noz	Part No.	Part Name	Price	Part No.	Part Name	Price
20076 Mindhield Upper Glass 3.75 22204 Carburetor Venturi. 20077 Windhield Upper Glass 5.25 22206 Carburetor Inlet Valve Seat. Use No. 22 20088 Raw Wheel Brake Brum 3.50 22207 Carburetor Inlet Walve Seat. Use No. 22 20089 Brake Lider Shaft, and Lining 3.00 22208 Carburetor Inlet Walve Seat. Use No. 22 20089 Emergency Brake Rod Comp. (Rear) 5.00 22210 Carburetor Nozale Disc. 20089 Emergency Brake Rod Comp. (Rear) 5.00 22211 Carburetor Nozale Disc. 20091 External Brake Band (Lift) 4.00 22214 Carburetor Nozale Disc. 20091 External Brake Band (Lift) 4.00 22215 Carburetor Pay-Pass Tube 20093 External Brake Band (Lift) 4.00 22215 Carburetor Pay-Pass Tube 20093 External Brake Band (Lift) 4.00 22215 Carburetor Bay-Pass Tube 20093 External Brake Band (Lift) 4.00 22215 Carburetor Bay-Pass Tube 20093 External Brake Band (Lift) 4.00 22215 Carburetor Day-Pass Tube 20093 External Brake Band (Lift) 4.00 22215 Transmission Support Servey 20094 External Brake Band (Lift) 4.00 22215 Transmission Support Servey 20095 Emergency Brake Rod (Front) 4.6 22220 Tire Carrier Bracket (Lift) 4.00 22097 Rear Fender (Lift) 6.75 22224 Rear Wheel Complete 10 20098 Rear Fender (Lift) 6.75 22224 Rear Wheel Complete 10 20099 Tire Carrier Bracket (Lift) 3.60 22225 Front Wheel Complete 10 20100 Tire Carrier Bracket (Lift) 3.60 22225 Front Wheel Complete 10 20100 Tire Carrier Bracket (Lift) 3.60 22225 Front Wheel Complete 10 20100 Tire Carrier Bracket (Lift) 3.60 22225 Front Wheel Complete 10 20100 Tire Carrier Bracket (Lift) 3.60 22225 Front Wheel Complete 10 20100 Tire Carrier Bracket (Lift) 3.60 22225 Front Wheel Complete 10 20100 Tire Carrier Bracket (Lift) 3.60 22225 Front Wheel Complete 10 20100 Tire Carrier Bracket (Lift) 3.60 22225 Front Wheel Complete 10 22225 Front Whe			A Company of the Company		Carburetor By-Pass Adjusting Needle	
2007 Windshield Lower Glass 3.75 22207 Carburetor Inlet Needle 1.9 22208 Rar Wheel Brake Drum 3.50 22207 Carburetor Stuffing Box Gland Gasket 22085 Rate Idler Shaft 3.50 22208 Carburetor Stuffing Box Gland Gasket 22085 Carburetor Stuffing Box Gland Gasket 22085 Rate Idler Shaft 3.50 22208 Carburetor Stuffing Box Gland Gasket 22088 External Brake Band Lining 1.5 22208 Carburetor Novale Disc 22088 External Brake Band (Rear) 6.50 22211 Carburetor Novale Bead Screw 22089 Description 22218 Carburetor Novale Bead Screw 22209 Description 22218 Carburetor Novale Bead Screw 22209 Description 22218 Carburetor Novale Bead Screw 22209 Description 22218 Carburetor Puel Restriction 22219 Carburetor Puel Restriction 22219 Carburetor Puel Restriction 22210 Carburetor Puel Restriction 22219 Carburetor Puel Restriction 22210 Carburetor Puel Restriction 22210 Carburetor Puel Restriction 22210 Carburetor Puel Restriction 22210 Carburetor Adjusting Screw 22209 Carburetor Puel Restriction 22211 Carburetor Adjusting Screw 22209 Carburetor Puel Restriction 22211 Carburetor Adjusting Screw 22209 Carburetor Puel Restriction 22211 Carburetor Adjusting Screw 22216 Carburetor Adjusting Screw 2						.15
22084 Rear Wheel Brake Bortum 3.50 22206 Carburetor Inlet Valve Seat. Use No. 22 22084 Rear Wheel Brake Bortum 3.50 22208 Carburetor Stuffing Box Gland Gasket 22208 External Brake Band (Right) 4.00 22212 Carburetor Nozzle Head Sterew 22209 External Brake Band (Left) 4.00 22214 Carburetor Fox Bestriction 22209 External Brake Band (Left) 4.00 22215 Carburetor Pay-Pass Tube 22209 External Brake Band (Left) 4.00 22215 Transmission Support Screw 22209 External Brake Anchor Plate 3.00 22216 Transmission Support Screw 22209 External Brake Anchor Plate 3.00 22216 Transmission Support Screw 22209 External Brake Anchor Plate 3.00 22216 Transmission Support Screw 22209 External Brake Anchor Plate 3.00 22216 Transmission Support Screw 22209 External Brake Anchor Plate 3.00 22216 Transmission Support Screw 22209 External Brake Anchor Plate 3.00 22216 Transmission Support Screw 22209 External Brake Anchor Plate 3.00 22216 Transmission Support Screw 22209 External Brake Anchor Plate 3.00 22221 Transmission Support Screw 22209 Transmission Support Screw 3.00 22221 Transmission Support Screw 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00 3.00					Carburetor Inlet Needle	1.40
22088 Rear Wheel Briske Drum 3.50 22207 Carburetor Stuffing Box Gland Gasket 22088 External Brake Band Lining 9.0 22208 Carburetor Nozzle 222087 Carburetor Nozzle 222088 Carburetor Nozzle 222090 Carburetor Nozzle 222090 Carburetor Nozzle 222090 Carburetor Nozzle 222090 Carburetor Brake Band (Left) 4.00 22214 Carburetor Pael Restriction 222092 External Brake Band (Right) 4.00 22214 Carburetor Pael Restriction 222093 Carburetor Pael Restriction 222092 Carburetor Pael Restriction 22212 Carburetor Pael Restriction 22212 Carburetor Pael Restriction 22212 Carburetor Pael Restriction 22212 Carburetor Adjusting Screw 22213 Carburetor Pael Restriction 22214 Carburetor Adjusting Screw 222224 Carburetor Adjusting Screw 222224 Carburetor Pael Restriction 222224 Car			The second second		Carburetor Inlet Valve Seat. Use No.	
22086 External Brake Band Lining. 90 22290 Carburetor Nozzle.	22084	Rear Wheel Brake Drum	3.50		Carburetor Stuffing Box Gland	.80
Internal Brake Band Lining					Carburetor Stuffing Box Gland Gasket	
202088 Service Brake Rod Comp. (Rear) 60 22211 Carburetor Nozzle Head Screw 20209 Internal Brake Band (Left) 4.00 22213 Carburetor Puc Restriction.					Carburetor Nozzle Disc	$\begin{array}{c} .50 \\ .10 \end{array}$
202099 Emergency Brake Rod Comp. (Rear) 50 22213 Carburetor Fuel Restriction. 222099 External Brake Band (Light) 4.00 22214 Carburetor Adjusting Screw 222092 External Brake Band (Right) 4.00 22215 Transmission Support Screw 222093 Brake Idler Lever 50 22216 Transmission Support Screw 222093 Brake Idler Lever 50 22216 Tre Carrier Bracket (Light) 4 4 4 4 4 2 2 2 2 2						.25
22092 External Brake Band (Left)					Carburetor Fuel Restriction	.20
22092 External Brake Band (Right), 4.00 22236 Transmission Support Screw 22093 Brake Idler Lever. 50 2216 22095 Emergency Brake Nanchor Plate. 35 22217 Tire Carrier Bracket (Left), 4 22296 Emergency Brake Rod (Front). 45 22221 Tire Carrier Bracket (Left), 4 222097 Rear Fender (Left). 6.75 22224 Flat Head Tubular Rivet. 10 22099 Tire Carrier Bracket (Left), 3.60 22225 Rear Wheel Complete. 10 22100 Tire Carrier Bracket (Left), 3.60 22225 Rear Wheel Complete. 10 22100 Tire Carrier Bracket (Right), 4.75 22230 Emonutable Rim Lock Stud Screw 22104 Flat head Tubular Rivet. 222097 Emonutable Rim Lock Stud Screw 22104 Flat head Tubular Rivet. 22209 Torn Wheel Complete. 10 22105 Piston with Pin (005° oversize) 4.75 22230 Demountable Rim Lock Stud Screw 22106 Piston with Pin (010° oversize) 4.75 22231 Demountable Rim Lock Stud Screw 22108 Piston with Pin (010° oversize) 4.75 22231 Demountable Rim Lock Stud Screw 22108 Piston with Pin (010° oversize) 4.75 22231 Tire Carrier Bracket (Right), 1 22125 Exhaust Pipe Packing Nut. 60 22234 Tire Carrier Bracket (Left), 1 1 22127 Rear Axle Housing (Right Half), 17.00 22235 Tire Carrier Bracket (Left), 1 1 22126 Rear Axle Housing (Right Half), 17.00 22235 Tire Carrier Bracket (Left), 1 1 22127 Rear Axle Housing (Right Half), 17.00 22235 Demountable Rim Lock Stud Screw 22218 Rear Axle Housing (Right Half), 17.00 22233 Tire Carrier Bracket (Left), 1 1 22129 Rear Axle Housing (Right Half), 17.00 22233 Differential Shaft Retaining Screw 1 2 2224 Rear Axle Housing (Right Half), 17.00 22235 Differential Shaft Retaining Screw 1 2 2224 Rear Axle Housing (Right Half), 16 Rear Axle Housin					Carburetor By-Pass Tube	.80
22093 Brake Idler Lever. 50 22094 External Brake Anchor Plate. 35 22017 Tire Carrier Bracket (Left). 4 22095 Emergency Brake Rod (Front). 45 22096 Emergency Brake Rod (Front). 45 22096 Emergency Brake Rod (Front). 45 22097 Rear Wheel Complete. 10. 00 22221 Flat Head Tubular Rivet. 10 22098 Rear Fender (Left). 6.75 22228 Rear Wheel Complete. 10 22098 Tire Carrier Bracket (Left). 3. 60 22227 Floor Wheel Complete. 10 22100 Tire Carrier Bracket (Right). 3. 60 222210 Floor with Pin (Standard). 4.75 22103 Floor with Pin (1007 oversize). 4.75 22104 Floor with Pin (1007 oversize). 4.75 22105 Floor with Pin (1007 oversize). 4.75 22106 Floor with Pin (1007 oversize). 4.75 22107 Floor with Pin (1015 oversize). 4.75 22108 Floor with Pin (1015 oversize). 4.75 22109 Floor with Pin (1015 oversize). 4.75 22105 Floor with Pin (1015 oversize). 4.75 22105 Floor with Pin (1020 oversize). 4.75 22107 Floor with Pin (1020 oversize). 4.75 22108 Floor with Pin (1020 oversize). 4.75 22109 Floor with Pin (1020 oversize). 4.75 22109 Floor with Pin (1020 oversize). 4.75 22105 Floor with Pin (1020 oversize). 4.75 22107 Floor with Pin (1020 oversize). 4.75 22108 Floor with Pin (1020 oversize). 4.75 22109 Floor with Pin (1020 oversize). 4.75 22100 Floor Wentland Floor with Pin			2000		Transmission Support Screw	.40
22994 External Brake Anchor Plate 35 22295 Tire Carrier Bracket (Left) 4 22096 Rear Wheel Complete 10 90 22221 Flat Head Tubular Rivet 10 22097 Rear Fender (Left) 6 75 22224 Flat Head Tubular Rivet 10 22099 Rear Fender (Right) 3 60 22226 Rear Wheel Complete 10 10 22099 Tire Carrier Bracket (Left) 3 60 22226 Rear Wheel Complete 10 10 22039 Tire Carrier Bracket (Left) 3 60 22226 Rear Wheel Complete 10 22030 Floton with Pin (003° oversize) 4 75 22239 Demountable Rim Lock Stud Screw 22105 Piston with Pin (005° oversize) 4 75 22231 Demountable Rim Lock Stud Screw 22106 Piston with Pin (105° oversize) 4 75 22231 Demountable Rim Lock Stud Screw 22107 Piston with Pin (105° oversize) 4 75 22231 Demountable Rim Lock Stud Screw 22107 Piston with Pin (105° oversize) 4 75 22231 Demountable Rim Lock Stud Screw 22107 Piston with Pin (105° oversize) 4 75 22231 Demountable Rim Lock Stud Screw 22107 Piston with Pin (105° oversize) 4 75 22231 Demountable Rim Lock Stud Screw 22107 Piston with Pin (105° oversize) 4 75 22231 Demountable Rim Lock Stud Screw 22107 Piston with Pin (105° oversize) 4 75 22231 Demountable Rim Lock Stud Screw 22212 Rear Axie Housing (Left Half) 77 00 22233 Tire Carrier Bracket (Left) 1 1 1 1 1 1 1 1 1					Tire Carrier Bracket (Right)	4.00
22296 Emergency Brake Rod (Front)			.35	22217	Tire Carrier Bracket (Left)	4.00
22098 Rear Fender (Left)					Tire Carrier Bracket Stud	.14
22098 Rear Fender (Right)					Rear Wheel Complete	.01
22190 Tire Carrier Bracket (Right) 3.60 22227 Pomountable S.R. Rim. 2 22100 Tire Carrier Bracket (Right) 3.60 22227 Demountable S.R. Rim. 2 22101 Piston with Pin (905" oversize) 4.75 22230 Demountable Rim Lock Stud Screw 22106 Piston with Pin (905" oversize) 4.75 22230 Demountable Rim Lock Stud Screw 22106 Piston with Pin (915" oversize) 4.75 22230 Demountable Rim Wedge (Slotted) 22107 Piston with Pin (915" oversize) 4.75 22232 Demountable Rim Wedge (Slotted) 22108 Piston with Pin (915" oversize) 4.75 22232 Demountable Rim Wedge (Slotted) 22108 Piston with Pin (920" oversize) 4.75 22232 Demountable Rim Wedge (Slotted) 22108 Piston with Pin (920" oversize) 4.75 22232 Demountable Rim Wedge (Slotted) 22126 Piston with Pin (920" oversize) 4.75 22232 Demountable Rim Wedge (Slotted) 22126 Piston with Pin (920" oversize) 4.75 22232 Demountable Rim Wedge (Slotted) 22126 Piston with Pin (920" oversize) 4.75 22232 Demountable Rim Wedge (Slotted) 22126 Piston with Pin (910" oversize) 4.75 22232 Demountable Rim Wedge (Slotted) 22234 Demountable Rim Wedge (Slotted) 22234 Demountable Rim Wedge (Slotted) 22234 Tire Carrier Bracket (Right) 1.00 22234 Tire Carrier Bracket (Right) 1.00 22235 Tire Carrier Bracket (Right) 1.00 22236 Tire Carrier Bracket (Right) 1.00 22236 Tire Carrier Bracket (Right) 1.00 22236 Tire Carrier Bracket (Right) 1.00 22235 Tire Carrier Bracket (Right) 1.00 22236 T					Rear Wheel Complete	10.00
22103 Piston with Pin (903° oversize) 4.75 22229 Demountable Rim Lock Stud 22104 Piston with Pin (903° oversize) 4.75 22229 Demountable Rim Lock Stud 22105 Piston with Pin (905° oversize) 4.75 22221 Demountable Rim Lock Stud 22106 Piston with Pin (905° oversize) 4.75 22231 Dem Rim Wedge (Slotted) 22107 Piston with Pin (915° oversize) 4.75 22231 Dem Rim Wedge (Round Hole) 22108 Piston with Pin (920° oversize) 4.75 22232 Tire Carrier Bracket (Left) 1 1 1 1 1 1 1 1 1				22226	Front Wheel Complete	10.00
			3.60	22227	Demountable S.S. Rim	2.25
Demountable Rim Wedge (Slotted)	22103	Piston with Pin (Standard)			Demountable Rim Lock Stud	.10
22107 Piston with Pin (010' oversize)						$.10 \\ .14$
22107 Piston with Pin (016" oversize) 4.75 22232 Tire Carrier Bracket (Right) 1 1 1 1 1 1 1 1 1		Piston with Pin (.010" oversize)			Dem. Rim Wedge (Round Hole)	.14
22126 Exhaust Pipe Packing Nut. 60 22234 Tire Carrier Bracket (Right). 1 22126 Rear Axle Housing (Right Half). 17.00 22236 Rear Axle Housing (Right Half). 17.00 22236 Rear Axle Housing (Right Half). 16.00 22237 Rear Axle Housing (Right Half). 17.00 22236 Rear Axle Housing (Left Half). 16.00 22237 Rear Axle Housing (Left Half). 16.00 22238 Differential Shaft Retaining Screw. 12 22234 Rear Axle Housing (Left Half). 16.00 22238 Differential Pinion Shaft. 65 22234 Reg. Handle Escutcheon Spring Carliar Prinor Mat. 2.15 22235 Regulator Handle Escutcheon. 22238 Outside Door Handle. 80 22238 Windshield Wing Bracket (Left). 8 22243 Quisside Door Handle, with Key. 5.00 22238 Windshield Wing Bracket (Right). 8 22145 Clutch Shaft Yoke. 70 22263 Windshield Lower Panel Complete. 15.00 22264 Door Lock. 1 22154 Cowl Ventilator Spring (Left). 25 22265 Door Lock. 1 22155 Windshield Fastening Nut. 25 22266 Windshield Glass. 12 22155 Windshield Door Panel Complete. 12.50 22266 Windshield Glass. 12 22156 Windshield Door Panel Complete. 12.50 22266 Windshield Glass. 12 22157 Windshield Lower Panel Complete. 13.00 22269 Lightweight Piston (003" oversize) 3 22169 Door Window Handle Escutcheon. 15 22271 Eiston (0010" oversize) 3 22161 Handle Escutcheon Spring. 16 22273 Piston (0010" oversize) 3 3 22161 Handle Escutcheon Spring. 16 22273 Piston (0010" oversize) 3 3 22161 Handle Escutcheon Spring. 16 22273 Piston (0010" oversize) 3 3 22161 Pront Wheel Hub Bolt. 10 22275 Piston (0030" oversize) 3 22171 Pront Wheel Hub Bolt. 10 22276 Piston (0030" oversize) 3 22171 Pront Wheel Hub Bolt. 10 22276 Piston (0030" oversize) 3 22171 Pront Wheel Hub Bolt. 10 22277 Piston (030" oversize) 3 22179 Windshield Glass Clip Screw. 40 22284 Door Lock Lever Handle Escutcheon. 16 22287 Piston Ring (030" oversize) 3 22288 Piston Ring (010" oversize) 3 22291 Pront Wheel Graph Pront Weel				22232	Tire Carrier Bracket (Right)	1.75
22126 Rear Axle Housing (Right Half) 17.00 22235 Rear Axle Housing (Right Half) 17.00 22237 Rear Axle Housing (Right Half) 17.00 22237 Rear Axle Housing (Right Half) 17.00 22237 Rear Axle Housing (Right Half) 16.00 22238 Instrument Board Bracket (Upper) 17.00 22238 Instrument Board Bracket (Upper) 17.00 22238 Instrument Board Bracket (Upper) 18.00 22238 Instrument Board Bracket (Upper) 18.00 22234 Rear Axle Housing (Left Half) 16.00 22234 Rear Axle Housing (Left Half) 16.00 22234 Instrument Board Bracket (Upper) 16.00 22234 Rear Axle Housing (Left Half) 16.00 22234 Instrument Board Bracket (Upper) 16.00 22234 Instrument Board Bracket (Upper) 16.00 22234 Reg. Handle Escutcheon Spring 22235 22257 Windshield Wing Bracket (Left) 8.00 22238 Windshield Wing Bracket (Left) 8.00 22234 Reg. Handle Escutcheon 15.00 22234 Windshield Wing Bracket (Left) 8.00 22234 Windshield Wing Bracket (Left) 8.00 22235 Windshield Lower Panel Complete 15.00 22245 Windshield Lower Panel Complete 10.00 22245 Windshield Lower Panel Complete 10.00 22246 Windshield Glass 12.00 22246 Windshield Lower Panel Complete 10.00 22249 Lightweight Piston (Standard) 3.00 22216 Windshield Lower Panel Complete 15.00 22274 Piston (003° oversize) 3.00 22274					Tire Carrier Bracket (Left)	1.75
22127 Rear Axle Housing (Left Half)					Tire Carrier Bracket (Right)	1.75
22128					Rear Axle Housing (Right Half)	1.75
22139					Rear Axle Housing (Left Half)	16.00
22136 Differential Shaft Retaining Screw. 12 22241 Grease Nipple.				22238	Instrument Board Bracket (Upper)	.35
22137 Front Floor Mat		Differential Shaft Retaining Screw	. 12		Grease Nipple	.30
22138 Outside Door Handle 2. 25 22257 Windshield Wing Bracket (Left) 8 22139 Outside Door Handle, with Key 5.00 22258 Windshield Wing Bracket (Right) 8 8 22145 Clutch Shaft Yoke 70 22263 Windshield Lower Panel Complete 17 22149 Rear Wheel Complete 15.00 22264 Door Lock 1 22153 Cowl Ventilator Spring (Right) 25 22265 Door Lock 1 22155 Windshield Fastening Nut 25 22266 Windshield Lower Panel Complete 12 50 22266 Windshield Lower Panel Complete 12 50 22267 Hex. Nut (Special)						$05 \\ .15$
22199 Outside Door Handle, with Key 5.00 22263 Windshield Wing Bracket (Right) 8 22164 Clutch Shaft Yoke 70 22263 Windshield Lower Panel Complete 17 15 15 15 15 15 15 15					Windshield Wing Bracket (Left)	8.00
22145 Clutch Shaft Yoke		Outside Door Handle, with Key			Windshield Wing Bracket (Right)	8.00
22153 Cowl Ventilator Spring (Left) 25 22265 Cowl Ventilator Spring (Right) 25 22266 Windshield Glass 12 22155 Windshield Fastening Nut 25 22267 Windshield Glass 12 22157 Windshield Upper Panel Complete 12 50 22268 Lighting and Ignition Switch Key 22157 Windshield Lower Panel Complete 10 00 22269 Lightweight Piston (Standard) 3 3 3 3 3 3 3 3 3	22145	Clutch Shaft Yoke			Windshield Lower Panel Complete	
22154 Cowl Ventilator Spring (Right) 25 22266 Windshield Glass 12 22155 Windshield Upper Panel Complete 12.50 22267 Hex. Nut (Special)						1.80
22155 Windshield Fastening Nut						1.80
22156 Windshield Upper Panel Complete 12.50 22268 Lighting and Ignition Switch Key 22157 Windshield Lower Panel Complete 10.00 22270 Lightweight Piston (Standard) 3 3 3 3 3 3 3 3 3					Hex. Nut (Special)	.06
22158 Back Window Curtain					Lighting and Ignition Switch Key	.05
Door Window Handle						3.60
22160 Door Window Handle Escutcheon 15 22272 Piston (010" oversize) 3 3 22161 Handle Escutcheon Spring 16 22273 Piston (015" oversize) 3 3 22162 Front Wheel Complete 15 00 22274 Piston (020" oversize) 3 3 22169 Front Wheel Hub Bolt 10 22275 Piston (023" oversize) 3 3 22170 Demountable Rim Bolt 10 22276 Piston (025" oversize) 3 3 22171 Rear Wheel Brake Drum 3 50 22277 Piston (030" oversize) 3 3 22172 Front Wheel Hub Bolt 10 22278 Piston (035" oversize) 3 3 22173 Speedometer Drive Pinion Sleeve 60 22279 Battery to Magneto Change Over Unit 75 22174 Timing Chain Hunting Link 75 22280 Oil Gun 3 22177 Windshield Side Arm (Left) 2 05 22281 Door Complete with Glass (Left) Upon Applicate 22180 Windshield Glass Clip Plug 15 Upon Applicate 22181 Windshield Glass Clip Screw 04 22284 Dome Light Glass Use No. 23 22183 Door Bumper Retainer Use No. 22284 Dome Light Glass Use No. 23 22183 Door Lock Lever Handle Escutcheon 16 22289 Piston Ring (010" oversize) Piston Ring (020" oversize) 22191 Piston Ring (020" oversize) Piston Ring (030" oversize) Pi					Piston (005" oversize)	$\frac{3.60}{3.60}$
22161			the state of the s			3.60
22162 Front Wheel Complete. 15.00 22274 Piston (.020" oversize). 3 22170 Demountable Rim Bolt. 10 22276 Piston (.025" oversize). 3 22171 Rear Wheel Brake Drum. 3.50 22277 Piston (.030" oversize). 3 22172 Front Wheel Hub Bolt. 10 22278 Piston (.030" oversize). 3 22173 Speedometer Drive Pinion Sleeve. 60 22279 Battery to Magneto Change Over Unit 75 22174 Timing Chain Hunting Link. 75 22280 0il Gun. 3 22178 Windshield Side Arm (Right). 2.05 22281 Door Complete with Glass (Left) 22179 Windshield Glass Clip Plug. 15 22282 Door Complete with Glass (Right) Upon Applicat 22180 Windshield Glass Clip Plug. 15 22283 Brake Shoe Lock Ring. Upon Applicat 22181 Windshield Glass (Lower). 4.00 22284 Dome Light Reflector. 1 22182 Windshield Glass (Lower). 4.00 22286 Dome Light Reflector	A STATE OF THE STA			22273	Piston (.015" oversize)	3.60
22170 Demountable Rim Bolt 10 22276 Piston (.025" oversize) 3 22171 Rear Wheel Brake Drum 3 50 22277 Piston (.030" oversize) 3 22172 Front Wheel Hub Bolt 10 22278 Piston (.035" oversize) 3 22173 Speedometer Drive Pinion Sleeve 60 22279 Battery to Magneto Change Over Unit 75 22174 Timing Chain Hunting Link 75 22280 Oil Gun 3 22175 Windshield Side Arm (Right) 2 05 22281 Door Complete with Glass (Left) 22176 Windshield Glass Clip Plug 08 22281 Door Complete with Glass (Left) 22180 Windshield Glass Clip Plug 15 Upon Applicat 22181 Windshield Glass (Lower) 4 00 22283 Brake Shoe Lock Ring Upon Applicat 22182 Windshield Glass (Lower) 4 00 22284 Dome Light Glass Use No. 23 22182 Top Ventilator Regulator Plate 20 22287 Piston Ring (Standard) 22288 22191 Rear		Front Wheel Complete	15.00		Piston (.020" oversize)	3.60
22171 Rear Wheel Brake Drum 3.50 22277 Piston (.030" oversize) 3 22172 Front Wheel Hub Bolt 10 22278 Piston (.035" oversize) 3 22173 Speedometer Drive Pinion Sleeve 60 22279 Battery to Magneto Change Over Unit 75 22174 Timing Chain Hunting Link 75 22280 Oil Gun 3 22175 Windshield Side Arm (Left) 2.05 22281 Door Complete with Glass (Left) Upon Applicat 22179 Windshield Giass Clip Plug .08 22282 Door Complete with Glass (Right) Upon Applicat 22181 Windshield Glass (Lower) .04 22283 Brake Shoe Lock Ring Upon Applicat 22182 Windshield Glass (Lower) .400 22284 Dome Light Glass Use No. 23 22183 Door Bumper Retainer .Use No. 1592 22286 Dome Light Reflector .1 22184 Top Ventilator Regulator Plate .20 22288 Piston Ring (.010" oversize) 22191 Rear Floor Carpet 8.00 22289					Piston (.023" oversize)	3.60
22172 Front Wheel Hub Bolt 10 22278 Piston (.035" oversize) 3 22173 Speedometer Drive Pinion Sleeve .60 22279 Battery to Magneto Change Over Unit 75 22174 Timing Chain Hunting Link .75 22280 Oil Gun .3 22178 Windshield Side Arm (Left) .205 22281 Door Complete with Glass (Left) 22180 Windshield Glass Clip Plug .15 Upon Applicat 22181 Windshield Glass (Lower) .400 22283 Brake Shoe Lock Ring 22182 Windshield Glass (Lower) .400 22284 Dome Light Reflector .1 22183 Door Bumper Retainer .Use No. 23 22287 Piston Ring (Standard) 22184 Top Ventilator Regulator Plate .20 22288 Piston Ring (.010" oversize) 22193 Rear Floor Carpet .800 22289 Piston Ring (.030" oversize) 22195 Tire Carrier Bracket (Right) 1.75 22290 Piston Ring (.030" oversize)					Piston (030" oversize)	$\frac{3.60}{3.60}$
22173 Speedometer Drive Pinion Sleeve. 60 22279 Battery to Magneto Change Over Unit 75 75 22174 Timing Chain Hunting Link 75 22280 Oil Gun 3 3 22179 Windshield Side Arm (Right) 2 05 22281 Door Complete with Glass (Left) Upon Applicat 1 </td <td></td> <td></td> <td></td> <td></td> <td></td> <td>3.60</td>						3.60
22177 Windshield Side Arm (Left)				22279	Battery to Magneto Change Over Unit	75.00
22178 Windshield Side Arm (Right) 2 .05					Oil Gun	3.00
22179 Windshield Pivot Plug .08 22282 Door Complete with Glass (Right) 22180 Windshield Glass Clip Plug .15 Upon Applica 22181 Windshield Glass Clip Screw .4 .04 22283 Brake Shoe Lock Ring 22182 Windshield Glass (Lower) .4 .00 22284 Dome Light Glass 22183 Door Bumper Retainer .Use No. .25				22281	Door Complete with Glass (Left)	igntion
22180 Windshield Glass Clip Plug 15 Upon Applicated 22181 Windshield Glass Clip Screw 04 22283 Brake Shoe Lock Ring 22182 Windshield Glass (Lower) 4 00 22284 Dome Light Glass Use No. 23 22184 Top Ventilator Regulator Plate 20 22287 Piston Ring (Standard) 22185 Top Vent. Regulator Plate Catch 20 22288 Piston Ring (.010" oversize) 22289 Piston Ring (.020" oversize) <td></td> <td></td> <td></td> <td>22282</td> <td>Door Complete with Glass (Right)</td> <td>ication</td>				22282	Door Complete with Glass (Right)	ication
22181 Windshield Glass (Lower) 04 222283 Brake Shoe Lock Ring 22182 Windshield Glass (Lower) 4 00 22284 Dome Light Glass Use No. 23 22183 Door Bumper Retainer Use No. 1592 22286 Dome Light Glass Use No. 23 22184 Top Ventilator Regulator Plate 20 22287 Piston Ring (Standard) 22288 22195 Top Vent. Regulator Plate Catch 20 22288 Piston Ring (.010" oversize) 22289 22191 Rear Floor Carpet 8 00 222289 Piston Ring (.020" oversize) 22290 22195 Tire Carrier Bar 40 22290 Piston Ring (.030" oversize) 22290 22196 Tire Carrier Bracket (Right) 1 .75 22290 Vacuum Tank Suction Pipe 22197 Tire Carrier Bracket (Left) 1 .75 22295 Door Lock Lever Escutcheon 22198 Tire Carrier Bracket (Right) 1 .75 22296 Door Lock Lever Escutcheon 22198 Tire Carrier Bracket (Right) 1 .90 22297 Windshield Rubber Channel 1 </td <td></td> <td>Windshield Glass Clip Plug</td> <td></td> <td>411120 417</td> <td></td> <td>ication</td>		Windshield Glass Clip Plug		411120 417		ication
22183 Door Bumper Retainer Use No. 1592 22286 Dome Light Reflector 1 22184 Top Ventilator Regulator Plate 20 22287 Piston Ring (Standard) 1 22185 Top Vent. Regulator Plate Catch 20 22288 Piston Ring (.010" oversize) 2 22191 Rear Floor Carpet 8.00 22289 Piston Ring (.020" oversize) 2 22195 Tire Carrier Tie Bar 40 22290 Piston Ring (.030" oversize) 2 22196 Tire Carrier Bracket (Right) 1.75 22295 Door Dove Tail (Male) 2 22197 Tire Carrier Bracket (Left) 1.75 22296 Door Lock Lever Escutcheon 22198 Tire Carrier Bracket (Right) 1.90 22297 Windshield Rubber Channel 1 22199 Tire Carrier Bracket (Left) 1.90 22298 Door Dove Tail (Female) 1 22200 Rear Fender (Right) 1.00 22299 Door Hinge (Lower)	22181	Windshield Glass Clip Screw	.04			
22184 Top Ventilator Regulator Plate 20 22287 Piston Ring (Standard) 22185 Top Vent. Regulator Plate Catch 20 22288 Piston Ring (.010" oversize) 22191 Rear Floor Carpet 8 .00 22289 Piston Ring (.020" oversize) 22192 Door Lock Lever Handle Escutcheon 16 22290 Piston Ring (.030" oversize) 22195 Tire Carrier Bracket (Right) 1 .75 22293 Vacuum Tank Suction Pipe 22196 Tire Carrier Bracket (Left) 1 .75 22295 Door Dove Tail (Male) 22197 Tire Carrier Bracket (Right) 1 .75 22296 Door Lock Lever Escutcheon 22198 Tire Carrier Bracket (Right) 1 .90 22297 Windshield Rubber Channel 1 22199 Tire Carrier Bracket (Right) 1 .90 22298 Door Dove Tail (Female) 22290 22200 Rear Fender (Right) 1 .90 22298 Door Dove Tail (Female) 1						
22185 Top Vent. Regulator Plate Catch 20 22288 Piston Ring (.010" oversize) 22191 Rear Floor Carpet 8 00 22289 Piston Ring (.020" oversize) 22192 Door Lock Lever Handle Escutcheon 16 22290 Piston Ring (.030" oversize) 22195 Tire Carrier Bar. 40 22293 Vacuum Tank Suction Pipe 22196 Tire Carrier Bracket (Right) 1 .75 22295 Door Dove Tail (Male) 22197 Tire Carrier Bracket (Right) 1 .90 22297 22198 Tire Carrier Bracket (Left) 1 .90 22298 22199 Tire Carrier Bracket (Right) 1 .90 22298 22190 Rear Fender (Right) 1 .90 22298 22190 Door Dove Tail (Female) 1 .90 22290 Door Hinge (Lower) .90					Piston Ring (Standard)	.30
22191 Rear Floor Carpet					Piston Ring (.010" oversize)	.30
22192 Door Lock Lever Handle Escutcheon. 16 22290 Piston Ring (.030" oversize). 22195 Tire Carrier Tie Bar. 40 22293 Vacuum Tank Suction Pipe. 22196 Tire Carrier Bracket (Right). 1.75 22295 Door Dove Tail (Male). 22198 Tire Carrier Bracket (Right). 1.90 22297 Windshield Rubber Channel. 1 22199 Tire Carrier Bracket (Left). 1.90 22298 Door Dove Tail (Female). 1 22200 Rear Fender (Right). 10.00 22299 Door Hinge (Lower). 1	22191	Rear Floor Carpet	8.00	22289	Piston Ring (.020" oversize)	.30
22196 Tire Carrier Bracket (Right) 1.75 22295 Door Dove Tail (Male) 22197 Tire Carrier Bracket (Left) 1.75 22296 Door Lock Lever Escutcheon 22198 Tire Carrier Bracket (Right) 1.90 22297 Windshield Rubber Channel 1 22199 Tire Carrier Bracket (Left) 1.90 22298 Door Dove Tail (Male) 1 22200 Door Dove Tail (Male) 22297 Windshield Rubber Channel 1 22200 Rear Fender (Right) 10.00 22299 Door Hinge (Lower)	22192	Door Lock Lever Handle Escutcheon.			Piston Ring (.030" oversize)	. 30
22197 Tire Carrier Bracket (Left) 1.75 22296 Door Lock Lever Escutcheon 22198 Tire Carrier Bracket (Right) 1.90 22297 Windshield Rubber Channel 1 22199 Tire Carrier Bracket (Left) 1.90 22298 Door Dove Tail (Female) 1 22200 Rear Fender (Right) 10.00 22299 Door Hinge (Lower) 1						.25
22198 Tire Carrier Bracket (Right) 1.90 22199 Tire Carrier Bracket (Left) 1.90 22200 Rear Fender (Right) 10.00 22299 Door Dove Tail (Female) 22299 Door Hinge (Lower)						.20
22199 Tire Carrier Bracket (Left) 1.90 22298 Door Dove Tail (Female) 22200 Rear Fender (Right) 10.00 22299 Door Hinge (Lower)		Tire Carrier Bracket (Right)			Windshield Rubber Channel	1.30
	22199	Tire Carrier Bracket (Left)	1.90	22298	Door Dove Tail (Female)	.40
WIND Mondon (Lott) ULUI 77300 LIOOF HINGE (LIDDET)		Rear Fender (Right)	10.00			. 55
22201 Real Fender (Left)	22201	Rear Fender (Left)	10.00	22300	Door Hinge (Upper)	. 55

DURANT		RUGBY		STAR	
Part No.	Part Name	Price	Part No.	Part Name	Price
22301	Deck Door Lock	\$0.50	22393	Piston Ring (Standard)	\$0.25
22304	Side Curtain Channel		22394	Piston Ring (.010" oversize)	.25
22305	Door Complete (Left)	18.50	22395	Piston Ring (.020" oversize)	.25
22306	Door Complete (Right)		22396	Piston Ring (.030" oversize)	.25
22309	Pedal Shaft Brace	.45	22397 22398	Piston Pin (Standard)	.45
22310 22311	Side Curtain Bumper (Front) Side Curtain Bumper (Rear)	.16	22399	Piston Pin (.005" oversize) Piston Pin (.010" oversize)	
22313	Door Window Lift Roller	.40	22400	Piston Pin Retaining Ring	
22314	Dummy Prop Iron Nut	.10	22401	Piston Pin Screw	.15
22316	Rear Axle Shaft Outer Bearing	4.95	22402	Piston Pin Screw Nut Lock	
22317	Dummy Prop Iron	4.00	22403	Special Hex. Nut	
22318 22319	Door Window Regulator Handle	1.60	22404	Connecting Rod Complete	4.75
22320	Door Window Reg. Roller and Pin Back Window Curtain	6.00		Note: Rod returned for new Bearing will be accepted at full credit less a charge of \$2.00	
22321	Frame Complete			list for a new Bearing.	
22323	Gas Tank Support	3.25	22405	Connecting Ded Diston Din Bushing	10
22324	Rear Spring Bracket	.80	22406	Connecting Rod Piston Pin Bushing Connecting Rod Bearing Shim	$.18 \\ .03$
22325	Rear Spring Horn (Left)	.75	22407	Connecting Rod Bolt	.20
22326	Rear Spring Horn (Right)	.75	22408	Connecting Rod Bolt Nut	.05
22327 22328	Step Hanger (Front) Step Hanger—Center and Rear (Right)	.75 .75	22409	Crankshaft	44.00
22329	Step Hanger—Center and Rear (Left).	.75	22410	Crankshaft Sprocket	2.25
22330	Front Spring		22411	Front Bearing (Upper)Use No.	
22333	Rear Spring	6.10	22412 22413	Intermediate Bearing (Upper) Use No. Rear Bearing (Upper)	
22335	Rear Spring Center Bolt	.17	22414	Front Bearing Cap	2.25
22336	Spring Bolt		22415	Intermediate Bearing Cap	2.25
22337 22338	Rear Spring Shackle		22416	Rear Bearing Cap	2.25
22339	Front Spring Bumper Retainer	.07		Note: Bearing Caps returned for rebabbitt-	LO TO
22340	Special Hex. Nut			ing will be accepted at full credit less a charge of \$1.25 list—Front \$1.25 list—Intermediate	
22341	Front Spring Bumper	.09	VIME:	and \$1.25 list—Rear for rebabbitting.	
22342	Front Axle "I" Beam		22417	Crankshaft Bearing Shim (Front and	ZEYEZ:
22343	Steering Knuckle (Left)		17411	Inter.)	.06
22344 22345	Steering Knuckle Thrust Washer	.25	22418	Crankshaft Bearing Shim (Rear)	.08
22346	Steering Knuckle King Pin Steering Knuckle Arm (Right)	$\frac{.50}{1.80}$	22419 22420	Crankshaft Thrust Shim	.02
22347	Steering Knuckle Arm (Left)	1.80	22421	Crankshaft Bearing Cap Stud	:10
22348	Front Axle Tie Rod	2.15	22422	Rear Bearing Filler Block	1.35
22351	Propeller Shaft	10.50	22423	Rear Bearing Filler Block Packing	.07
22352	Radiator Complete	38.50	22424	Rear Bearing Filler Block Gasket	.01
22353 22354	Radiator Shell	11.00	22425	Rear Bearing Filler Block Screw	.10
22355	Rear Spring	5.50	22426 22427	Crankshaft Thrust Plate	$1.50 \\ .11$
22357	Radiator and Dash Hood Rod Bracket	.07	22428	Crankshaft Starting JawUse No.	
22358	Radiator Inlet Hose	.20	22429	Fan Drive Pulley	2.50
22359	Cylinder Head	12.00	22430	Water Outlet Pipe	1.60
22360	Cylinder Head Gasket	.70	22431	Water Outlet Flange Gasket	.02
22362 22363	Cylinder Block		22432 22433	Water Outlet Flange Stud	.06
22364	Exhaust Valve		22433	Radiator Splash ApronCamshaft	1.70
22366	Valve Spring		22435	Camshaft Bushing (Front)	
22367	Valve Spring Cup	.06	22436	Camshaft Sprocket	2.90
22368	Valve Spring Seat	.12	22437	Camshaft Thrust Plug	.60
22370	Valve Chamber Cover	1.45	22438	Camshaft Thrust Plug Lock	.09
22371 22372	Valve Chamber Cover Gasket Valve Chamber Cover Screw	.12	22439	Oil Relief Valve Spring	.06
22375	Valve Tappet Guide	1.70	22440 22441	Oil Relief Valve Plug Timing Chain Case	$\frac{.10}{8.00}$
22376	Valve Tappet Guide Spring	.01	22442	Timing Chain Case Gasket	.15
22377	Valve Tappet Guide Screw Lock	.06	22443	Chain Case Stud	.06
22378	Valve Tappet Guide Plug	.10	22444	Chain Case to Crankcase Stud	.07
22379	Oil Level Gauge Rod	.80	22445	Chain Case Stud Nut	.05
22380 22381	Piston (Standard)	$\frac{2.10}{2.10}$	22446	Chain Case Cover Cosket	3.50
22382	Piston (.005 oversize)	2.10	22447 22448	Chain Case Cover Gasket	.07
22383	Piston (.010" oversize)	2.10	22449	Hood Complete	16.00
22384	Piston (.020" oversize)	2.10	22450	Timing Sprocket Drive Chain	8.20
22385	Piston (.023" oversize)	2.10	22451	Timing Chain Rocker Pin	.03
22386	Piston (.025" oversize)	2.10	22455	Fly Wheel with Steel Ring Gear	
22387 22388	Piston (.030" oversize) Piston (.035" oversize)		22456	Oil Pan Complete	5.25
22388 22389	Piston (1935" oversize)	$\frac{2.10}{.20}$	22457 22458	Oil Pan Gasket	24519
22390	Piston Ring (Plain) (.010" oversize)	.20	22459	Oil Pump Body	3.85
22391	Piston Ring (Plain) (.020"oversize)	.20	22460	Oil Pump Body Gasket	.04
22392	Piston Ring (Plain) (.030" oversize)	.20	22461	Oil Pump Body Stud	.06

art Io.	Part Name	Price	Part No.	Part Name	Pri
2462	Oil Pump Drive Gear (Driven)	\$1.95	22538	Emergency Brake Cross Shaft Support	
2463	Oil Pump Drive Shaft	1.60	22539	Hanger Pin Complete (Long)	5 (s.c) 3 co
2465	Oil Pump Cover	$.45 \\ .02$	$22540 \\ 22541$	Brake Cross Shaft Lever (Inner) Brake Cross Shaft Lever (Outer)	
2466 2467	Oil Pump Cover GasketOil Suction Pipe	.80	22542		
2468	Oil Delivery Pipe	7.00	22543	Emergency Brake Idler Lever	
2469	Chain Case Oil Tube		22544		11.0
2470	Water Pump Body	4.75	22545	Idler Lever Stud	F15
2471	Muffler	2.40	22546		1115
2472	Muffler Rear Bracket	. 55	22547	Brake Pedal Pull Rod	
2473	Head Lamp	4.50	22548		185
474	Muffler Tail Pipe		22549	Service Brake Rod (Center)	
475	Muffler Tail Pipe Clamp		22550	Emergency Brake Rod (Center)	
476	Muffler Tail Pipe Bracket	.10	22551	Service Brake Rod (Rear) Emergency Brake Rod (Rear)	USA EXE
477	Water Pump Rotor	. 50	22552 22554	Steering Gear Main Shaft	-
478	Water Pump Rotor Shaft		22555	Mast Jacket with Control Sector	2.
479	Water Pump Cover Gasket		22556	Control Tube Complete	1.
480 481	Coupling Clamp		22557	Control Tube Spring	
482	Fan Bracket		22558	Throttle Lever (Lower)	200
483	Water Pump and Generator Shaft		22559	Spark Lever (Lower)	
400	Coupling Hose	.80	22560	Mast Jacket Bracket (Lower)	
484	Carburetor Complete	20.00	22561	Mast Jacket Bracket (Upper)	1231
485	Carburetor Choke Complete	.80	22562	Steering Connecting Rod Complete	1
486	Carburetor Choke Guide Tube	.45	22563	Throttle Control Tube	
487	Motor Underpan (Left)	.80	22564	Accelerator Rod	425
488	Motor Underpan (Right)		22565	Spark Control Tube with Bracket	
489	Fly Wheel Underpan	. 90	22566	Front Fender (Right)	8
490	Intake and Exhaust Manifold		22567	Front Fender (Left)	8
491	Intake and Exhaust Manifold Gasket		22570	Side Apron (Right)	3
	Use No	. 24617	$22571 \\ 22572$	Side Apron (Left)	3 4
492	Exhaust Manifold Packing Gasket	21002	22573	Running Board (Right)	
	Use No		22574	Hood Sill (Right)	
494	Exhaust Pipe		22575	Hood Sill (Left)	1
497 498	Gasoline TankGasoline Tank Strap	65	22576	Hood Sill Spacer	200
499	Gasoline Tank to Vacuum Tank Pipe		22577	Head Lamp Bracket (Left)	
500	Carburetor Feed Pipe	50	22578	Head Lamp Bracket (Right)	
501	Vacuum Tank Suction PipeUse No	. 22293	22579	Head Lamp Tie Rod	
2502		. 5.00	22580	Tire Carrier Bracket (Right)	
503	Clutch Pedal Shaft	65	22581	Tire Carrier Bracket (Left)	
2504		85	22582	Tire Carrier Bracket (Right)	
505			22583	Tire Carrier Bracket (Left)	
506			22584	Tire Carrier Stud.	12
507	Clutch Pedal Return Spring		22585	Tire Carrier Tie Bar	
2508			22586 22588	Tire Carrier Tie Bar	
2509	Transmission Support—Front	$25 \\01$	22590	Lighting and Ignition Switch Steering Knuckle (Right)	
2510	Transmission Support—Front Shim.	01	22592	Battery Bracket	
2511 2512		3.25	22593	Battery Clamp Strap	
513	A A SECTION OF THE PROPERTY OF		22594	Battery Clamp Bolt	
2514			22595	Oil Pressure Gauge Pipe	
516		The second second	22599	Spark Plug Wire Support	
2517			22603	Universal Joint Hub with Cross (Long)	2
518		1.75	22605	Front Floor Mat	2
519		1.75	22606	Frame Complete	38
520	Piston (.015" oversize)	. 2.10	22607	Front Spring	3
2521	Shifter Fork	90	22609		38
522	Shifter Fork Screw	05	22612		
2523		. 4.50	22613		
2524			22614		
2525	Spline Shaft Thrust Washer	16	22615	Motor Underpan (Left)	
2526	Speedometer Gear Housing	. 2.00	22616 22617		
2527		. 1.00	22618		
2528			22619		
2529			22620		
2530		20	22621		23
2531 2532			22622		
2533		95	22623		
253 ⁴	Emergency Brake Cross Shaft	95	22624		
253	Cross Shaft Bearing Plate (Left)	45	22625	Running Board (Left)	
253		45	22626	Hood Complete	. 14
400			22627	Hood Sill (Left)	6.7

	Part No.	Part Name	Price	Part No.	Part Name	Price
	22628	Hood Sill (Right)	\$1.30	22737	Windshield Body Bracket (Left)	\$0.35
	22630	Radiator Name Plate	. 65	22738	Windshield Thumb Screw	.35
	22631 22632	Head Lamp Reflector	1.45	22739	Windshield Thumb Screw Washer	.06
	22633	Head Lamp Rim	1775	22740	Windshield Swing Arm.	
	22634	Head Lamp Focus Spring	.05	22741 22742	Windshield Swing Arm Pivot Screw Dummy Prop Iron (Right)	.11
	22635	Head Lamp Plug Connector	.40	22743	Dummy Prop Iron (Left)	$\frac{2.25}{2.25}$
	22636	Door Window Regulator Spring	. 65	22744	Door Glass (Front)	7.00
	22640	Ammeter	1.50	22745	Door Glass (Rear)	7.00
	22641	Oil Pressure Gauge	2.00	22746	Rear Quarter Glass	7.00
	22642 22644	Ammeter and Oil Gauge Glass Instrument Board Lamp Wire	.12	22747	Deck Door Lock Escutcheon	.35
	22645	Lighting and Ignition Switch	$\frac{.05}{2.00}$	22748	Door Hinge Upper (Right)	. 65
	22646	Universal Joint Hub with Cross (Short)	2 25	22749	Door Hinge Upper (Left)	. 65
	22647	Universal Joint Spacer Block	30	22750 22751	Door Hinge Lower (Right)	. 65 . 65
	22649	Universal Joint Ball (Rubber)	.13	22752	Outside Door Handle	.95
	22650 22651	Universal Joint Spacer	1.50	22753	Side Curtain Bumper (Rubber)	
	22652	Universal Joint Flange Bolt	.20	22755	Left Front Door Complete	13.00
	22653	Universal Joint Flange Bolt Nut Use No	23374	22756	Right Front Door Complete	13.00
	22654	Universal Joint Lock Plate	. 06	22757	Left Rear Door Complete	13.00
	22655	Carburetor Throttle Valve Lever	40	22758	Right Rear Door Complete	13.00
	22656	Carburetor Complete	15.00	22759 22760	Door Lock (Left)	
•	22659	Door Complete with Glass (Left)	ication	22761	Top Iron (Left)	. 55
3	22660	Upon Appl Door Complete with Glass (Right).	ication	22762	Top Iron (Right)	
		Upon Appl	ication	22763	Top Iron Support	. 50
	22661	Door Bumper (Rubber)	.10	22764	Windshield Bracket (Right)	
	22662	Door Glass	8.00	22765	Windshield Bracket (Left)	
	22663 22664	Rear Quarter Glass	7.00	22766 22767	Front Seat Cushion	9.00
	22665	Rear Seat Cushion	28.00	22768	Hood Hinge Reinforcement	.50
	22698	Seat Cushion	22.00	22769	Rear Wheel Brake Drum	2.50
	22699	Rear Floor Carpet	5 00	22770	Right Rear Door Upholstery	1.00
	22700	Front Floor Mat	2 15	22771	Left Rear Door Upholstery	1.00
	22701 22702	Back Window Curtain	6.00	22772	Front Floor Mat	2.15
	22703	Right Door Hinge (Upper)Left Door Hinge (Upper)	.60	22773 22774	Tonneau Floor Carpet	2.50
	22704	Right Door Hinge (Center)	.60	22775	Top Deck with Side Quarters	
	22705	Left Door Hinge (Center)	. 60	22776	Right Front Side Curtain	3.25
	22706	Right Door Hinge (Lower)	75	22777	Left Front Side Curtain	3.25
	22707	Left Door Hinge (Lower)	.75	22778	Right Center Side Curtain	3.25
	22708 22709	Right Door Lock	1.80	22779 22780	Left Center Side Curtain	$\frac{3.25}{2.50}$
	22710	Outside Door Handle	1.80	22781	Left Rear Side Curtain	2.50
	22711	Door Lock Handle Knob (Inside)	15	22782	Back Curtain Complete	5.00
	22712	Door Lock Handle (Inside)	. 40	22783	Windshield Complete	25.00
	22713	Locking Device Lever	.45	22784	Windshield Glass (Lower)	3.75
	22714 22715	Locking Device Lever Screw Locking Device Lever Escutcheon	.08	22786 22800	Windshield Side ArmCarburetor Plug Screw	1.85
	22716	Door Cylinder Lock	1.25	22801	Carburetor Plug Screw Gasket	.20 .05
	22717	Cylinder Lock Dowel with Set Screw.	.15	22802	Throttle Adjusting Screw Spring	.05
	22718	Door Lock Striker Plate	.40	22803	Carburetor Float Lever Pinion Screw	.10
	22719	Door Dove Tail (Male)	.20	22804	Carburetor Float Complete	1.00
	$22720 \\ 22721$	Cowl Ventilator Cover	. 95	22805	Carburetor Float Bowl Cover Carburetor Throttle Lever Spring	.20
	22722	Cowl Ventilator Lever	$\begin{array}{c} .25 \\ .10 \end{array}$	22806 22807	Carburetor Air Horn	
	22723	Cowl Ventilator Spring (Left)	.10	22808	Carburetor By-Pass Tube Assembly	
	22725	Door Comp. with Glass (Left)		22809	Carburetor Throttle Lever	. 50
	00500	Upon App	lication	22810	Carburetor Throttle Lever Stop	.30
-	22726	Door Comp. with Glass (Right)	22338	22811	Carburetor By-Pass Auxiliary Tube	.25
	22728	Upon App. Front Door Comp. with Glass (Right)	lication	22812 22813	Carburetor Nozzie	.65
- 8	0	Upon App.		22814	Carburetor Economizer Lever	.30
-	22729	Front Door Comp. with Glass (Left))	22815	Carburetor Economizer Cam	
	W. O.	Upon App	lication	22816	Carburetor Economizer Roller	.10
	22730	Rear Door Comp. with Glass (Right)	more.	22817	Carburetor Economizer Valve Cage	
	99791	Poor Door Comp. with Class (Lott)	lication	22818	Carburetor Economizer Retainer Nut.	The Real Property lies
	22731	Rear Door Comp. with Glass (Left) Upon App	lication	22819 22820	Carburetor Economizer Sleeve Carburetor Economizer Plunger	25
-	22733	Door Complete (Left)	18.50	22821	Carburetor Economizer Spring	.05
4	22734	Door Complete (Right)	18.50	22822	Cowl Lamp	1.30
	22735	Windshield Glass	8.00	22823	Rear Wheel Complete	10.00
	22736	Windshield Body Bracket (Right)	35	22824	Door Lock Lever Handle Escutcheon.	. 05

-1-at Change	
	0.0
	.0
haft Bolt	$.0^{1}$
	.6
	1.6
(R.D.)	. 5
	1.2
	1.5
	21.0
$\ldots \ldots 2$	
	5.0
tch Rod (R.D.).	. 2
D.)	1.0
	1.1
tchet (R.D.)	.2
.D.)	. !
	1.2
ł.D)	. 6
Din Complete	. (
Pin Complete	2.0
	2.0
	2.0
ulding (Right)	250
oulding (Left)	
	4.
	2.0
e Comp. (R.D.). e Comp. (R.D.).	Tr.
e Comp. (K.D.).	
R.D.)	
R.D.)	
er) (R.D.)	
od (R.D.)	
od (R.D.)	
ever (R.D.)	SP SS Na SS
Complete (R.D.)	6
	3.
	3.
e 1	
) 1	10.
	3 1 1 3
	35.
y) 1	10.
Rugby)	10
5)	40
o.) (35.
	3.
	5.
l	
l	
	1
	Contract of
ull Rod	
Shaft (R.D.)	1.
hort) (R.D.)	
	1.
Use No.	
	19
	9.
	9.
	1.
Rod	2.
	- 2.0
	161
	1.
	2.
	oss Shaft Lever oss Shaft Rear) od (Rear) ull Rod Shaft (R.D.) Short) (R.D.) ross Shaft (R.D.) Use No. 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

23063 Primary and Auxiliary Shoc Complete \$2.00 23064 Prof. Control Lever (Right)	Part No.	Part Name	Price	Part No.	Part Name	Price
20056 Proct Control Lever (Left)		Primary and Auxiliary Shoe Complete				
23065 Brake Cam Bracket Stud Nut. 10 23139 Tie Bar Reinforcement (Left). 20 23075 Special Cut Washer . 04 23140 Head Lamp Washer . 09 23085 Brake Cam Bracket Stud . 04 23140 Head Lamp Washer . 09 23086 Brake Cam Bracket Stop Bott . 11 23142 Sub Lamp Washer . 05 23086 Brake Cam Bracket Stop Bott . 11 23143 Dorn Lock (Laft). 1.55 23086 Brake Cam Bracket Stop Bott . 12 23085 Pront Brake Cam Lever . 85 23086 Pront Pin Washer (Outer) . 35 23086 Pront Pin Washer (Outer) . 35 23086 Pront Brake Lever Adjusting Serew . 35 23086 Pront Pin Washer (Outer) . 35 23086 Pront Brake Lever Adjusting Serew . 35 23086 Primary and Aux Brake Shoe Spring . 45 23086 Primary and Aux Brake Shoe Spring . 45 23097 Primary and Aux Brake Shoe Spring . 45 23097 Primary and Aux Brake Shoe Lining .		Front Control Lever (Right)				
Special Cut Washer						A
### Space Sp		Special Cut Washer				The state of the s
23066 Primary Shoe Operating Pin. 45 23142 Door Lock (Left) 55 23061 Brake Cam Bracket Stop Bolt. 11 23143 Seat Bracket. Complete (Right) 1.5 23062 Brake Cam Bracket Stop 11 23143 Seat Bracket. Complete (Right) 1.5 23063 Brake Cam Bracket Stop 11 23143 Seat Bracket. Complete (Right) 1.5 23064 Anchor Pin Washer (Outer) 35 23144 Dummy Prop Iron (Left) 2.5 23066 Rake Lever Adjusting Screw 35 23144 Dummy Prop Iron (Left) 2.2 23067 Secondary Shoe Take Up Cam 40 23149 Dummy Prop Iron (Left) 2.2 23068 Auxiliary Brake Shoe Pin 35 23160 Dummy Prop Iron (Left) 2.2 23069 Primary and Aux. Brake Shoe Spring 45 23150 Dummy Prop Iron (Left) 2.8 23070 Primary and Aux. Brake Shoe Ining 45 23150 Dummy Prop Iron (Left) 2.8 23071 Brake Cam Bracket Complete 1.20 23154 Dumby Prop Iron (Right) 2.8 23072 Brake Cam Bracket Complete 1.20 23154 Dumby Prop Iron (Right) 2.8 23073 Brake Cam Bracket Complete 1.25 23156 Spark Lever Lower (Magneto Ignition) 36 23074 Special Nut 0.5 23165 The Rod Adjustable Socket 1.0 23075 Rear Control Lever (Right) 1.25 23166 The Rod Adjustable Socket 1.0 23077 Brake Lining River 0.0 23167 The Rod Comnecting Rod Early Russel 23277 Secondary Shoe Spring 0.7 23167 The Rod Comnecting Rod Early Russel 23288 Rear Axle Housing (Right Half) 1.5 0.3 2317 The Rod and Conne Rod Spring Sast 0.7 23165 The Rod and Conne Rod Spring Sast 0.7 23165 The Rod and Conne Rod Spring Sast 0.7 23165 The Rod and Conne Rod Spring Sast 0.7 23165 The Rod and Conne Rod Spring Sast 0.7 23165 The Rod and Conne Rod Spring Sast 0.7 23165 The Rod and Conne Rod Spring Sast 0.7 23165 The Rod and Conne Rod Spring Sast 0.7 23165 The Rod and Conne Rod Spring Sast 0.7		Brake Cam Bracket Stud				The second second
23066 Brake Cam Bracket Stop Bolt		Primary Shoe Operating Pin				
23062 Secondary Shoe Anchor Pin	23060	Brake Cam Bracket Stop Bolt		23143	Door Lock (Left)	
23064 Anchor Pin Washer (Outer) 3.5 23146 Rear Motor Bearing Baffle 40 23066 Brake Lever Adjusting Screw 3.5 23147 Dummy Prop Iron (Left) 2. 2.5 23067 Secondary Shee Take Up Cam 40 23149 Dummy Prop Iron (Left) 2. 2.5 23068 Prairway and Aux Brake Shoe Pin 40 23149 Dummy Prop Iron (Left) 2. 2.5 23068 Prairway and Aux Brake Shoe Pin 45 23153 Dummy Prop Iron (Left) 2. 80 23068 Prairway and Aux Brake Shoe Pin 45 23153 Spark Lever Lower (Magnato Ignition) 2. 80 23074 Secondary Brake Shoe Lining 45 23165 Dummy Prop Iron (Right) 2. 80 23072 Brake Cam Bracket Complete 1. 20 23157 Secondary Brake Shoe Lining 45 23165 Spark Lever Loudshion. 4. 18 18 23072 Brake Cam Bracket Complete 1. 25 23165 Spark Lever Loudshion. 4. 18 18 23072 Brake Cam Bracket Complete 1. 25 23165 Tron Seat Cushion. 4. 50 23074 Special Nut 0.5 23169 Secondary Shoe Retaining Washer 0.5 23169 Secondary Shoe Spring 0.7 23167 Tie Rod Connecting Rod End Plug 23 23077 Brake Lining Rivet 0.0 23167 Tie Rod and Connecting Rod End Plug 23 23078 Secondary Shoe Spring 0.7 23167 Tie Rod and Connecting Rod End Plug 23 23078 Secondary Shoe Spring 0.7 23167 Tie Rod and Connecting Rod End Plug 23 23078 Secondary Shoe Spring 0.7 23167 Tie Rod and Connecting Rod Bearing 2.5 23083 Magneto Bell Crank 6.0 23177 Tie Rod and Connecting Rod Bearing 2.5 23083 Magneto Bell Crank 6.0 23176 Tie Rod and Connecting Rod Bearing 2.5 23083 Magneto Bell Crank 6.0 23176 Tie Rod and Connecting Rod Bearing 2.5 23083 Trive Oiler 1. 20 23187 Tie Rod and Connecting Rod Bearing 2.5 23083 Magneto Bell Crank 6.0 23176 Tie Rod and Connecting Rod Bearing 2.5 23083 Magneto Bell Crank 6.0 23176 Tie Rod and Connecting Rod Bearing 2.5 23083 Magneto Bell Crank 6.0 23176 Tie Rod and Connecting Rod Bearing 2.5 23083 M						
23066 Anchor Pin Washer (Outer)		Secondary Shoe Anchor Pin				
23066 Brake Lever Adjusting Screw 35 23148 Dummy Prop Iron (Right) 2. 80 23068 Auxiliary Brake Shoe Pin 40 23149 Dummy Prop Iron (Right) 2. 80 23069 Primary and Aux Brake Shoe Spring 45 23153 Brake Cam Bracket Complete 1. 20 23167 Primary and Aux Brake Shoe Lining 75 23167 Steering Gear Housing Bolt. 1. 32 23172 Brake Cam Bracket Complete 1. 20 23188 Pront Seat Cushion. 14. 00 23077 Brake Cam Bracket Complete 1. 25 23165 Primary and Aux Brake Shoe Lining 75 23167 Steering Gear Housing Bolt. 1. 10 23076 Rear Control Lever (Right) 1. 25 23165 Primary and Aux Brake Shoe Lining 1. 25 23167 Rear Control Lever (Right) 1. 25 23168 Rear Axle Housing (Right Half) 15. 00 23177 Rear Control Lever (Right) 1. 25 23168 Rear Axle Housing (Right Half) 15. 00 23177 Rear Control Lever (Right) 1. 20 23167 Rear Axle Housing (Right Half) 15. 00 23177 Rear Control Lever (Right) 1. 25 23168 Rear Axle Housing (Right Half) 15. 00 23177 Rear Control Lever (Right) 1. 20		Anches Die Wester (Oster)				
23068 Auxiliary Brake Shoe Fin. 35 23150 Dummy Prop Iron (Light). 2, 80 23068 Primary and Aux. Brake Shoe Spring. 45 23153 Spark Lever Lower (Magneto Ignition). 50 23070 Primary and Aux. Brake Shoe Lining. 45 23154 Spark Lever Lower (Magneto Ignition). 50 23071 Brake Cam Bracket Complete. 1.20 23157 Secondary Brake Shoe Lining. 75 23157 Secondary Brake Control Lever (Light). 1.25 23158 Secondary Shoe Spring. 75 23168 Secondary Shoe Spring. 76 23169 Secondary Shoe Spring. 76 23169 Secondary Shoe Spring. 77 23169 Tie Rod and Connecting Rod Spring. 76 23077 Brake Lining Rivet. 70 23169 Tie Rod and Connecting Rod Spring. 76 23081 Rear Axle Housing (Light Half). 15.00 23171 Tie Rod and Connecting Rod Spring. 76 23081 Rear Axle Housing (Light Half). 15.00 23171 Tie Rod and Connecting Rod Braing. 25 23088 Door Lock (Right Front). 1.80 23176 Tie Rod and Connecting Rod Braing. 25 23088 Door Lock (Right Front). 1.80 23176 Starter Strap (Lower) 1.80 23176 Starter Stra		Broke Lever Adjusting Serem				
23068 Auxiliary Brake Shoe Fin. 35 23169 23069 23069 23069 23069 23069 23069 23069 23069 23069 23069 23069 23069 23069 23069 23069 23069 23069 23071 23060 23072 23062 23062 23073 23062 23073 23074 23074 23074 23074 23074 23074 23074 23074 23074 23074 23074 23074 23074 23074 23074 23074 23075 23075 23075 23075 23076 230		Secondary Shoe Take IIn Cam				
23069 Primary and Aux Brake Shoe Spring 45 23167 23070 23070 23071 25000 23071 25000 23071 25000 23072 23073 25000 23074 25001 23074 23075 23075 23077 230		Auxiliary Brake Shoe Pin				
23070 Primary and Aux. Brake Shoe Lining. 75 23167 Secondary Brake Shoe Lining. 75 23167 Steering Gear Housing Blott. 1 1 1 1 1 1 1 1 1		Primary and Aux. Brake Shoe Spring.				. 50
23073 Front Axle Dust Cover. 55 23159 Front Seat Cushion. 14.00 23073 Front Axle Dust Cover. 55 23159 Secondary Special Nut. 0.5 23160 Secondary Special Nut. 0.5 23160 Secondary Shoe Rear Seat Cushion. 0.5 23160 Secondary Shoe Rear Seat Cushion. 0.5 23160 Tie Rod Clamp. 50 23077 Brake Lining Rivet. 0.2 23167 Tie Rod Connecting Rod End Plug. 25 23078 Secondary Shoe Spring. 0.7 23168 Tie Rod and Connecting Rod Spring. 0.5 23178 Secondary Shoe Spring. 0.7 23168 Tie Rod and Connecting Rod Spring. 0.5 23188 Tie Rod and Connecting Rod Bearing. 2.5 23184 Tie Rod Connecting Rod Spring. 0.5 23188 Tie Rod and Connecting Rod Spring. 0.5 23188 Tie Rod and Connecting Rod Spring. 0.5 23188 Tie Rod and Connecting Rod Bearing. 2.5 23184 Tie Rod and Connecting Rod Bearing Shim. 2.5 23184 Tie Rod and Connecting Rod Bearing Shim. 2.5 23184 Tie Rod and Connecting Rod Bearing Shim. 2.5 23		Primary and Aux. Brake Shoe Lining.	.45		Oil Delivery Pipe Flange Gasket Use No.	23428
23074 Special Nut. 0.5 23165 Secondary Shoe Retaining Washer 0.5 23076 Rear Control Lever (Light) 1.25 23165 Tie Rod Adjustable Socket 1.10 23077 Brake Lining Rivet 0.2 23167 Tie Rod Adjustable Socket 1.10 23078 Rear Control Lever (Right) 1.25 23166 Tie Rod Clamp 0.5 23078 Secondary Shoe Retaining Rod Spring 0.7 23168 Tie Rod and Connecting Rod Spring 0.6 23078 Secondary Shoe Spring 0.6 23177 Tie Rod and Connecting Rod Spring 0.6 23080 Rear Axle Housing (Right Haif) 15 0.0 23170 Tie Rod and Connecting Rod Spring 0.5 23082 Dive Oller 1.10 23171 Tie Rod and Conne Rod Spring Seat 0.2 23182 Rear Axle Housing (Left Haif) 1.5 0.0 23170 Tie Rod and Conne Rod Bearing 0.5 23082 Dive Oller 1.10 23171 Tie Rod and Conne Rod Bearing 0.5 23082 Dive Oller 1.10 23174 Starter Strap (Lower) 0.5 23182 Starter Strap (Lower) 0.5 23184 Rear Fender (Left) 0.6 23090 Door Lock (Left Rear) 1.30 23185 Rear Fender (Left) 0.6 23093 Head Lamp Lens 0.5 23184 Rear Fender (Left) 0.6 23093 Head Lamp Lens 0.5 23184 Rear Fender (Left) 0.6 23093 Head Lamp Lens 0.5 23184 Rear Fender (Left) 0.6 23093 Head Lamp Lens 0.5 23186 Sacondary Shoe Rear Brake Flange Plate (Left) 0.6 23186 Sacondary Shoe Rear Brake Flange Plate (Left) 0.6 23193 Gasoline Tank Strap 0.6 0.6 0.3 0.		Secondary Brake Shoe Lining				
23074 Special Nut		Brake Cam Bracket Complete				
23076 Rear Control Lever (Light). 1.25 23067 Rear Control Lever (Right). 1.25 23077 Brake Lining Rivet. 02 23077 Brake Lining Rivet. 02 23078 Secondary Shoe Spring. 07 23168 Tie Rod Connecting Rod End Plug. 25 23078 Secondary Shoe Spring. 07 23168 Tie Rod and Connecting Rod Spring. 05 23080 Rear Axle Housing (Right Half). 15.00 23177 Tie Rod and Connecting Rod Spring. 25 23081 Rear Axle Housing (Right Half). 15.00 23171 Tie Rod and Connecting Rod Bearing. 25 23082 Drive Oiler. 10 23082 Drive Oiler. 10 23083 Magneto Bell Crank. 60 23175 Tie Rod and Conne Rod Bearing. 25 23084 Transmission Case Cover (R.D.) 3.00 23085 Door Lock (Right Front). 1.80 23086 Door Lock (Right Front). 1.80 23189 Door Lock (Right Rear and Lett Front) 1.80 23189 Transmission Bracket. 1.85 23089 Transmission Bracket. 1.85 23090 Door Lock (Right Rear and Lett Front) 1.80 23190 Door Lock (Right Rear and Lett Front) 1.80 23190 Door Lock (Right Rear and Lett Front) 1.80 23190 Door Lock (Right Rear and Lett Front) 1.80 23191 Rear Render (Right) 6.6 23090 Door Lock (Right Rear and Lett Front) 2.18 23192 Steering Gear Bracket (R.D.) 1.20 23092 Steering Gear Bracket (R.D.) 1.20 23093 Head Lamp Lens. 50 23093 Head Lamp Lens. 50 23094 Secondary Shoe Spring Anchor 09 23095 Primary Operating Pin Spacer. 05 23096 Front Brake Flange Plate (Right) 1.60 23097 Front Brake Flange Plate (Right) 1.60 23098 Rear Brake Flange Plate (Right) 1.60 23099 Rear Brake Flange Plate (Right) 1.60 23090 Rear Brake Flange Plate (Right) 1.60 2310 Head Lamp Rim Lock Screw Use No. 26402 2310 Head Lamp Rim Lock Screw Use No. 26402 2310 Rear Brake Flange Plate (Right) 1.40 2310 Rear Brake Flange Plate (Righ		Special Nut				
23076 Rear Control Lever (Right) 1.25 23166 Tie Rod Clamp. 50 23077 Secondary Shoe Spring 07 23168 Tie Rod and Connecting Rod End Plug 25 23078 Secondary Shoe Spring 07 23168 Tie Rod and Connecting Rod End Plug 25 23079 Special Nut. 07 23168 Tie Rod and Connecting Rod Spring 08 23080 Rear Axle Housing (Right Half) 15 00 23170 Tie Rod and Conn. Rod Spring 56 23081 Rear Axle Housing (Left Half) 15 00 23171 Tie Rod and Conn. Rod Bearing S. 15 23083 Magneto Bell Crank 06 23174 Starter Strap (Lower) 5 00 23083 Magneto Bell Crank 06 23176 Passenger Seat Complete 27 60 23084 Transmission Case Cover (R.D.) 3 00 23176 Passenger Seat Complete 27 60 23085 Door Lock (Right Front) 1 80 23180 Outside Door Handle Key 25 23088 Transmission Packet 45 23181 Rear Fender (Left) 6 25 23099 Frame Front Cross Member 3 75 23182 Rear Fender (Left) 6 25 23099 Steering Gear Bracket (R.D.) 1 20 23184 Spark Control Tube Complete Use No. 23099 Steering Gear Bracket (R.D.) 1 20 23186 Transmisch Complete Use No. 23099 Steering Gear Bracket (R.D.) 20 23186 Transmisch Control Tube Complete Use No. 23099 Frame Front Cross Member 09 23187 Transmisch Control Tube Complete Use No. 23099 Steering Gear Bracket (R.D.) 20 23186 Transmisch Control Tube Complete Use No. 23099 Steering Gear Bracket (R.D.) 20 23186 Transmisch Control Tube Complete Use No. 23099 Steering Gear Bracket (R.D.) 20 23186 Transmisch Control Tube Complete Use No. 23099 Tra		Rear Control Lever (Left)				
23077 Brake Lining Rivet		Rear Control Lever (Right)				
23079 Secondary Shoe Spring 07 23168 The Kod and Connecting Rod Spring 09 23079 Special Nut. 07 23169 Tie Rod and Connex Kod Spring Seat 04 23080 Rear Axle Housing (Left Half) 15 00 23171 Tie Rod and Connecting Rod Bearing 25 23083 Rear Axle Housing (Left Half) 15 00 23171 Tie Rod and Connecting Rod Bearing 25 23083 Tire Rod and Connecting Rod Bearing 25 23083 Transmission Case Cover (R.D.) 3 00 23175 Triver's Seat Complete 27 50 23085 Door Lock (Right Front) 1 30 23179 Dustide Door Handle Key 1 85 23086 Door Lock (Right Rear and Left Front) 1 30 23180 Dustide Door Handle Key 1 85 23088 Transmission Bracket 45 23181 Rear Fender (Left) 6 6 25 23099 Frame Front Cross Member 3 75 23182 Rear Fender (Left) 6 6 23093 Each Inguistry 5 23184 Accelerator Rod 20 23093 Each Inguistry 5 23184 Accelerator Rod 20 23094 Secondary Shoe Spring Anchor 09 23185 Thortothe Control Tube Complete 60 23095 Primary Operating Pin Spacer 05 23187 Rear Spring 65 23187 Rear Spring 75 23194 Reactine Tank Strap 76 23194 23294		Brake Lining Rivet		700 TO 100 TO 10	Tie Rod Connecting Rod End Plug	.25
23099 Special Nut.		Secondary Shoe Spring	.07	23168	Tie Rod and Connecting Rod Spring.	.05
23082 Rear Axle Housing (Left Half) 15.00 23082 Dive Oller 10 23082 Dive Oller 10 23083 Magneto Bell Crank 60 23175 Driver's Seat Complete 27.50 23084 Transmission Case Cover (R.D.) 3.00 23176 Passenger Seat Complete 27.50 23085 Door Lock (Right Front) 1.80 23179 Outside Door Handle, with Key 1.85 23088 Door Lock (Right Rear and Left Front) 1.80 23180 Outside Door Handle Key 2.85 23088 Transmission Bracket 3.75 23182 Rear Fender (Right) 6.25 23089 Door Lock (Left Rear) 1.80 23183 Spark Control Tube Complete Use No. 23041 23091 Steering Gear Bracket (R.D.) 1.20 23185 Throttle Control Tube Complete Use No. 23092 Steering Gear Bracket (R.D.) 1.20 23185 Vacuum Tank Feed Pipe 60 23093 Head Lamp Lens 50 23186 Vacuum Tank Feed Pipe 60 23093 Forth Brake Flange Plate (Right) 1.60 23189 Gasoline Tank Feed Pipe 60 23093 Forth Brake Flange Plate (Right) 1.40 23195 Gasoline Tank Strap 76 23100 Head Lamp Rim Lug 10 23194 Gasoline Tank Strap 76 23101 Head Lamp Rim Lug 10 23196 Gasoline Tank Strap 76 23101 Head Lamp Rim Lug 10 23196 Gasoline Tank Strap 76 23101 Head Lamp Rim Lug 10 23196 Gasoline Tank Strap 76 23101 Rear Yellow Glass 10 10 23196 Gasoline Tank Strap 76 23101 Rear Floor Carpet 60 23195 Gasoline Tank Strap 76 23101 Rear Floor Carpet 61 62 23196 Gasoline Tank Strap 76 23101 Rear Floor Carpet 62 60 23117 External Brake Road Lining (Short) 75 23121 External Brake Cam Lever Adjuster 1.10 23211 External Brake Cam Lever Adjuster 1.15 23212 External Brake Band Lining (Short) 75 23123 External Brake Band Lining (Short) 75 23123 External Brake Band Lining (Short) 75 23123 External Brake Band Lining (Short) 76 23221 Door Complete with Glass Upon Application 23221 Internal Brake Cam Lever Adjuster 1.15 23212 Carburetor Choke Housing		Special Nut	.07			
23082 Drive Oiler		Rear Axle Housing (Right Half)	15.00			
23083 Magneto Bell Crank 60 23175 Driver's Seat Complete 27.50 23084 Transmission Case Cover (R.D.) 1.80 23176 Passenger Seat Complete 27.50 23085 Door Lock (Right Rear and Left Front) 1.80 23180 Outside Door Handle Key 2.25 23088 Transmission Bracket 45 23181 Rear Fender (Left) 6.25 23099 Door Lock (Left Rear) 1.80 23183 Spark Control Tube Complete Use No. 23041 23091 Steering Gear Bracket (R.D.) 1.20 23183 Accelerator Rod 20 23093 Head Lamp Lens 50 23186 Vacuum Tank Feed Pipe 66 23094 Secondary Shoe Spring Anchor 09 23187 Rear Spring 8.50 23095 Friont Brake Flange Plate (Right) 1.60 23189 Gasoline Tank 8.00 23095 Front Brake Flange Plate (Left) 1.60 23189 Gasoline Tank Strap 2.25 23098 Rear Brake Flange Plate (Left) 1.40 23196 Gasoline Tank Strap <td></td> <td>Rear Axle Housing (Left Half)</td> <td>15.00</td> <td></td> <td></td> <td></td>		Rear Axle Housing (Left Half)	15.00			
23085 Door Lock (Right Front) 1.80 23176 Passenger Seat Complete 27.56 23085 Door Lock (Right Front) 1.80 23179 Outside Door Handle, with Key 1.85 23088 Transmission Bracket 4.5 23181 Rear Fender (Left) 6.25 23089 Frame Front Cross Member 3.75 23181 Rear Fender (Left) 6.25 23090 Door Lock (Left Rear) 1.80 23183 Spark Control Tube Complete Use No. 23041 23091 Steering Gear Bracket (R.D.) 1.25 23184 Accelerator Rod 1.00 23093 Head Lamp Lens 50 23185 Throttle Control Tube Complete Use No. 23041 23093 Secondary Shoe Spring Anchor 0.9 23187 Kear Spring 8.50 23095 Front Brake Flange Plate (Left) 1.60 23193 Rear Spring (Dip 3.00 23093 Rear Brake Flange Plate (Left) 1.60 23193 Rear Spring (Dip 3.00 23093 Rear Brake Flange Plate (Left) 1.40 23194 Gasoline Tank Strap Spool 3.5 23104 Rear Spring Min Leg 23194 Gasoline Tank Strap Spool 3.5 23104 Rear Spring Min Leg 23194 Gasoline Tank Strap Door Complete, with Glass Upon Application 23194 Gasoline Tank Strap 7.5 23104 Rear Window Glass 6.00 23194 Gasoline Tank Strap 7.5 23104 Rear Window Glass 6.00 23194 Gasoline Tank Strap 7.5 23104 Rear Window Glass 6.00 23194 Gasoline Tank Strap 7.5 23104 Rear Window Glass 7.5 23105 Door Complete, with Glass Upon Application 23204 Tire Carrier Bracket (Left) 1.35 23104 Door Complete, with Glass Upon Application 23204 Tire Carrier Bracket (Left) 1.35 23104 Door Complete, with Glass Upon Application 23204 Tire Carrier Bracket (Left) 1.35 23104 Door Complete, with Glass Upon Application 23204 Tire Carrier Bracket (Left) 1.35 23104 Door Lock (Left) 2.5 23114 Dome Lamp Glass Retaining Ring 1.6 23115 Dome Lamp Glass Retaining Ring 1.6 23116 External Brake Band (Lining (Short) 7.5 23121 Internal Brake Cam Lever Adjuster 1.5 23212 Carburetor Choke Complete 1.00 23121 Internal		Magnete Pell Creak	.10		Driver's Seet Complete	27 50
23085 Door Lock (Right Front) 1.80 23179 Outside Door Handle, with Key 2.85 23088 Tansmission Bracket 4.5 23181 Rear Fender (Left) 6.25 23089 Frame Front Cross Member 3.75 23182 Rear Fender (Left) 6.25 23090 Door Lock (Left Rear) 1.80 23183 Rear Fender (Right) 6.25 23193 Steering Gear Bracket 1.25 23184 Accelerator Rod 200 23093 Steering Gear Bracket (R.D.) 1.20 23185 Throttle Control Tube Complete Use No. 23041 23093 Steering Gear Bracket (R.D.) 1.20 23185 Throttle Control Tube Complete 60 23093 Head Lamp Lens 50 23186 Vacuum Tank Feed Pipe 65 63 63 63 63 63 63 63					Passenger Seat Complete	27 50
23086 Door Lock (Right Rear and Left Front) 1.80 23188 23183 23184 23184 23184 23184 23184 23184 23184 23184 23185		Door Lock (Right Front)	1 80			
23088 Transmission Bracket 45 23181 Rear Fender (Left) 6.25 23099 Door Lock (Left Rear) 1.80 23183 Spark Control Tube Complete Use No. 23041 Accelerator Rod		Door Lock (Right Rear and Left Front)	1.80		Outside Door Handle Key	.25
23089 Frame Front Cross Member 3.75 23089 Frame Front Cross Member 1.80 23183 Spark Control Tube Complete Use No. 23091 Steering Gear Bracket (R.D.) 1.20 23185 Spark Control Tube Complete Use No. 23092 Steering Gear Bracket (R.D.) 1.20 23185 Throttle Complete Use No. 23093 Head Lamp Lens 50 23186 Throttle Complete Use No. 23093 Head Lamp Lens 50 23186 Throttle Complete Use No. 23094 Secondary Shoe Spring Anchor 0.99 23187 Rear Spring Clip 8.50 23095 Front Brake Flange Plate (Left) 1.60 23193 Rear Spring Clip 8.50 23097 Front Brake Flange Plate (Left) 1.60 23193 Robe Rail Complete 2.25 23098 Rear Brake Flange Plate (Left) 1.40 23195 Gasoline Tank Strap Spool 35 23100 Head Lamp Rim Lug 10 23196 Gasoline Tank Strap 75 23100 Head Lamp Rim Lug 10 23196 Gasoline Tank Strap 75 23101 Head Lamp Rim Lock Screw Use No. 26402 23197 Gasoline Tank Strap 75 23104 Rear Window Glass 3.75 23196 Gasoline Tank Strap 75 23105 Gasoline Tank Strap 75 23106 Door Complete, with Glass Upon Application 23109 Gasoline Tank Support Complete 3.85 23109 23101		Transmission Bracket	.45		Rear Fender (Left)	6.25
23091 Steering Gear Bracket (R.D.) 1.20 23185 Steering Gear Bracket (R.D.) 1.20 23187 Steering Gear Bracket (R.D.) 1.20 23187 Steering Gear Bracket (R.D.) 1.20 23195 Steering Gear Bracket (R.B.) 1.20 23195 Steering Bracket (L.B.) 1.20 23195 Steering B		Frame Front Cross Member	3.75		Rear Fender (Right)	6.25
23092 Steering Gear Bracket (R.D.) 1.20 23185 23094 Secondary Shoe Spring Anchor 0.9 23186 Vacuum Tank Feed Pipe 65 65 23094 Secondary Shoe Spring Anchor 0.9 23187 Rear Spring C. 8.50 23095 Primary Operating Pin Spacer 0.5 23188 Rear Spring Clip 8.50 23096 Front Brake Flange Plate (Right) 1.60 23189 Gasoline Tank Complete 2.25 23098 Rear Brake Flange Plate (Left) 1.40 23194 Gasoline Tank Strap Spool 35 23099 Rear Brake Flange Plate (Left) 1.40 23195 Gasoline Tank Strap Spool 35 23101 Head Lamp Rim Lug 10 23196 Gasoline Tank Strap Spool 35 23101 Head Lamp Rim Luck Screw Use No. 26402 23196 Gasoline Tank Strap 75 23101 Head Lamp Rim Lock Screw Use No. 26402 23196 Gasoline Tank Complete 8.00 23104 Rear Guarter Glass 10 23196 Gasoline Tank Complete 8.00 23104 Rear Guarter Glass 10 23196 Gasoline Tank Complete 8.00 23105 Door Complete, with Glass 10 23196 Gasoline Tank Complete 8.00 23106 Gasoline Tank Strap 75 23106 Gasoline Tank Complete 8.00 23196 Gasoline Tank Complete 8.00		Door Lock (Left Rear)				
23093 Head Lamp Lens. 50 23186 Vacuum Tank Feed Pipe. 65 23094 Secondary Shoe Spring Anchor 09 23187 Rear Spring. 8.60 23095 Primary Operating Pin Spacer 05 23188 Rear Spring. 8.00 23096 Front Brake Flange Plate (Right) 1.60 23189 Gasoline Tank. 8.00 23097 Rear Brake Flange Plate (Right) 1.40 23194 Gasoline Tank Strap Spool. 3.5 23109 Rear Brake Flange Plate (Left) 1.40 23195 Gasoline Tank Strap Spool. 3.5 23101 Head Lamp Rim Lug. 10 23195 Gasoline Tank Strap Spool. 3.6 23101 Head Lamp Rim Lock Screw Use No. 26402 23197 Gasoline Tank Complete. 8.00 23104 Rear Window Glass. 6.00 23196 Gasoline Tank Complete. 8.00 23105 Door Complete, with Glass Upon Application 23206 Tice Carrier Bracket (Right). 1.85 23106 Door Complete, with Glass Upon Application 23201 Tice Carrier Bracket (Right). </td <td></td> <td>Steering Gear Bracket</td> <td></td> <td></td> <td></td> <td>And the later of t</td>		Steering Gear Bracket				And the later of t
23094 Secondary Shoe Spring Anchor .09 23095 Primary Operating Pin Spacer .05 23188 Rear Spring Clip .80 23096 Front Brake Flange Plate (Right) 1.60 23097 Front Brake Flange Plate (Left) 1.60 23193 Robe Rail Complete 2.25 23098 Rear Brake Flange Plate (Left) 1.40 23193 Robe Rail Complete 2.25 23100 Head Lamp Rim Lug 1.0 23195 Gasoline Tank Strap .75 23101 Head Lamp Rim Lock Screw Use No. 26402 23197 Gasoline Tank Strap .75 23104 Rear Window Glass 6.00 23197 Gasoline Tank Complete 8.00 23105 Door Complete, with Glass Upon Application 23199 Gasoline Tank Strap .75 23106 Door Complete, with Glass Upon Application 23107 Tire Carrier Bracket (Right) 1.85 23108 Door Complete, with Glass Upon Application 23200 Tire Carrier Bracket (Left) 1.35 23108 Rear Flance Flance 2310 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23200 Tire Carrier Bracket (Left) 1.35 23108 Door Lock (Right) 23200 Tire Carrier Bracket (Left) 1.35 23110 Rear Floor Carpet 5.00 23200 T		Head Lamp Long				
23095 Primary Operating Pin Spacer 0.5 23096 Pront Brake Flange Plate (Right) 1.60 23097 Front Brake Flange Plate (Left) 1.60 23193 Rear Brake Flange Plate (Left) 1.40 23194 Gasoline Tank Strap 5.5 23098 Rear Brake Flange Plate (Right) 1.40 23195 Gasoline Tank Strap 5.5 23100 Head Lamp Rim Lug 1.0 23196 Gasoline Tank Strap 7.5 23101 Head Lamp Rim Lock Screw Use No. 26402 23197 Gasoline Tank Strap 7.5 23104 Rear Window Glass 6.00 23195 Gasoline Tank Complete 8.00 23105 Door Complete, with Glass Upon Application 23196 Gasoline Tank Complete 8.00 23106 Door Complete, with Glass Upon Application 23200 Tire Carrier Bracket (Right) 1.35 23106 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23202 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23202 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23202 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23202 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23204 Door Lock (Right) 3.00 23111 Rear Floor Carpet 5.00 23205 Door Lock (Right) 3.00 23112 Back Window Curtain 6.25 23208 Vanity Case 3.25 23114 Dome Light Reflector 1.10 23118 External Brake Toggle Lever (Right) 1.15 23211 Carburetor Choke Knob Complete 40 23116 External Brake Toggle Lever (Right) 25 23216 Carburetor Choke Gomplete 40 23112 External Brake Band Lining (Short) 75 23212 Carburetor Choke Housing Complete 23214 Carburetor Choke Housing Complete 23214 Carburetor Choke Housing Complete 23216		Secondary Shoe Spring Anchor				
23096 Front Brake Flange Plate (Right) 1.60 23193 Gasoline Tank 8.00 23098 Rear Brake Flange Plate (Right) 1.40 23193 Robe Rail Complete 2.25 23098 Rear Brake Flange Plate (Right) 1.40 23194 Gasoline Tank Strap Spool .35 23100 Head Lamp Rim Lock Screw Use No. 26402 23195 Gasoline Tank Strap .75 23101 Head Lamp Rim Lock Screw Use No. 26402 23197 Gasoline Tank Strap .75 23103 Rear Quarter Glass 3.75 23198 Gasoline Tank Complete 8.00 23104 Rear Window Glass 6.00 23199 Gasoline Tank Complete 8.00 23105 Door Complete, with Glass Upon Application 23109 Gasoline Tank Strap .75 23106 Door Complete, with Glass Upon Application 23107 Tire Carrier Bracket (Right) 1.35 23107 Front Seat Cushion 26.00 23202 Tire Carrier Bracket (Right) 1.35 23107 Rear Seat Cushion 30.00 23204 Tire C		Primary Operating Pin Spacer				
23098 Rear Brake Flange Plate (Right). 1.40 23194 Gasoline Tank Strap Spool. .35 23090 Head Lamp Rim Lug. .10 23195 Gasoline Tank Strap. .75 23101 Head Lamp Rim Lock Screw Use No. 26402 23197 Gasoline Tank Strap. .75 23104 Rear Window Glass. 6.00 23197 Gasoline Tank Complete. 8.00 23105 Door Complete, with Glass. Upon Application 23199 Gasoline Tank Strap. .75 23106 Door Complete, with Glass. Upon Application 23200 Tire Carrier Bracket (Right). 1.35 23107 Door Complete, with Glass. Upon Application 23201 Tire Carrier Bracket (Right). 1.35 23108 Door Complete, with Glass. Upon Application 23202 Tire Carrier Bracket (Right). 1.35 23108 Pront Seat Cushion. 30.00 23202 Tire Carrier Bracket (Left). 1.35 23110 Rear Seat Cushion. 30.00 23203 Tire Carrier Bracket (Left). 1.35 23111 Back Window Curtain. 6.25 2300 Tool Lock (Right). 3.00 23112 Back Window Curtain. 6.25 23208 Vanity Case. 5.00 23113 Dome Light Reflector. 1.10 23201 Carburetor Choke Konob Complete. 1.0 23116		Front Brake Flange Plate (Right)				
23199 Rear Brake Flange Plate (Left) 1.40 23196 Gasoline Tank Strap 7.5 23101 Head Lamp Rim Lug 1.0 23196 Gasoline Tank Strap 7.5 7.5 23103 Rear Quarter Glass 3.75 23198 Gasoline Tank Complete 8.00 23104 Rear Window Glass 6.00 23198 Gasoline Tank Cap, with Gauge 1.50 23196 Door Complete, with Glass Upon Application 23200 Tire Carrier Bracket (Right) 1.35 23106 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Right) 1.35 23108 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Right) 1.35 23108 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Right) 1.35 23109 Front Seat Cushion 26.00 23204 Door Lock (Right) 3.00 23111 Rear Floor Carpet 5.00 23205 Door Lock (Right) 3.00 23112 Back Window Curtain 6.25 23208 Vanity Case 5.00 23113 Dome Light Glass 25 23208 Vanity Case 5.00 23114 Dome Lamp Glass Retaining Ring 16 23211 Carburetor Choke Complete 40 23116 External Brake Toggle Lever (Right) 1.15 23211 External Brake Toggle Lever (Right) 2.5 23210 Carburetor Choke Complete 40 23116 Carburetor Choke Housing Complete 25 23219 Carburetor Choke Housing Complete 25 23219 Carburetor Choke Housing Complete 25 23210 Carburetor Choke Housing Complete 25 23211 Carburetor Choke Housing Complete 25 23212 Carburetor Choke Housing Complete 25 23213 Carburetor Choke Housing Complete 23212 Carburetor Choke Housing Complete 23213 Carburetor Choke Housing Complete 23214		Front Brake Flange Plate (Left)				
23100 Head Lamp Rim Lug.		Rear Brake Flange Plate (Right)	1.40			
23103 Rear Quarter Glass 3.75 23198 Gasoline Tank Cap, with Gauge 1.50 23104 Rear Window Glass 6.00 23105 Door Complete, with Glass Upon Application 23200 Tire Carrier Bracket (Right) 1.35 23107 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23202 Tire Carrier Bracket (Left) 1.35 23109 Front Seat Cushion 26.00 23203 Tire Carrier Bracket (Left) 1.35 23109 Front Seat Cushion 26.00 23204 Door Lock (Right) 3.00 23111 Rear Floor Carpet 5.00 23206 Rear Quarter Window Curtain 5.00 23112 Back Window Curtain 6.25 23208 Vanity Case 5.00 23114 Dome Light Glass 25 23209 Smoking Case 3.25 23211 Carburetor Choke Complete 1.00 23115 External Brake Toggle Lever (Right) 1.15 23211 Carburetor Choke Guide Tube 1.5 23211 Carburetor Choke Guide Tube 1.5 23212 Carburetor Choke Housing Complete 2.5 23214 Carburetor Choke Housing Complete 2.5 23215 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23215 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Co		Head Lamp Rim Lug	1.40			
23103 Rear Quarter Glass 3.75 23198 Gasoline Tank Cap, with Gauge 1.50 23104 Rear Window Glass 6.00 23105 Door Complete, with Glass Upon Application 23200 Tire Carrier Bracket (Right) 1.35 23107 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23202 Tire Carrier Bracket (Left) 1.35 23109 Front Seat Cushion 26.00 23203 Tire Carrier Bracket (Left) 1.35 23109 Front Seat Cushion 26.00 23204 Door Lock (Right) 3.00 23111 Rear Floor Carpet 5.00 23206 Rear Quarter Window Curtain 5.00 23112 Back Window Curtain 6.25 23208 Vanity Case 5.00 23114 Dome Light Glass 25 23209 Smoking Case 3.25 23211 Carburetor Choke Complete 1.00 23115 External Brake Toggle Lever (Right) 1.15 23211 Carburetor Choke Guide Tube 1.5 23211 Carburetor Choke Guide Tube 1.5 23212 Carburetor Choke Housing Complete 2.5 23214 Carburetor Choke Housing Complete 2.5 23215 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23215 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Complete 2.5 23216 Carburetor Choke Housing Complete 2.5 23217 Carburetor Choke Housing Co	2 10 10 10 10 10 10 10 10 10 10 10 10 10	Head Lamp Rim Lock Screw Use No	26402			
23104 Rear Window Glass 6 .00 23105 Door Complete, with Glass Upon Application 23106 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Right) 1.35 23108 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Left) 1.35 23108 Door Complete, with Glass Upon Application 23202 Tire Carrier Bracket (Left) 1.35 23108 Door Lock (Right) 1.35 23204 Door Lock (Right) 1.35 23204 Door Lock (Right) 1.35 23205 Door Lock (Right) 1.35 23205 Door Lock (Right) 1.35 23205 Door Lock (Right) 23206 Rear Quarter Window Curtain 5.00 23206 Rear Quarter Window Curtain 5.00 23206 Rear Quarter Window Curtain 5.00 23208 Smoking Case 3.25 23209 Smoking Case 3.25 23210 Carburetor Choke Knob Complete 4.00 23211 Carburetor Choke Wine 3.2211 Carburetor Choke Wine 3.2211 Carburetor Choke Wine 3.2211 Carburetor Choke Wine 3.2211 Carbur		Rear Quarter Glass	3.75			
23105 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Right). 1.35 23108 Door Complete, with Glass Upon Application 23201 Tire Carrier Bracket (Right). 1.35 23108 Door Complete, with Glass Upon Application 23202 Tire Carrier Bracket (Right). 1.35 23109 Front Seat Cushion. 26.00 23204 Door Lock (Right). 3.00 23110 Rear Seat Cushion. 30.00 23205 Door Lock (Left). 3.00 23111 Rear Floor Carpet. 5.00 23206 Rear Quarter Window Curtain. 5.00 23208 Vanity Case. 5.00 23209 Vanity Case. 5.00 23211 Dome Light Glass. 25 23209 Smoking Case. 3.25 23211 Dome Light Reflector. 1.10 23211 Carburetor Choke Knob Complete. 40 23118 External Brake Toggle Lever (Right). 1.15 23212 Carburetor Choke Guide Tube. 1.5 23119 External Brake Sand Lining (Short). 75 23123 External Brake Band Lining (Short). 75 23123 External Brake Cam Lever Adjuster. 1.15 23216 Carburetor Choke Lock Nut. 0.05 0.00 0	23104	Rear Window Glass	6.00			
23107 Door Complete, with Glass Upon Application 23108 Door Complete, with Glass Upon Application 23109 Front Seat Cushion 26.00 23204 Door Lock (Right) 1.35 23109 Front Seat Cushion 26.00 23204 Door Lock (Right) 3.00 23110 Rear Seat Cushion 30.00 23205 Door Lock (Left) 3.00 23112 Back Window Curtain 6.25 23208 Rear Quarter Window Curtain 5.00 23113 Dome Light Glass 25 23209 Smoking Case 5.00 23114 Dome Light Reflector 1.10 23211 Carburetor Choke Complete 1.00 23116 External Brake Toggle Lever (Right) 1.15 23212 Carburetor Choke Guide Tube 1.5 23117 External Brake Toggle Lever (Left) 1.15 23212 Carburetor Choke Housing Complete 25 23119 External Brake Cam Lever Adjuster 1.15 23212 Carburetor Choke Housing Complete 25 23120 Internal Brake Cam Lever Adjuster 1.15 23217 Door Complete with Glass (Left) Upon Application 23122 External Brake Band Lining (Short) 75 23212 External Brake Band Lining (Short) 75 23212 External Brake Band (Light) 4.00 23223 Dummy Prop Iron Spacer (Lower) 20 23134 Rear Axle Housing (Right Half) 17.00 23224 Dummy Prop Iron Spacer (Upper) 11		Door Complete, with Glass. Upon Appl	lication			
23108 Door Complete, with Glass Upon Application 23109 Front Seat Cushion 26.00 23101 Rear Seat Cushion 30.00 23205 Door Lock (Right) 3.00 23111 Rear Floor Carpet 5.00 23206 Rear Quarter Window Curtain 5.00 23112 Back Window Curtain 6.25 23208 Vanity Case 5.00 23113 Dome Light Glass 25 23209 Smoking Case 3.25 23209 Smoking Case 3.25 23214 Dome Lamp Glass Retaining Ring 16 23211 Carburetor Choke Complete 40 23115 Dome Light Reflector 1.10 23211 Carburetor Choke Knob Complete 40 23116 External Brake Toggle Lever (Right) 1.15 23212 Carburetor Choke Guide Tube 15 23117 External Brake Toggle Lever (Left) 1.15 23213 Carburetor Choke Wire 10 23118 External Brake Support Clip (Right) 25 23215 Carburetor Choke Housing Complete 25 23215 Carburetor Choke Housing Complete 25 23215 Carburetor Choke Housing Complete 25 23215 Carburetor Choke Lock Nut 05 23120 Internal Brake Cam Lever Adjuster 1.15 23217 Door Complete with Glass (Left) Upon Application 23122 External Brake Band Lining (Short) 75 23213 External Brake Band Lining (Long) 90 Upon Application 23220 Dummy Prop Iron Spacer (Lower) 17 23132 External Brake Band (Right) 4.00 23223 Dummy Prop Iron Spacer (Lower) 11 23224 Dummy Prop Iron Spacer (Lower) 12 23224 Dummy Prop Iron Spacer (Low		Door Complete, with Glass. Upon Appl	ication			
23109 Front Seat Cushion 26.00 23204 Door Lock (Right) 3.00 23110 Rear Seat Cushion 30.00 23205 Door Lock (Left) 3.00 23111 Rear Floor Carpet 5.00 23206 Rear Quarter Window Curtain 5.00 23112 Back Window Curtain 6.25 23208 Vanity Case 5.00 23114 Dome Light Glass 25 23209 Smoking Case 3.25 23114 Dome Light Reflector 1.10 23211 Carburetor Choke Complete 1.00 23115 Dome Light Reflector 1.10 23211 Carburetor Choke Knob Complete 40 23116 External Brake Toggle Lever (Right) 1.15 23212 Carburetor Choke Guide Tube 1.5 23118 External Brake Toggle Lever (Left) 1.15 23213 Carburetor Choke Wire 1.00 23118 External Brake Cam Lever Adjuster 1.15 23214 Carburetor Choke Housing Complete 25 23119 External Brake Cam Lever Adjuster 1.15 23215 Carburetor Choke Lock Nut 0.5 23120 Internal Brake Cam Lever 45 23216 External Brake Band Lining (Short) 75 23123 External Brake Band Lining (Short) 75 23218 External Brake Band Lining (Short) 75 23218 External Brake Band (Right) 4.00 23220 Dummy Prop Iron Spacer (Lower) 11 23134 Rear Axle Housing (Right Half) 17.00 23224 Dummy Prop Iron Spacer (Upper) 11		Door Complete, with Glass. Upon Appl	ication			The second second
23110 Rear Seat Cushion				00004		
23111 Rear Floor Carpet	The state of the s					
23112 Back Window Curtain. 6.25 23208 Vanity Case. 5.00 23113 Dome Light Glass. 25 23209 Smoking Case. 3.25 23115 Dome Light Reflector. 1.10 23211 Carburetor Choke Complete. 1.00 23116 External Brake Toggle Lever (Right). 1.15 23212 Carburetor Choke Knob Complete. 40 23117 External Brake Toggle Lever (Left). 1.15 23212 Carburetor Choke Guide Tube. 15 23118 External Brake Toggle Lever (Left). 1.5 23212 Carburetor Choke Wire. 10 23119 External Brake Support Clip (Right). 25 23215 Carburetor Choke Housing Complete. 25 23120 Internal Brake Cam Lever Adjuster. 1.15 23215 Carburetor Choke Housing Complete. 25 23121 Internal Brake Band Lining (Short). 75 23215 Carburetor Choke Housing Choke Lock Nut. 05 23121 Internal Brake Band Lining (Short). 75 23217 Door Complete with Glass (Right) 05 23124 Internal Brake Band Lever. 95 23218 Door Complete with Glass (Righ					Rear Quarter Window Curtain	5.00
23113 Dome Light Glass 25 23209 Smoking Case 3.25 23114 Dome Lamp Glass Retaining Ring 16 23210 Carburetor Choke Complete 1.00 23115 Dome Light Reflector 1.10 23211 Carburetor Choke Knob Complete 40 23116 External Brake Toggle Lever (Right) 1.15 23212 Carburetor Choke Knob Complete 40 23118 External Brake Toggle Lever (Left) 1.15 23212 Carburetor Choke Guide Tube 1.0 23118 External Band Support Clip (Right) 25 23213 Carburetor Choke Wire 10 23119 External Brake Cam Lever 25 23214 Carburetor Choke Housing Complete 25 23120 Internal Brake Cam Lever 45 23217 Door Complete with Glass (Left) Upon Application 23121 External Brake Band Lining (Short) 75 23218 Door Complete with Glass (Right) 23123 External Brake Band Lever 95 23219 Seat Cushion 20 20 23123 External Brake Band (Right)		Back Window Curtain	6.25		Vanity Case	5.00
23115 Dome Light Reflector	23113	Dome Light Glass	.25	23209	Smoking Case	3.25
23116 External Brake Toggle Lever (Right) 1.15 23212 Carburetor Choke Guide Tube 1.5 23117 External Brake Toggle Lever (Left) 1.15 23213 Carburetor Choke Wire 10 23118 External Band Support Clip (Right) 25 23214 Carburetor Choke Housing Complete 25 23120 Internal Brake Cam Lever Adjuster 1.5 23215 Carburetor Choke Housing Complete 25 23121 Internal Brake Cam Lever 45 23217 Door Complete with Glass (Left) Upon Application 23123 External Brake Band Lining (Short) 75 23218 Door Complete with Glass (Right) Upon Application 23124 Internal Brake Cam 95 23219 Seat Cushion 20 20 23125 Internal Brake Band (Right) 400 23220 Dummy Prop Iron Spacer (Lower) 17 23132 External Brake Band (Right) 400 23223 Dummy Prop Iron Spacer (Lower) 17 23134 Rear Axle Housing (Right Half) 17.00 23224 Dummy Prop Iron Spacer (Upper) 11		Dome Lamp Glass Retaining Ring	.16			
23117 External Brake Toggle Lever (Left) 1.15 23213 Carburetor Choke Wire						
23118 External Band Support Clip (Right) .25 23214 Carburetor Choke Housing Complete .25 23119 External Band Support Clip (Left) .25 23215 Carburetor Choke Lock Nut .05 23120 Internal Brake Cam Lever .45 Upon Application 23121 External Brake Band Lining (Short) .75 23218 Door Complete with Glass (Right) 23123 External Brake Band Lining (Long) .90 23219 Seat Cushion .20 .00 23125 Internal Brake Cam .95 23219 Seat Cushion .20 .00 23125 Internal Brake Band (Right) 4 00 23220 Alemite Grease Nipple .17 23132 External Brake Band (Right) 4 00 23220 Dummy Prop Iron Spacer (Lower) .11 23134 Rear Axle Housing (Right Half) 17.00 23224 Dummy Prop Iron Spacer (Upper) .11					Carburetor Choke Wire	10
23119 External Band Support Clip (Left) 25 23215 Carburetor Choke Lock Nut 05		External Band Support Clin (Right)	25		Carburetor Choke Housing Complete	25
23120 Internal Brake Cam Lever Adjuster 1.15 23217 Door Complete with Glass (Left) 23121 Internal Brake Cam Lever .45 23122 External Brake Band Lining (Short) .75 23123 External Brake Band Lining (Long) .90 23124 Internal Brake Cam .95 23125 Internal Brake Cam Lever Draw Pin 10 23126 External Brake Band (Right) 4.00 23127 Door Complete with Glass (Left) Upon Application 23219 Seat Cushion 20.00 23129 Alemite Grease Nipple .17 23133 External Brake Band (Left) 4.00 23223 Dummy Prop Iron Spacer (Lower) .11 23134 Rear Axle Housing (Right Half) 17.00 23224 Dummy Prop Iron Spacer (Upper) .11		External Band Support Clip (Left)	.25		Carburetor Choke Lock Nut	.05
23121 Internal Brake Cam Lever		Internal Brake Cam Lever Adjuster	1.15		Door Complete with Glass (Left)	Techno
23122 External Brake Band Lining (Short). .75 2323 External Brake Band Lining (Long) .90 Upon Application 23124 Internal Brake Cam .95 23219 Seat Cushion .20 .00 23125 Internal Brake Band (Right) 4.00 23220 Alemite Grease Nipple .11 23133 External Brake Band (Lieft) 4.00 23222 Dummy Prop Iron Spacer (Lower) .20 23134 Rear Axle Housing (Right Half) 17.00 23224 Dummy Prop Iron Spacer (Upper) .11	23121	Internal Brake Cam Lever	.45		Upon App	lication
23124 Internal Brake Cam		External Brake Band Lining (Short)	.75	23218	Door Complete with Glass (Right)	Butto
23125 Internal Brake Cam Lever Draw Pin. .10 23220 Alemite Grease Nipple. .17 23132 External Brake Band (Right). 4.00 23222 Dummy Prop Iron Spacer (Lower). .11 23133 External Brake Band (Left). 4.00 23223 Dummy Prop Iron Spacer (Lower). .20 23134 Rear Axle Housing (Right Half) 17.00 23224 Dummy Prop Iron Spacer (Upper). .11		External Brake Band Lining (Long)	.90	00010	Seet Cushian Upon App.	lication
23132 External Brake Band (Right) 4.00 23222 Dummy Prop Iron Spacer (Lower) .11 23133 External Brake Band (Left) 4.00 23223 Dummy Prop Iron Spacer (Lower) .20 23134 Rear Axle Housing (Right Half) 17.00 23224 Dummy Prop Iron Spacer (Upper) .11					Alemita Greece Ninnle	17
23133 External Brake Band (Left)		External Brake Band (Bight)	4 00			
23134 Rear Axle Housing (Right Half) 17.00 23224 Dummy Prop Iron Spacer (Upper) 11		External Brake Band (Left)	4.00		Dummy Prop Iron Spacer (Lower)	.20
					Dummy Prop Iron Spacer (Upper)	.11
	23135			23225	Dummy Prop Iron Stud (Lower)	.13

Part No.	Part Name	Price	Part No.	Part Name Pri
23226	Dummy Prop Iron Stud (Upper)	\$0.10	23307	Radiator Core\$27.5
23227	Dummy Prop Iron Stud (Lower)	.13	23308	Radiator Core
23229	Spark Control Tube (R.D.)	.60	23309	Deck Floor Carpet
23232	Hand Lever	$2.50 \\ .35$	23310 23311	Dome Lamp Glass and Rim
23233	Hand Lever Latch Rod (R.D.)	.45	23312	Body Bolt Lock
23234 23235	Side Curtain, Pyroline	1.25	23313	Step Countersunk Washer
23236	Rear Spring Bumper Retainer	.12	23314	Door Complete with Glass (Right)
23237	Rear Spring Bumper	.12	Diam.	Upon Application
23238	Steering Wheel Complete	7.25	23315	Door Complete with Glass (Left)
23239	Steering Wheel Cap	.40	99916	Upon Application
23242	Hood (with Bead)	.35	23316	Door Complete with Glass (Right) Use No. 233
23243	Hood Catch Bracket Hood Catch Complete		23317	Door Complete with Glass (Left)
23244 23245	Hood Handle	.18	Nat.	Use No. 233
23246	Cowl Lamp	2.25	23318	Door Complete with Glass (Right)
23247	Head Lamp Complete (Left)	10.00	- 64	Use No. 233
23248	Head Lamp Complete (Right)	10.00	23319	Door Complete with Glass (Left)
23250	Right Door Complete	16.00	00000	Use No. 233
23251	Left Door Complete	16.00	23320	Door Comp. with Glass (Right Front) Upon Application
23252	Outside Door Handle	.85	23321	Door Comp. with Glass (Left Front)
23253	Top Iron (Left)	.65	20021	Upon Application
23254 23255	Roof Top Handle	3.25	23322	Door Comp. with Glass (Right Rear)
23256	Step Plate (Lower) (Right)			Upon Application
23257	Step Plate (Lower) (Left)	4.00	23323	Door Comp. with Glass (Left Rear)
23258	Step Plate Reinforcement (Lower)	.25	00004	Upon Application
23259	Step Plate (Upper)	1.30	23324	Door Comp. with Glass (Right Front)
23260	Step Plate Gasket (Upper)	.05	23325	Upon Application Door Comp. with Glass (Left Front)
23261	Seat Cushion	1.75	20020	Upon Application
23262 23263	Left Front Door Upholstery	1.75	23326	Door Comp. with Glass (Right Rear)
23264	Deck Door Lock	1.00		Upon Applicati
23265	Deck Door Lock Striker Plate	.25	23327	Door Comp. with Glass (Left Rear)
23266	Deck Door Handle	.95	6	Upon Applicati
23267	Deck Hand Rail Reinforcement Plate.	.03	23328	Right Front Door Complete 13.
23268	Deck Hand Rail	7.50	23329 23330	Left Front Door Complete 13. Right Rear Door Complete 13.
23269	Top Complete Less Curtains	8.00	23331	Left Rear Door Complete
23270	Top Deck with Side Quarters Left Front Side CurtainUse No	24837	23332	Head Lamp Door Catch Spring
23271 23272	Right Front Side CurtainUse No	24836	23333	Wing Radiator Cap Gasket
23273	Left Rear Side CurtainUse No	. 24839	23334	Crankshaft Rear Bearing (Upper) 1.
23274	Right Rear Side Curtain Use No	. 24838	23335	Crankshaft Interm. Bearing (Upper) 1.
23275	Back Curtain Use No	. 24840	23336	Crankshaft Front Bearing (Upper) 1.
23276	Curtain Rod	25	23337	Oil Pump Drive Gear
23277	Curtain Rod Socket	2.60	23338 23339	Crankshaft Bearing Dowel
23278	First Top Bow Second Top Bow	2.60	23340	Horn Wire
23279 23280	Third Top Bow	3.75	23341	Tire Carrier Bracket Complete 2.
23281	Top Bow Slat Iron (Left)	. 13.00	23342	Tire Carrier Bracket Complete 2.
23282	Top Bow Slat Iron (Right)	. 13.00	23343	Tire Carrier Plate
23283	Windshield Top Bracket	14	23344	Tire Carrier Brace
23284	Windshield Side Arm Clamp (Right).	12	23345 23347	Tire Carrier Stud
23285	Windshield Side Arm Clamp (Left)	12	23348	Right Door Complete
23286	Windshield Wing Glass	8.00	23349	Seat Cushion
23287 23288	Windshield Wing Bracket Screw	10	23350	Right Front Door Upholstery 1
23290	Windshield Complete	. 35.00	23351	Left Front Door Upholstery 1:
23291	Windshield Glass	. 12.00	23352	Top Complete
23292	Windshield Frame Plug	55	23353	Top Deck
23293	Windshield Frame Clip	25	23354	Right Front Side Curtain
23294	Windshield Frame Clip Screw	02	23355 23356	Left Front Side Curtain
23295	Windshield Pivot Clamp		23357	Left Rear Side Curtain
23296	Windshield Pivot Thumb Screw	40	23358	Back Curtain Complete 4
23297 23298	Windshield Side Arm (Right)	1.85	23359	First Top Bow
23299			23360	Second Top Bow
23300	Windshield Weatherstrip	70	23361	Third Top Bow 1
23301	Top Prop Nut	20	23362	
23302	Windshield Top Fastener Acorn Nut.	16	23363	
23303	Hood Complete	. 15.00	23364 23365	
23304		17 00		
23305	프로그램 시간 아이들은 사람들이 가장 아이들은 사람들이 되었다면 하는 것이 없는데 모든데 되었다.	17.00	23368	
23306	TIOOG Combiere	. 21.00	20000	manufi walkaranni ni ni ni ni ni ni ni ni

	Part No.	Part Name	Price	Part No.	Part Name	Price
	23369	Deck Panel Guard		23454	Hexagon Head Cap Screw	
	23370	Top Strap		23455	Windshield Wing Deflector Complete.	\$0.05 6.60
	23371	Outside Door Handle	.85	23456	Demountable Rim Lock Stud	.10
	23372	Window Regulator Roller and Pin	.45	23458	Window Regulator Complete (Right).	1.40
	23373	Fly Wheel Bolt	.15	23459	Window Regulator Complete (Left)	1.40
	23374	Special Hexagon Nut	.08	23460	Front Bearing (Lower) (.010" under-	SOME
	23375	Filler Block Packing (Rear)	.04	00461	size)	2.30
	23376 23377	Lightweight Piston (Standard) Lightweight Piston (.003" oversize)	3.55 3.55	23461	Front Bearing (Upper) (.010" undersize)	1 00
	23378	Lightweight Piston (.005" oversize)	3.55	23462	Intermediate Bearing (Lower) (.010"	1.80
	23379	Lightweight Piston (.010" oversize)	3.55	20102	U.S.)	1.30
	23380	Lightweight Piston (.015" oversize)	3.55	23463	Intermediate Bearing (Upper) (.010"	1300
	23381	Lightweight Piston (.020" oversize)	3.55		U. S.)	1.30
	23382	Lightweight Piston (.023" oversize)	3.55	23464	Rear Bearing (Upper) (.010" under-	SEATE .
	23383 23384	Lightweight Piston (.025" oversize)	3.55	99465	size)	1.90
	23385	Lightweight Piston (.030" oversize) Lightweight Piston (.035" oversize)	3.55 3.55	23465	Rear Bearing (Lower) (.010" under-	1.75
	23386	Piston Pin (Standard)	.45	23466	size) Timing Chain Hunting Link	1.00
	23387	Piston Pin (.005" oversize)	.45	23467	Rear Floor Carpet	5.00
	23388	Piston Pin (.010" oversize)	.45	23468	Front Spring Bracket	.80
	23389	Piston Ring (Plain) (Standard)	.20	23469	Rear Spring	5.50
	23390	Piston Ring (Plain) (.010" oversize)	.20	23470	Rear Spring	6.10
	23391 23392	Piston Ring (Plain) (.020" oversize)	.20	23471 23472	Front Spring Charles (Inner)	3.85
	23393	Piston Ring (Plain) (.030" oversize) Oil Level Gauge Rod Guide	$.20 \\ .35$	23473	Front Spring Shackle (Inner) Front Spring Shackle (Outer)	.30
	23394	Rear Bearing Filler Block	1.40	23474	Rear Spring Shackle (Outer)	.35
	23395	Rear Bearing Oil Retainer	.20	23475	Rear Spring Shackle (Inner)	.35
	23396	Oil Suction Pipe with Nut	.70	23476	Spring Shackle Pin	.25
	23397	Oil Suction Pipe Packing (Felt)		23477	Rear Spring Shackle Spring	.09
	23398 23399	Oil Suction Pipe Packing (Felt)	.04	23478	Spring Shackle Spring	.08
	23399	Crankshaft Bearing Cap Stud (Rear) Bearing Cap Stud (Front and Inter.).		23479 23480	Rear Spring Horn with Pin (Left)	.95
	23401	Rear Bearing Oil Retainer	.35	23481	Rear Spring Horn with Pin (Right) Carburetor Body Upper Half	.95 7.50
	23402	Crankshaft Bearing Cap (Front)	1.60	23482	Spring Shackle Bolt	.09
	23403	Crankshaft Bearing Cap (Inter)	1.55	23487	Clutch Shaft Lever	.20
	23404	Crankshaft Bearing Cap (Rear)	1.90	23488	Special Hex. Head Cap Screw	.09
	23405	Crankshaft Front Bearing (Lower)	2.30	23489	Clutch Shaft Lever Support	.45
	23406 23407	Crankshaft Front Bearing (Upper)		23490	Internal Brake Band Lining	. 50
	23408	Intermediate Bearing (Lower) Intermediate Bearing (Upper)	$\frac{1.30}{1.30}$	23491 23492	Rear Window Glass	6.00
	23409	Crankshaft Rear Bearing (Lower)		23493	Carburetor By-Pass Screen	.05
	23410	Crankshaft Rear Bearing (Upper)	1.90	23494	Steering Wheel Cap	.40
	23411	Rear Bearing Filler Block Packing		23500	Rear Floor Carpet	6.50
	GO A	Use No.	22423	23501	Rear Floor Carpet (R. D.)	6.00
	23412	Oil Delivery Pipe Complete	5.25	23504	Door Lock Lever Handle (Inside)	40
	23413 23414	Flared Tube Union Filler Block Dust Guard Packing	.50	23505	(Right) Door Lock Lever Handle (Inside)	.40
	23415	Filler Block Dust Guard Facking	1.85	20000	(Left)	.40
	23416	Rear Spring Center Bolt	.16	23506	Outside Door Handle	1.00
	23417	Gasoline Tank Filler Cap	.20	23507	Outside Door Handle (With Lock)	1.85
	23418	Gasoline Tank Filler Cap Gasket	.03	23508	Outside Door Handle Key	.25
	23425	Demountable Rim Lock Stud Screw	.10	23510	Curtain Rod	.25
	23426	Curtain Rod	2 40	23511	Valve Tappet Guide Plug	.10
	23427 23428	Oil Delivery Pipe Flange Gasket	.03	23512 23513	Mast Jacket Bracket (Upper)	3.50
	23429	Deck Door Handle	.25	23514	Mast Jacket Bracket Cap (Upper)	.15
	23430	Head Lamp Complete	6.50	23515	Motor Underpan (Left)	.80
	23431	Head Lamp Reflector	1.85	23516	Exhaust Pipe	1.50
	23432	Head Lamp Glass	.40	23517	Front Floor Carpet	5.50
	23433 23434	Head Lamp Rim	1.70	23518	Front Floor Carpet	5.50
	23434	Cowl Lamp Complete	1.80	23519 23520	Front Floor Mat. Front Spring Clip	2.15
	23436	Cowl Lamp Rim	.25	23521	Exhaust Pipe Clamp (Front)	.17
2	23437	Gypsy Curtain (Left)	3.25	23537	Front Brake Rod (Rear)	.55
	23438	Gypsy Curtain (Right)	3.25	23539	Brake Rod (Front) (Adjusting Nut)	.20
	23439	Left Front Door Complete	13.00	23540	Spark Control Tube	1.00
	23440	Right Front Door Complete	13.00	23543	Steering Wheel	7.25
	23441	Left Rear Door Complete	13.00	23544	Intake and Exhaust Manifold	
	23442 23446	Right Rear Door Complete Tire Carrier Bracket Complete (R.D.)	2.50	23545 23546	Brake Lever Adjusting Screw Brake Lever Adjusting Screw Nut	.35
	23447	Tire Carrier Bracket Complete (R.D.)	2.50	23547	Front Wheel Complete (Rugby)	.07 10.00
	23448	Tire Carrier Brace (R.D.)	. 50	23548	Rear Wheel Complete (Rugby)	10.00
	23449	Door Glass (Rear)	8.00	23549	Floor Board Cutout Cover	.35
	23450	Door Glass (Front)	8.00	23550	Brake Cam	1.45
					The second secon	

art No.	Part Name	Price	Part No.	Part Name	Pric
3551	Cluster Instrument Panel Screw		23647	Steering Gear Bracket	
3552	Instrument Board	3.00	23648	Steering Gear Bracket Bushing	.2
3553	Instrument Board	$\frac{3.00}{.35}$	23649 23650	Spark Control Tube with Lever Throttle Control Tube with Lever	$\frac{1.1}{1.1}$
3556 3557	Cowl Lamp Ring	26.50	23651	Steering Gear Control Tube with Base	
3558	Stop Light Switch	. 55	23652	Control Cover	.2
3560	Hand Brake Lever	1.85	23653	Control Cover Screw	. 0
3561	Cowl Lamp Complete	1.40	23654	Control Cover Spacer	.0
3562	Headlamp Complete	4.25	23655	Control Cover Spring	.0
3564	Tail and Stop Lamp Complete	2.35	23656	Control Friction Plate (Lower) Control Friction Plate (Upper)	.0
3565	Windshield Complete (R.D.)	.35	23657	Control Tube Clamp (Lower)	.0
3566 3567	Double Spring Contact Plug Cowl Lamp Lens	.25	23658 23659	Control Tube Clamp Plate (Lower)	.0
3568	Smoking Case		23660	Horn Wire Complete	
3569	Vanity Case	9.00	23661	Horn Button	.1
3570	Door Lock (Right Rear and Left Front)		23662	Horn Button Spring	. (
3571	Door Lock (Left Rear)	1.25	23663	Water Pump Body Shim	
3572	Door Lock (Left)	$\frac{1.40}{1.10}$	23664	Headlamp Reflector	
3573	Outside Door Handle Door Lock Handle (Inside)	.85	23665 23666	Headlamp RimHeadlamp Glass	
3574	Outside Door Handle, with Key		23667	Cowl Lamp Lens	1036
3575 3576	Door Lock (Right Front)	1.40	23668	Cowl Lamp Rim	
3577	Door Lock (Right Front)		23669	Spark Control Tube	
3578	Frame Complete	38.00	23670	Steering Wheel	4.
3579	Dome Lamp Reflector	1.10	23671	Rear Main Bearing Mud Guard	0.60%
3580	Dome Lamp Glass	.30	23672	Front Floor Mat (R.D.)	
3581	Dome Lamp Glass Retaining Ring	.14 $.75$	23673	Front Floor MatFront Floor Mat	2.
3582	Motor Underpan (Right) (R.D.) Motor Underpan (Left) (R.D.)	.75	23674 23675	Front Floor Mat (R.D)	2.
3583 3584	Motor Underpan (Right)	.80	23676	Steering Gear Bracket (R.D)	2.
3585	Motor Underpan (Left)	.80	23677	Steering Gear Bracket (R.D)	2.
3586	Motor Shock Insulator	.80	23678	Steering Gear Housing (R.D)	3.
3587	Flywheel Underpan	1.80	23679	Intake and Exhaust Manifold	6.
3588	Flywheel Underpan Washer	.02	23680	Exhaust Pipe	
3589	Shock Insulator Housing Cap	.25	23681	Steering Gear Worm (R.D)	
3590	Shock Insulator Housing Cap Screw	$03 \\ 5.15$	23682	Steering Gear Worm Wheel (R.D.) Flywheel Underpan	
3591· 3592	Chain Case Exhaust Pipe		23683 23684	Motor Underpan (Left)	
3593	Motor Arm Rivet	.03	23685	Motor Underpan (Left) (R.D.)	
3594	Rear Motor Support	2.75	23686	Motor Underpan (Right) (R.D.)	. H47
3595	Front Motor Arm	. 40	23687	Front Axle "I" Beam	. 14.
3596	Rear Motor Support Brace	.11	23688	Steering Knuckle (Right)	6.
23597	Shock Insulator Housing (Front)	55	23689	Steering Knuckle (Left)	
23598	Rear Quarter Window Regulato	65	23690	Steering Knuckle (Right) (R.D.)	
2000	HandleWindow Regulator Handle	. 65	23691	Steering Knuckle (Left) (R.D.) Steering Knuckle Adjusting Washer.	
23599 23600	Window Regulator Handle Escutcheon	20	23692 23693	Steering Knuckle Thrust Bearing	
23612	Door Lock Remote Control Plate	Э	23694	Steering Arm (Right) (R.D.)	
	(R.F.)	50	23695	Steering Arm (Left)	. 4.
23623	Spark Lever (Lower)	10	23696	Steering Arm Ball Stud	
23625	Door Lock Remote Control Plate (Lef	t FA	23697	Steering Arm (Left) (R.D.)	. 1.
	Rear) Parata Control Plate / F	50	23698	Steering Arm (Right)	$\frac{1}{2}$
23626	Door Lock Remote Control Plate (L.F and R.R.)	50	23699	Front Axle Tie Rod	
22628	Steering Gear Worm Adjust'g	1 00000	23701 23702	Transmission Case Cover	
23020	Steering Gear Worm Adjust'g Nut	1-26902 1-26903	23703	Transmission Case Cover (R.D.)	
	Steering Gear Main Tube Bushing		23704	Shifter Shaft (Low and Reverse)	
23629	Pitman Arm	1.90	23705	Shifter Shaft (High and Intermediate	
23630 23631	Pitman Arm	. 1.90	23706	Gear Shift Lever Spring	
23632		2.25	23707	Gear Shift Lever	
3633	Steering Gear Worm	95	23709	Shifting Lock Ball Spring	20 275
23634	Steering Gear Mast Jacket Bushing	35	23710 23711	Horn Button	
23635	Steering Gear Bracket with Bushing	. 2.35	23711	Stop Light Switch Spring	781
23636	Throttle Lever (Lower)	10 45	23713	Lighting and Ignition Switch	. 2.
23637		02	23714	Front Brake Cam Lever	. 1.
23638				Water Pump Coupling Hose	. Upp
23639 23640		10	23716	Lighting and Ignition Switch	. 2.
23641	Steering Gear Worm Wheel	2.70	23717		2.
23642	Steering Gear Housing	. 2.60	23718		
23643	Steering Gear Housing Stud	04			
70040			737711	I all ally DOOD Lally Little (Toughy)	
23644 23645	Pitman Arm Nut	09	00001	Front Fender (Left)	. 8.

Part No.	Part Name	Price	Part No.	Part Name	Price
23723		\$6.50	23804	Door Lock with Control Plate (Right	\$1.60
23724	Rear Fender (Right)	6.50	23805	Front)	φ1.00
23725 23726	Tire Carrier Bracket (Left) Tire Carrier Bracket (Right)	$\frac{2.10}{2.10}$	20000	Rear)	1.60
23727	Shock Insulator Housing Bolt	.04	23806	Door Lock with Control Plate (Right	4 00
23728	Spark Control Tube (R.D.)	. 60	601	Rear)	1.60
23729	Throttle Control Tube (R.D.)		23807	Piston Ring (Lower) (.035" oversize)	.30
23730	Throttle Control Wire (R.D.)	11 . 15	23808 23809	Piston Ring (Plain) (.005" oversize) Piston Ring (Plain) (.015" oversize)	.20
23731 23732	Coupster Top with WsUpon Appli Throttle Control Wire		23810	Piston Ring (Plain) (.025" oversize)	.20
23732	Throttle Control Wire (R.D.)		23811	Piston Ring (Plain) (.035" oversize)	
23734	Water Pump Packing		23812	Piston Ring (.005" oversize)	.25
23735	Front Wheel Complete	9.00	23813	Piston Ring (.015" oversize) Piston Ring (.025" oversize)	.25
23736 23737	Rear Wheel CompleteFront Wheel Complete	10.00	23814 23815	Piston Ring (.035" oversize)	.25
23738	Rear Wheel Complete		23816	Piston Ring (Plain) (.005" oversize)	.20
23739	Demountable Rim	2.25	23817	Piston Ring (Plain) (.015" oversize)	.20
23740 23741	Tire Carrier Tie Bar	$\frac{.90}{3.85}$	23818 23819	Piston Ring (Plain) (.025" oversize) Piston Ring (Plain) (.035" oversize)	.20
23742	Gas Tank Support	0.0	23820	Oil Pump Drive Gear	
23743	Steering Conn. Rod Adjusting Plug	11	23821	Oil Pump Driven Gear	1.70
23744	Steering Conn. Rod Adjusting Plug	.17	23822	Clutch Thrust Bearing Spring Washer	. 04
23745 23746	Steering Connecting Rod Ball Seat Steering Connecting Rod Ball Seat	.10	23825 23836	Hub Cap (Plain) Front Floor Mat (R. D.)	2.00
23747	Steering Connecting Rod Spring	.09	23837	Coupster Top with Windshield	02642
23748	Steering Conn. Rod Complete (R.D.).	2.50	00.12	Upon Appl	
23749	Steering Connecting Rod Complete	$\frac{2.50}{2.50}$	23838 23839	Front Floor Carpet (R. D.)	5.00
23750 23751	Steering Connecting Rod Complete Steering Conn. Rod Complete (R.D.).	2.50	23842	Front Floor Carpet (R. D.)	5.00
23752	Oil Pump Body	4.00	23843	Front Bearing (Lower) (.020" undersize) 2.30
23753	Oil Pump Relief Plunger Gasket	.02	23844	Front Bearing (Upper) (.020" undersize) 1.80
23754 23755	Oil Pump Relief ValveOil Pump Relief Valve Spring		23845 23846	Inter. Bearing (Lower) (.020" undersize Inter. Bearing (Upper) (.020" undersize	1.30
23756	Oil Pump Relief Spring Cap		23847	Rear Bearing (Upper) (.020" undersize)	1.90
23757	Throttle Control Tube (R.D.)	. 60	23848	Rear Bearing (Lower) (.020" undersize)	1.73
23758	Spark Control Tube (R.D.)		23849 23850	Brake Idler Lever Bushing Steering Gear Bracket (R. D.)	$\frac{10}{2.70}$
23759 23760	Throttle Control Wire (R.D.) Oil Pressure Gauge		23851	Steering Gear Bracket, with Bushings	2.90
23761	Ammeter	1.50	23852	Steering Knuckle (Right)	9.50
23762	Oil Pressure Gauge Bezel		23853	Steering Knuckle (Left) Steering Knuckle (Right) (R. D.)	9.50
23763 23765			23854 23855	Steering Knuckle (Left) (R.D.)	9.50
23766			23856	Steering Arm (Right) with Ball Stud	1000
23767	Piston Ring (Plain) (.025" oversize)	.20	**1) .	(R.D.)	6.2
23768			23857	Steering Arm (Left) with Ball Stud (L.D.)	5.00
23770 23771	Carburetor Choke Housing Complete.		23858	Steering Knuckle Arm (Right) (L.D.) Z.Z.
23772	Carburetor Choke Guide Tube	.40	23859	Steering Knuckle Arm (Left) (R.D.)	. 4.5
23773			23860 23861	Steering Knuckle Arm Ball Stud Front Axle Tie Rod	2.6
23774 23775			23863	Tie Rod Spring Seat Washer	0
23776			23864	Tie Rod Spring	0
23777	Piston Ring (Lower) (.005" oversize)	30	23865	Tie Rod Spring Seat (Shouldered) Tie Rod End Plug	$\begin{array}{ccc} & .0 \\ & .2 \end{array}$
23778 23779			23866 23868	Top Dust Cover	4.6
23780			23869	Top Dust Cover	. 6.0
23781	Front Control Lever (Left)	3.00	23870	Top Dust Cover	. 4.6
23782			23871 23872	Oil Pan TroughOil Suction Pipe	$\begin{array}{ccc} . & 2.6 \\ . & .8 \end{array}$
23791 23792			23873	Oil Suction Pipe Flared Tube Union.	6
23793	Deck Floor Carpet	4.50	23874	Tail and Stop Lamp Rim	6
23794	Rumble Seat Cushion	25.00	23875	Front Bearing (Upper) (.005" undersize Front Bearing (Lower) (.005" undersize	e) 1.8 e) 2.3
23795 23796			23876 23877	Inter. Bearing (Lower) (.005 undersize	e) 1.3
23797	Piston Ring (Lower) (.015" oversize).	30	23878	Inter. Bearing (Upper) (.005" undersize	e) 1.3
23798	B Door Lock Control Plate (Right Front	.50	23879	Rear Bearing (Upper) (.005" undersize) 1.9
23799	Door Lock Control Plate (Left Rear).	50	23880	Rear Bearing (Lower) (.005" undersize Horn with Bracket	
23800 23801			23881 23882		
		1.60	23883	Rear Fender (Left)	. 6.2
20001	Front)	. 1.00			
23802 23803	2 Door Lock with Control Plate (Right	1.60	23884 23885	Rear Fender (Right)	. 6.2

Part No.	Part Name	Price	Part No.	Part Name	Price
23887	Exhaust Pipe Clamp	\$0.09	23973	Door Complete (Left) Upon Applic	
23888	Oil Pump Body	4.00	23974	Door Window Glass Door Glass Felt	
23889	Oil Relief Valve Spring	.04 .25	23975 23976	Front Seat Cushion	
23890 23891	Oil Relief ValveOil Relief Valve Plug		23977		
23892	Spark Control Tube (L.D.)	. 50	23978	Door Dovetail (Male)	.40
23893	Spark Control Tube (R.D.)	.30	23979	Prop Iron	5.25
23902	Worm Adjusting Nut Spacer	.60	23980 23981	Prop Iron Nut	.16
23903	Steering Gear Worm Adjusting Nut	$\begin{array}{c} .45 \\ 1.90 \end{array}$	23982	Prop Iron Spacer (Upper)	.20
23904 23905	Front Bearing (Upper) Front Bearing (Upper) (.005" undersize)	1.90	23983	Prop Iron Stud (Lower)	.20
23906	Front Regring (Unner)(010"undersize	e) 1.90	23984	Prop Iron Stud (Upper)	.50
23907	Front Bearing (Upper)(.020"undersize	e) 1.90	23985	Top Complete (Less Slat Irons)	
23908	Front Boaring (Lower)	1.10	23986	Tail Lamp Complete (Rugby) Back Curtain Complete	1.75 11.00
23909	Front Bearing (Lower) (.005" undersize	2.30	23987 23988	Tail Lamp Lens (Rugby)	.15
23910 23911	Front Bearing (Lower) (.010" undersize Front Bearing (Lower)(.020" undersize	e) 2.30	23990	Back Curtain Glass	3.00
23912	Inter Rearing (Unner)	1.00	23991	Back Curtain Inner Frame	.70
23913	Inter Bearing (Upper)(.005"undersiz	e) 1.40	23992	Back Curtain Outer Frame	2.10
23914	Inter. Bearing (Upper)(.010"undersiz	e) 1.40	23993	Top Strap LoopSocket and Clinch Plate	.06
23915	Inter. Bearing (Upper) (.020" undersize	1.40	23994 23995	Socket and Clinch Plate	.06
23916	Inter. Bearing (Lower)	1.00	23996	Two Pronged Clincher and Plate	.07
23917 23918	Inter. Bearing (Lower) (.000 undersize	1.40	23997	"Lift the Dot" Stud	.04
23919	Inter. Bearing (Lower)(.020"undersiz	e) 1.40	23998	Button and Socket	.03
23920	Rear Rearing (Upper)	1.00	23999	Snap Fastener Eyelet	.03 1.90
23921	Rear Bearing (Upper) (.005" undersize)	$\frac{2.00}{2.00}$	24000 24001	Top Bow (Rear)	1.30
23922	Rear Bearing (Upper) (.010" undersize) Rear Bearing (Upper) (.020" undersize)	2.00	24002	Top Brace	.95
23923 23924	Rear Bearing (Upper) (.020 undersize)	1.30	24003	Top Brace Screw	.25
23925	Rear Rearing (Lower) (.005" undersize)	1.85	24004	Top Brace Bracket (Front)	.20
23926	Rear Bearing (Lower) (.010" undersize)	1.80	24005	Top Brace Bow Bracket (Left)	.25
23927	Rear Bearing (Lower) (.020" undersize)	1.85	24006 24007	Top Brace Bow Bracket (Right) Folding Pillar Bracket (Left)	.25
23928	Front Bearing Cap (From Motor No	1.65	24007	Folding Pillar Bracket (Right)	.25
23929	54657) Intermediate Bearing Cap		24009	Front Wheel (21" Dia.)	
23930	Rear Bearing Cap	2.00	24010	Front Wheel (19" Dia.)	
23931	Crankshaft Bearing Dowel	.05	24012	Front WheelFront Floor Mat	
23932	Lighting and Ignition Switch Complete	2.50	24013 24014	Front Floor Mat. (R.D.)	
23933	Tail Lamp Lower Lens		24015	Front Fender Lamp Complete	
23934 23935	Rear Wheel	5.50	24016	Main Bearing Mud Guard	.11
23938	Rear Wheel	5.50	24019	Top Bow Socket (Left)	
23939	Cowl Lamp Rim Screw	.05	24020	Top Bow Socket (Right)	
23941	Carburetor Nozzle Gasket	05	24021 24022	Top Bumper Bracket	T 04.
23942			24023	Filtrator Shell	
23943 23944		75	24024	Filtrator Lower Half	8.00
23945	Carburetor Body (Upper Half)	4.25	24025	Oil Filtrator Gasket	4.0
23946	Carburetor Float Bowl Cover	25	24026 24027	Filtrator Shell Gasket	
23947	Carburetor Inlet Valve Seat	$0.40 \\ 1.00$	24028	Filtrator Outlet Fitting Gasket	
23948 23949		40	24029	Filtrator Outlet Fitting Cap	.14
23950		10	24030	Filtrator Outlet Fitting Cap Gasket	04
23951	Carburetor Choke Shaft	20	24031	Filtrator Washer	.14
23952	Carburetor Choke Lever	30	24032	Filtrator Felt Retaining Washer (Upper)	.14
23953		25	24033		18224
23954			00.8	(Lower)	.14
23955 23956		40	24034	Filtrator Outlet Tube	95
23957	Carburetor Accelerator Lever	50	24035	Filtrator Outlet Tube Spring	50
23958	Carburetor Accelerator Lever	50	24036		30 r .14
23959			24037 24038		r .07
23960			24039		10
23961 23962		75	24040	Filtrator Drain Plug	16
23963	Carburetor Float Lever Pin	05	24041		
23964	Foot Rest Complete	. 1.60	24042		
23965	Shock Insulator Housing Shim	01	24043 24044		
23966		14	24045		30
23967 23968	Top Strap	40	24046	Oil Level Gauge Rod Washer	02
23969	Gasoline Tank Gauge Glass	07	24047		
23972		plication	24048	Filtrator Tube Complete	80

Part No.	Part Name	Price	Part No.	Part Name	Price
24049	Water Pump Body	. \$4.75	24135	Seat Cushion	17.75
24051	Cylinder Block	.115.00	24136 24138	Seat CushionOil Pump Suction Pipe Complete	1.65
24052	Oil Delivery Pipe Complete Front Spring Seat Spacer		24139	Oil Pump Suction Pipe Union	
24053 24054	Front Spring First Leaf Bushing		24140	Carburetor Body (Upper Half)	3.50
24058	Cylinder Head Stud Nut		24141	Carburetor Throttle Lever	.40
24061	Headlamp Rim Gasket	07	24142	Carburetor Choke Shaft	
24062	Throttle Operating Rod	16	24143	Carburetor Choke Shutter	.05
24063	Throttle Rod Trunnion	16	24144 24145	Special ScrewCarburetor By-Pass Tube Screen	.05
24064 24065	Frame Complete		24145	Carburetor Air-Horn	1.00
24066	Steering Gear Bracket (R.D.)		24147	Carburetor Body (Upper Half)	3.50
24067	Tire Carrier Complete	4.75	24148	Carburetor Nozzle	.60
24068	Front Spring	. 3.90	24149	Carburetor Nozzle Seat	.30
24069	Front Spring Seat	50	24150	Carburetor Throttle Shutter	
24070	Front Axle "I" Beam	. 14.00	24151	Carburetor Throttle Lever Shaft Carburetor Secondary Venturi	
24072	Ring Gear	. 21.00	24152 24153	Carburetor By-Pass Tube and Screen	80
24073	Ring Gear Rivet	14 50	24154	Hub Cap	.25
24074 24075	Propeller Shaft	12.25	24161	Front Floor Carpet	5.50
24076	Radiator Shell	10.00	24162	Front Floor Carpet (R.D.)	5.25
24077	Fan Drive Pulley	3.00	24163	Door Check Rod Complete	
24078	Exhaust Pipe	. 1.75	24164	Door Check Rod Washer (Steel)	.07
24079	Underpan (Left)		24165	Door Check Rod Washer (Leather)	$.04 \\ .04$
24080	Underpan (Right)		24166 24179	Door Check Rod Washer (Rubber) Instrument Board Lamp Wire	.30
24081	Underpan (Left) (R.D.)	1.50	24179	Door and Rear Quarter Glass Channel	.50
24082 24083	Underpan (Right) (R.D.)		24181	Door and Rear Quarter Glass Channel	.45
24084	Clutch Pedal.		24182	Radiator Shim	.02
24085	Clutch Pedal (R.D.)		24183	Vacuum Tank Cover Complete	2.10
24086	Pedal Return Spring (R.D.)	20	24184	Vacuum Tank Float	1.10
24087	Clutch Pedal Shaft	65	24185	Vacuum Tank Screen and Bushing	
24088	Speedometer Gear		94996	Complete	.18
24089	Speedometer Pinion		24226	(Right)	
24090	Foot Brake PedalBrake Pedal Pull Rod		24227	Choke Complete	
24091 24092	Worm Wheel (R.D.)	3.15	24228	Choke Complete	
24094	Steering Conn. Rod Complete	. 2.50	24229	Choke Mounting Plate Complete	
24095	Steering Conn. Rod Complete (R.D.)	2.25	24230	Choke Mounting Plate Complete	
24096	Throttle Wire	04	24231	Choke Guide Tube	
24097	Spark Tube Complete		24232 24239	Choke Wire	1 40
24098	Spark Tube Complete (Mag. Ign.) Throttle Tube Complete (R.D.)	525 25 15 15 15	24240	Motor Shim	.02
24099 24101	Spark Tube Comp. (R.D.) (Bat. Ign	2 7 6 4 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6 7 6	24241	Front Axle "I" Beam	15.00
24101			24242	Steering Knuckle (Right)	
24103			24243	Steering Knuckle (Left)	7.75
24104	Side Apron (Right)	. 3.75	24244	Steering Knuckle (Right) (R.D.)	7.75
24105	Side Apron (Left)	3.75	24245	Steering Knuckle (Left) (R.D.)	$\frac{7.75}{2.00}$
24106	Running Board Complete (Right)	4.50	24246 24247	Steering Knuckle Arm (Right) Steering Knuckle Arm (Left)	4.00
24107			24248	Steering Knuckle Arm (Right) (R.D.)	4.50
24109 24110			24249	Steering Knuckle Arm (Left) (R.D.).	
24111			24250	Front Brake Dust Cover	
24112	Hub Cap Wrench	75	24251	Front Control Lever (Left)	
24113	Insulator Housing (Left Rear)	60	24252		
24114	Insulator Housing (Right Rear)	60	24253		
24115	Door Complete (Left Front) Upon Ap	plication		Assembly	7.00
24116	Door Complete (Right Front)	plication		Note: Brake Shoe Assembly returned for relining will be accepted for full credit less a	354.50
04117	Upon Ap Door Complete (Left Rear) Upon Ap	plication		charge of \$2.50 list for relining.	
24117 24118		pheation	24254	Primary and Auxiliary Shoe Lining	. 45
24110	그는 그렇게 그렇게 그는 가는 그는 얼마를 가는 어느 없는 것이 없는 것이다.	plication	24255	Secondary Shoe Lining	75
24123	Top Less Curtains	70.00	24256		
24124	Top Deck	9.00	24257	Secondary Shoe Spring	
24125	Left Front Side CurtainUse N	o. 24837	24258		08 01
24126		0. 24836	24259		
24127	Left Rear Side Curtain Use N	10. 24839	24260 24261		
24128		Jo 24840	24262		
24129 24130		3.25	24263		03
24131	Gypsy Curtain (Left)	3.25	24264	Brake Cam Shaft Spring	07
24132	Hand Lever Pull Rod (R.D.)	65	24265	Brake Cam Shaft Bolt	08
24133	Pedal Pull Rod (R.D.)	65	24266	Front Brake Backing Plate (Right)	4.00
24134		\dots 2.70	24267	Front Brake Backing Plate (Left)	. 4.00

Part No.	Part Name	Price	Part No.	Part Name	Price
24268	Rear Brake Backing Plate (Right)	\$4.00	24348	Spark Lever (Lower)	\$0.09
24269 24273	Rear Brake Backing Plate (Left) Brake Shoe Spacer Pin Washer	4.00	24349 24350	Throttle Lever (Lower).	.09
24274	Brake Reinforcement Plate Comp.	AG F F I	24351	Rear Axle Housing (Right Half) Rear Axle Housing (Left Half)	15.75
	(Inner)	.60	24352	Frame Complete	38.00
24275 24277	Brake Reinforcement Plate (Outer) Brake Anchor Pin Link	:11	24353 24354	Front Cross Member	1.75
24278	Brake Articulating Pin	.19	24355	Front Spring Horn (Right) Front Spring Horn (Left)	$\frac{1.10}{1.10}$
24279	Brake Articulating Pin Spring	.01	24356	Rear Spring Horn (Right)	1.60
24280	Front Articulating Pin Washer	.02	24357	Rear Spring Horn (Left)	1.60
24281 24282	Front and Rear Brake Take Up Cam. Front Axle Tie Rod	2.50	24358 24359	Rear Spring Bracket	.80
24283	Tie Rod Adjustable Socket	.80	24360	Exhaust Pipe Exhaust Pipe Support	$\frac{1.50}{.10}$
24284	Rear Axle Housing (Right Half)	14.75	24361	Muffler	2.40
24285	Rear Axle Housing (Left Half) Rear Brake Control Lever (Right)	14.75	24362	Muffler Tail Pipe	. 65
24286 24287	Rear Brake Control Lever (Right) Rear Brake Control Lever (Left)	.90	24363 24364	Motor Underpan (Left)	.80
24288	Brake Shoe Roller Pin	.14	24365	Motor Underpan (Right) Motor Underpan (Left) (R.D.)	.80 .75
24289	Rear Cam Shaft Retaining Washer	.02	24366	Motor Underpan (Right) (R.D.)	.75
24290	Bearing Adjusting Nut Lock	.05	24367	Motor Underpan, Front	. 65
24291 24292	Front Wheel Complete	$9.50 \\ 5.50$	24368	Front Fender (Right)	15.00
24292	Front Wheel	2.25	24369 24370	Front Fender (Left) Radiator Splash Apron	$\frac{15.00}{3.00}$
24296	Front Wheel Inner Bearing	3.25	24371	Side Apron (Left)	3.50
24297	Front Wheel Felt Retainer (Inner)	.05	24372	Side Apron (Right).	3.50
24298 24299	Front Wheel Felt Retainer (Outer) Felt Washer	.05	24373	Running Board (Left).	4.15
24233	Rear Wheel Complete	9.50	24374 24375	Running Board (Right) Hood Complete	4.15
24301	Rear Wheel (Wood)	5.50	24376	Hood Complete	19.00
24302	Rear Wheel Brake Drum		24377	Transmission Case	5.75
24303 24304	Front Wheel Complete Demountable Rim	9.50	24378	Transmission Case Cover	3.30
24304	Demountable Rim Bolt	$\frac{2.25}{.10}$	24379 24380	Transmission Case Cover (R.D.) Hand Brake Lever Stud	3.60
24306	Demountable Rim Bolt Nut.	.05	24381	Gear Shift Lever	$\begin{array}{c} .16 \\ 1.25 \end{array}$
24307	Demountable Rim Wedge	. 10	24382	Gear Shift Lever Spring	.05
24308 24309	Demountable Rim Lock Stud Radiator Splash Apron	.15	24383	Gear Shift Lever Spring Retainer	.05
24310	Running Board (Right)	$\frac{3.00}{4.00}$	24384 24385	Gear Shift Lever Cover Shifter Fork (Low and Reverse)	$\frac{.30}{1.00}$
24311	Running Board (Left)	4.00	24386	Shifter Fork (High and Intermediate)	1.00
24312	Rear Fender (Right)	6.75	24387	Gear Shift Lever Pin (Short)	.04
24313 24314	Rear Fender (Left)	$\frac{6.75}{3.00}$	24388 24389	Gear Shift Lever Pin (Long)	.04
24315	Side Apron (Left)	3.00	24390	Transmission Interlock Plate. Main Drive Gear.	$\frac{.14}{5.25}$
24316	Front Wheel	5.50	24391	Main Drive Gear Bushing	.25
24317 24318	Rear Wheel Complete	9.50	24392	Transmission Bearing Retainer (Front)	1.50
24318	Rear Wheel. Demountable Rim	$\frac{5.50}{2.50}$	24393 24394	Speedometer Gear Housing Clutch Plate with Hub	1.30
24320	Front Axle Tie Rod	2.15	24395	Clutch Cover Plate Use No.	4.75
24321	Tie Rod Adjustable Socket (Left)	.80	24396	Clutch Cover Plate	6 25
24322 24323	Tie Rod Adjustable Socket (Right) Tie Rod Clamp	. 80 . 50	24397 24398	Clutch Pressure Ring.	2.90
24324	Tie Rod Ball Seat Spring	.04	24399	Clutch Pressure Ring. Clutch Pressure Ring Drive Pin	$5.40 \\12$
24325	Tie Rod Spring Seat	.06	24400	Clutch Pressure Ring Bolt	.12
24326	Tie Rod Ball Stud Bearing.	.25	24401	Clutch Adjusting Nut	.30
24327 24328	Worm Wheel and Shaft	$\frac{2.60}{3.00}$	24402 24403	Clutch Spring.	.12
24329	Steering Gear Worm	1.00	24404	Clutch Spring Retainer. Clutch Lifting Lever.	.08 .80
24330	Steering Gear Worm (R.D.)	.90	24405	Clutch Lifting Lever Spring	.14
24331 24332	Steering Gear Worm Key Steering Gear Main Tube with Silencer	2.60	24409	Propeller Shaft with Yoke End	9.00
24333	Steering Gear Worm Adjusting Nut	2.60	24410 24411	Clutch Housing (R.D.)	7.75
24334	Worm Adjusting Nut Spacer	. 60	24412	Clutch Housing Cover	$7.75 \\ 3.15$
24335	Worm Adjusting Nut Spacer Bushing	.25	24413	Clutch Bearing Oil Pipe.	.16
24336 24337	Frame Complete	38.00	24414	Clutch Pedal	1.25
24338	Step Hanger (Center)	.45	24415 24416	Clutch Pedal (R.D.). Pedal Return Spring.	1.25
24339	Step Hanger (Left Rear)	.45	24417	Pedal Shaft	.10 .90
24340	Front Spring	3.25	24418	Clutch Shaft Yoke	1.75
24341 24342	Rear Spring.	5.50 7.50	24419 24420	Clutch Shaft Operating Rod	.10
24344	Fan Hub	1.75	24420	Clutch Shaft Swivel	.20 .75
24345	Fan Spindle	1.35	24422	Clutch Operating Shaft Washer	.05
24346 24347	Drive Pinion and Shaft	7.00	24423	Clutch Shaft Operating Lever.	.90
24041	Ring Gear	7.00	24424	Clutch Shaft Operating Lever (R.D.)	1.10

Part No.	Part Name	Price	Part No.	Part Name	Price
24425	Universal Joint Flange Gasket	\$0.06	24503	Chain Cover Gasket	\$0.07
24426	Hand Lever	1.50	24504 24505	Chain Cover Stud Ose No. Chain Cover Oil Retainer Packing	20004
24427 24428	Hand Lever (R.D.)	.40	24000	(Cork)	.06
24429	Hand Lever Latch Rod (R.D.)	. 50	24506	Crankshaft SprocketGenerator Sprocket	2.35
24430	Hand Lever Ratchet	1.25	24507 24508	Generator to Motor Plate Gasket Use No	.26090
24431 24432	Foot Pedal (R.D.)	1.25	24509	Crankshaft Oil Thrower	. 10
24432	Brake Cross Shaft	1.75	24510	Starting Jaw Lock Washer	.14
24434	Brake Cross Shaft (R.D.)	1.60	24511 24512	Crankshaft Spacing Washer Crankshaft Pilot Bearing	1.30
24435 24436	Brake Cross Shaft Felt Washer Brake Cross Shaft Felt Washer Spring.	.02 $.03$	24513	Crankshaft Pilot Bearing Retainer	.05
24436	Brake Cross Shaft Washer (Steel)	.02	24514	Fly Wheel	14.50
24438	Brake Cross Shaft Bearing Plate	. 14	24515 24516	Fly Wheel HousingFly Wheel Housing Dust Cover	.30
24439	Brake Cross Shaft Bracket (Center) Brake Cross Shaft Lever (Inner)	$\begin{array}{c} .10 \\ .40 \end{array}$	24517	Fly Wheel Pointer	.07
24440 24441	Brake Cross Shaft Lever (Outer)	5 - 25 - 4 - 4 - 1	24518	Oil Pan Complete	3.75
24442	Brake Idler Lever (Front)	. 60	24519	Oil Pan GasketOil Pan Trough Complete	3.75
24444	Brake Idler Lever (Rear)	$.35 \\ .40$	24520 24521	Oil Pan Screw	.04
24445 24446	Brake Pedal Pull Rod Hand Brake Pull Rod	.30	24522	Front Motor Bolt	.06
24447	Front Brake Rod (Rear)	. 35	24523	Front Motor Insulator (Lower) Front Motor Insulator (Upper)	.15
24448	Front Brake Rod (Front)		24524 24525	Front Motor Insulator Washer	.04
24449 24450	Rear Brake Rod (Rear)		24526	Rear Motor Bracket Plate	.12
24451	Hood Sill (Left)	1.30	24527	Rear Motor Bracket Plate Insulator	.25
24452	Hood Sill (Right)	$1.30 \\ .05$	24528 24529	Rear Motor Insulator (Rubber) Oil Valve Relief Gasket	.02
24453 24454	Hood Sill Spacer	11.00	24530	Oil Tube Union Nut	61. LD
24455	Cylinder Block	115.00	24531	Water Pump Body	5.00 3.50
24456	Valve Tappet Guide	1.60	24532 24533	Front Spring Tire Carrier Bracket (Left)	.60
24457	Oil Filler Body CompleteOil Filler Cover Complete	1.00	24534	Tire Carrier Bracket (Right)	. 60
24459 24461	Piston (Standard)		24535	Tire Carrier Bracket (Left)	60
24462	Piston (.003" oversize)	4.00	24536	Tire Carrier Bracket (Right) Tire Carrier Tie Bar	
24463	Piston (.005" oversize) Piston (.010" oversize)	4.00	24537 24538	Tire Carrier Clamp Screw	15
24464 24465	Piston (.015" oversize)	4.00	24539	Tire Carrier Rim Clamp	11
24466	Piston (.020" oversize)	4.00	24541	Demountable Rim ToolPitman Arm	1.60
24467	Piston (.023" oversize) Piston (.025" oversize)	$\begin{array}{c} \cdot & 4.00 \\ \cdot & 4.00 \end{array}$	24542 24543	Main Tube with Silencer	2.60
24468 24469		4.00	24544	Main Jacket with Bushing	. 1.60
24470	Piston (.035" oversize)	4.00	24545	Mast Jacket with Bushing (R. D.) Control Tube with Base	1.00
24471	Piston Ring (Plain) (Standard)	20	24546 24547	Control Tube with Base (R. D.)	. 1.05
24472 24473	Piston Ring (Plain) (010" oversize)	20	24548	Throttle Control Tube with Lever	. 1.10
24474	Piston Ring (Plain) (.015" oversize)	20	24549	Throttle Control Tube with Leve (R. D.)	. 1.10
24475	Piston Ring (Plain) (.020" oversize)	20	24550	Cross Shaft Bearing Plate Washer	02
24476 24477	Piston Ring (Plain) (.030" oversize)	20	24551	Radiator Drain Cock	25
24478	Piston Ring (Plain) (.035" oversize)		24552	2 1 C 1 1 1 1 1 T (D 1)) 1.15
24479	Piston Ring (Standard)	25	24553 24554	Hand Brake Lever Rod	35
24480 24481		25	24555	Brake Pedal Rod	40
24482	Piston Ring (.015" oversize)	25	24556		. 1.30
24483	Piston Ring (.020" oversize)	$\begin{array}{ccc} . & .25 \\ . & .25 \end{array}$	24557 24559	Horn Wire Complete	
24484 24485		0 -	24560	Main Tube with Silencer (R.D.)	. 2.70
24486	Piston Ring (.035" oversize)	25	24561		09
24487	Piston Pin (Standard)	40	24562 24563	Fan Blades	. 1.10
24488 24489			24564	Fan Hub	. 1.00
24489	Crankshaft	. 45.00	24565	Fan Spindle	. 1.25
24491	Bearing Cap Stud (Front and Inter.)		24566 24567	Motorstat Complete	. Z.U
24492		1.60	24568	Motorstat Housing	
24493 24494		02	24569	Motorstat Housing Gasket	02
24495	Crankshaft Starting Jaw	1.00	24570 24571	Heat Indicator	. 2.0
24496		$\begin{array}{ccc} 6.75 \\ 1.95 \end{array}$	24572	Host Indicator Element	. 1.98
24497 24499	Front Motor Support Plate	. 3.10	24573	Radiator Complete	50.00
24500	Front Motor Support Bracket	50	24578 24576	Radiator Shell	18.00
24501		20	24580		lo. 2636
24502	chain Cover Complete	1.00			

Part No.	Part Name	Price	Part No.	Part Name Price
24581	Radiator Filler Cap Gasket	\$0.07	24679	Rear Top Apron (Left)\$1.40
24582	Radiator Filler Cap Washer	. 05	24680	Rear Top Apron (Right) 1 40
24584 24588	Starting Crank Hole Cover	.20	24681	Rear Apron Spacer 03
24589	Radiator Complete (Rugby)	39 00	24682 24683	Sedan Body Complete Upon Application
24590	Radiator Core	26.00	24000	Sedan Body Complete (R.D.) Upon Application
24591	Radiator Shell	16 00	24684	Door Complete (Right) (Front)
24592	Radiator Shell (Rugby)	15.00		Unon Application
24593 24594	Radiator Name Plate	.60	24685	Door Complete (Left) (Front)
24594	Throttle Control Wire	.03	24686	Door Could (Bill) Upon Application
24596	Radiator Filler Cap	2.25	24000	Door Complete (Right) (Rear)
24597	Radiator Filler Cap Spring Washer	09	24687	Door Complete (Left) (Rear)
24598	Radiator Hood Rod Bracket	.25		Unon Application
24599	Demountable Rim Wedge	.10	24688	Door Glass (Front) 5 50
24600 24601	Demountable Rim Bolt	.06	24689 24690	Door Glass (Rear)
24602	Accelerator Rod	.05	24691	Rear Quarter Glass 5.00 Front Seat Cushion 22.00
24603	Spark Control Rod Cross Shaft	. 15	24692	Rear Seat Cushion 22.00 Rear Seat Cushion 22.50
24604	Spark Control Rod Cross Shaft Lever	.05	24693	Back Window Curtain 9 40
24605	Spark Control Rod (Upper)	.10	24694	Front Floor Mat. 2 15
24606 24607	Spark Control Rod (Lower)	.14	24695	Front Door Mat (R.D.)
24608	Hex. Head Cap Screw	.03	24696 24697	Rear Floor Carpet. 5.00 Left Rear Door Hinge (Upper) 60
24609	Gasoline Tank	8.00	24698	Right Rear Door Hinge (Upper)
24610	Gas Gauge	50	24699	Left Front Door Hinge (Lower) 60
24611	Gas Gauge Cap	.11	24700	Right Rear Door Hinge (Upper) 60
24612 24613	Gas Gauge Gasket (Upper)	.01	24701	Left Rear Door Hinge (Center) 60
24614	Gas Gauge Glass.	$.02 \\ .03$	24702 24703	Right Front Door Hinge (Lower) 60 Left Rear Door Hinge (Lower) 60
24615	Gasoline Tank Support Complete	3.40	24704	Right Rear Door Hinge (Lower)
24616	Manifold	11 25	24705	Left Front Door Lock with Control
24617 24619	Manifold Gasket		38 E	Arm 1 50
24620	Carburetor Choke Complete	$\frac{1.00}{1.00}$	24706	Right Front Door Lock with Control
24621	Carburetor Choke Knob	.20	24707	Arm
24622	Carburetor Choke Housing	.35	24708	Right Front Door Hinge (Upper) 35
24623	Carburetor Choke Mounting Plate	.15	24709	Left Front Door Hinge (Center) 35
24624 24625	Head Lamp Tie Bar Reinforcement	.90	24710	Right Front Door Hinge (Center) 25
24020	(Left)	.18	24711 24712	Clutch Shaft Operating Rod (R.D.) 10
24626	Head Lamp Tie Bar Reinforcement	.10	24713	Door Hinge Pin. 02 Regulator Handle Rubber. 02
'Wal	(Right)	.18	24714	Front Spring Horn (Right) 1 50
24627	Carburetor Choke Complete	. 60	24715	Front Spring Horn (Left)
24628 24631	Horn Throttle Control Wire	3.75	24716	Door Complete (Right) Upon Application
24632	Spark Control Tube Complete	$03 \\ 1.15$	24717 24718	Door Complete (Left) Upon Application
24633	Throttle Control Tube Complete (R.D.)	.60	24719	Door Glass 5.00 Seat Cushion (Coupe) 22.00
24634	Spark Control Tube Complete (R.D.)	55	24720	7 100r Mat 9 15
24645 24646	Speedometer Drive Gear	3.00	24721	100r Mat (R.D)
24647	Speedometer Drive Pinion. Frame Complete (R.D.).	$\frac{2.10}{37.00}$	24722 24723	Right Door Lock with Control Arm 1 50
24648	Lighting Switch	2.00	24724	Left Door Lock with Control Arm. 1.50 Cowl Ventilator Lever
24649	Foot Dimmer Switch	80	24725	Deck Door Lock Striker Plate
24650	Ignition Lock with Wiring and Key	4.75	24726	Coupe Body Complete Unon Application
24651 24652	Battery Hanger. Battery Clamp (Rear)		24727	Coupe Body Complete (R.D.)
24653	Battery Clamp (Front)	.12	24728	Front Spring Polt Leals Upon Application
24654	Ammeter	1.50	24729	Front Spring Bolt Lock
24655	Horn	5 00	24730	Sedan Body Complete (R.D.)
24656 24657	Horn BracketGasoline Tank	.20	0.4701	IInon Application
24659	Gasoline Gauge Terminal (Left)	10.00	24731 24732	Door Complete (Left) IInon Application
24660	Gasoline Gauge Terminal (Right)	.05	24732	Door Complete (Right)Upon Application Rear Quarter Glass
24668	Starting Motor Ground Strap Washer	.01	24734	Driver's Auxiliary Seat Complete 20 00
24669	Starting Motor Cover	.40	24735	Driver's Auxiliary Seat Complete
24671 24672	Rubber Grommet. Oil Pressure Gauge.	.03	94790	(R.D.) 20.00 Passenger Auxiliary Seat Complete 20.00
24673	Oil Pressure Gauge Pipe	50	24736 24737	Passenger Auxiliary Seat Complete. 20.00
24674	Gasoline Gauge Complete	2 00	24738	Passenger Auxiliary Seat Comp.(R.D.) 20.00 Rear Seat Cushion
24675	Speedometer Drive Gear	3.00	24739	Rear Floor Carpet
24676	Speedometer Drive Pinion	2.10	24740	Rear Floor Carpet (R.D.) 5 00
24677 24678	Rear Side Apron (Left)	.75	24741	Seat Back Bracket Complete (Left) 1 00
	Trong Side Lipton (1018110)	. (0	24742	Seat Back Bracket Complete (Right). 1.00

Part No.	Part Name	Price	Part No.	Part Name	Price		
24743	Front Spring Bolt	\$0.30	24860	Carburetor Choke Shutter	\$.10		
24744	Hood Complete	16.00	24861	Carburetor Wire Tube Clamp Bracket	.30		
24745	Hood Complete	16.00	24862	Carburetor Choke Cam	.25		
24746	Hood Sill (Right)		24863	Carburetor Choke Cam Lever	.20		
24747	Hood Sill (Left)	1.35	24864	Carburetor Choke Lever Pinion Screw	.10		
24748	Motor Underpan (Right)	.80	24865	Carburetor Economizer Valve	.35		
24749	Motor Underpan (Left)	.80 .75	24866	Carburetor Economizer Lift Lever	. 50		
24750	Motor Underpan (Right) (R.D.) Motor Underpan (Left) (R.D.)	75	24867	Carburetor Economizer Valve Spring.	.05		
24751 24754	Motor Underpan (Front)	.40	24868	Carburetor Economizer Adjusting Nut	.10		
24756	Rear Spring Clip	.25	24869	Economizer Lever Pinion Screw	.10		
24757	Tail and Stop Lamp Complete		24870	Carburetor Economizer Valve Washer.	.05		
24759	Tail and Stop Light Lens	.35	24871	Carburetor Pump Plunger Assembly	.90		
24760	Stop Light Switch	. 55	24872	Carburetor Pump Overflow Chamber.	.30		
24761	Windshield Frame and Glass Comp		24873	Carburetor Pump Nozzle	.25		
24762	Windshield Swing Arm Complete	3.35	24874	Carburetor Air Bleed Screw	.25		
24763 24764	Windshield Swing Arm Bumper Windshield Swing Arm Screw (Male)	.03	24875	Carburetor Air Bleed Restriction Screw	.10		
24765	Windshield Swing Arm Screw (Female)		24876	Carburetor Body Upper Half Assembly	5.00		
24766	Windshield Weatherstrip (Lower)	F C7 13 Server	24877	Carburetor Throttle Lever Shaft	.25		
24767	Windshield Swing Arm Knob (Male)	.40	24878	Carburetor Air Horn Assembly	4.50		
24768	Windshield Swing Arm Knob (Female)		24879	Carburetor Choke Lever	.30		
24769	Touring BodyUpon Appl	ication	24880	Carburetor Choke Shaft	.25		
24770	Touring Body (R.D.)Upon Appl		24881	Carburetor Choke Shutter	. 10		
24771	Instrument Board		24882	Carburetor Wire Tube Clamp Bracket.	.30		
24772 24777	Windshield Bracket (Left)		24883	Carburgtor Choke Cam	.25		
24778	Windshield Bracket (Right)	1.10	24884	Carburetor Choke Cam Lever	1.00		
24779	Front Seat Cushion		24885	Carburetor Pump Plunger Assembly.	5.50		
24780	Rear Seat Cushion		24886	Front WheelWindshield Complete	The state of the s		
24785	Front Floor Mat	2.15	24887	Windshield Complete (R.D.)			
24786	Front Floor Mat (R.D.)		24888 24889	Windshield Glass	12.00		
24787	Rear Floor Carpet		24890	Windshield Side Arm (Right)	1.00		
24797	Service Brake Cross Shaft Service Brake Cross Shaft (R.D.)		24891	Windshield Side Arm (Left)	1.80		
24798 24799	Brake Cross Shaft Bracket (Center)		24892	Hoodlamn Glass Clip	.07		
24800	Brake Idler Lever (Right Front) (R.D.)	. 60	24893	Headlamp Connector Plug Socket	1.85		
24801	Brake Pedal Pull Rod	.35	24894	Windshield Side Arm (Right) Windshield Side Arm (Left)	1.85		
24802	Brake Pedal Pull Rod (R.D.)		24895 24896	Tire Carrier Tie Bar			
24803	Hand Brake Pull Rod	.30	24897	Tail and Stop Lamp	4.00		
24804	Front Brake Rod (Rear)Use No	. 24447	24898	Tail Lamp Bracket	4.10		
24805	Front Brake Rod (Rear) (R.D.) Front Brake Rod (Right Front) (R.D.)		24899	Toil Lamn Semaphore	.00		
24806 24807	Rear Brake Rod (Front)	30	24901	Tail Lamn Lower Lens	. 20		
24822	Ignition Lock Key	25	24902	Clutch Thrust Bearing			
24823	Convertible RoadsterUpon App	lication	24903	Hub CapGasoline Tank Complete			
24824	Convertible Roadster Body (R.D.)		24904	Gasoline Tank Complete			
Int. Tr	Upon App	lication	24905 24906	Tail Lamp Stop Lens	. 50		
24825	Left Door Complete	16.00	24907	Running Board Moulding (Outer)	.35		
24826 24827	Right Door CompleteSeat Cushion	9.00	24908	Running Board Moulding (Inner)	00		
24828	Right Door Upholstery	1.50		(Right)	.30		
24829	Left Door Upholstery	1.50	24909	Running Board Moulding (Inner)	.30		
24834	Top Complete Less Curtains	45.00	63010	(Left) Dash Body Bracket	.50		
24835	Top Deck	8.00	24912		270.0		
24836	Right Front Side Curtain		24913	Upon App	lication		
24837	Left Front Side Curtain	$\frac{4.00}{1.75}$	24914	Door Complete (Right Front)	PHILL		
24838	Right Rear Side Curtain	45 5 12 12 12 12	10179	Linon App.	lication		
24839 24840	Back Curtain Complete		24915	Door Complete (Left Rear) Upon App.	lication		
24841	Seat Cushion	. 14.00	24916	Door Complete (Right Rear) Upon App	lication		
24842		. 14.00	0.404	Tondlo	1.00		
24843	Left Door Upholstery	1.00	24917		.30		
24844	Right Door Upholstery	1.00	24918 24919	Door Glass (Front)	0.00		
24847	Rear Spring Snubber Clip	20	24919	Door Close (Roar)	4.10		
24848	Front Spring Snubber Clip	0.15 0.50	24921	Front Soot Cushion	20.00		
24849		5.00	24922	Poor Soat Cushion	41.00		
24850 24851		75	24923	Back Window Curtain	4.00		
24853		. 24141	24924	Robe Rail Complete			
24855	Carburetor Accelerator Lever	50	24925		2.15		
24857	Carburetor Air Horn Assembly	. 4.50	24926	Front Floor Mat (R. D.)	4.00		
24858		. 1.00	24927 24928		4.75		
24859	Carburetor Choke Shaft	25	24720	Trout Trot on Francisco			

Part No.	Part Name	Price	Part No.	Part Name	Price
24929	Outside Door Handle	\$1 00	25003	Rear Floor Carpet (R.D.)	
24930	Outside Door Handle (With Key)	2 20	25004	Door Glass Upper Bumper (Felt)	
24931	Door Lock Handle (Inside)	.80	25005	Rear Quarter Glass Upper Bumper	$05 \\ 05$
24932	Dummy Prop Iron (Right)	1.85	25006	Door Window Moulding (Upper)	.60
24933	Dummy Prop Iron (Left)	1.85	25007	Left Window Moulding (Lower)	.70
24935 24936	Dummy Prop Iron Spacer (Lower)	.11	25008	Right Window Moulding (Lower)	.70
24937	Dome Lamp Reflector	1.40	25009	Left Window Side Moulding (Front)	. 50
24938	Dome Lamp Glass Retaining Ring	$.25 \\ .20$	25010	Right Window Side Moulding (Front)	. 50
24939	Left Front Door Moulding	3.35	25011 25012	Window Moulding Door and Rear Quarter Window Moul-	. 50
24940	Right Front Door Moulding.	3.35	25012	ding	
24941	Rear Door Moulding	3.35	25013	dingQuarter Window Moulding (Upper)	. 50
24942	Door Glass Lower Bumper	.02	25014	Quarter Window Moulding (Lower)	.80
24943	Door Glass Upper Bumper	.05	25015	Accelerator Rod (R.D.)	.25
24944	Door Glass Felt	.10	25016	Spark Control Rod, Lower (R.D.)	.11
24945 24946	Demountable Rim Tool	. 60	25017	Spark Control Rod, Upper (R.D.)	.10
24947	Front Wheel Complete	9.50	25018	Throttle Operating Rod, Lower (R.D.)	.12
24948	Front Wheel	$9.50 \\ 5.50$	25019 25020	Throttle Operating Rod, Upper (R.D.)	.12
24949	Rear Wheel	5.50	25021	Throttle Cont. Rod Cross Shaft (R.D.) Control Rod Cross Shaft Bracket	.25
24952	Door Complete (Right Front)	0.00	20021	(R.D.) Bracket	the second second
	Upon Appli	cation	25024	Door Complete—Right Upon Appl	.35
24953	Door Complete (Left Front)		25025	Door Complete—Left. Ilpon Appl	ication
04054	Don Good La Chi La D	ication	25026	Door Glass (Coupe)	24718
24954	Door Complete (Right Rear)	1275 7 1	25027	Seat Cushion (Coune)	28 00
24955	Upon Appli Door Complete (Left Rear) Upon Appli	cation	25028 25029	Rumble Seat Cushion	22.00
24956	Rear Quarter Window Reg. Handle	1.25	25029 25030	Deck Floor Carpet.	
24957	Rear Quarter Window Curtain	3.85	25030	Deck Door Lock Spark Control Idler Lever (R.D.)	.70
24958	Door Glass Upper Bumper	.06	25032	Throttle Cross Shaft Lever (R.D.)	.30
24959	Rear Quarter Glass Upper Bumper	.06	25033	Motor Underpan, Left (R.D.)	$.40 \\ .75$
24960	Door and Rear Quarter Glass Felt	.10	25034	Throttle Lever—Lower	07
24961	Left Front Door Moulding	3.15	25037	Door Comp. with Glass—Left	
24962 24963	Right Front Door Moulding Left Rear Quarter Moulding	3.15	95090	Des C Upon Appli	cation
24964	Right Rear Quarter Moulding	$\frac{3.15}{3.15}$	25038	Door Comp. with Glass—Right	BATTER
24965	Rear Door Moulding	3.15	25039	Door Glass	cation
24966	Headlamp Complete	9.00	25040	Seat Cushion	19 00
24967	Headlamp Complete	9.50	25042	Tire Cover	2 50
24970	Headlamp Reflector		25044	Prop Iron Spacer	20
24971 24972	Headlamp Reflector. Auxiliary Reflector Complete	2.40	25045	Prop Iron Stud (Upper)	14
24975	Headlamp Rim	2 60	25046 25047	Back Curtain.	13.00
24976	Headlamp Rim Lock Ring	.40	25049	Top Complete Less Slat Irons. Brake Pedal Pull Rod (R.D.)	
24977	Headlamp Rim Lock Ring Screw	Part	25051	Gasoline Filter	$\frac{.50}{2.00}$
0.40=0	Use No.		25052	vacuum Tank Filter Plug	06
24978	Headlamp Gasket		25054	Tire Carrier Complete	5 00
24979 24980	Headlamp Lens Headlamp Reflector Screw	1.90	25055	Tire Carrier Complete	5 00
24981	Headlamp Reflector Screw Spring	.14	25056 25058	Tire Carrier Stud.	.25
24982	Headlamp Connector Socket	1.05	25059	Windshield Complete (R.D.)	25.00
24983	Headlamp Connector Socket	1.50	25060	Windshield Side Arm (Right)	9 00
24984	Cowl Lamp Complete (Right)	3.25	25061	Windshield Side Arm (Left)	3 00
24985	Cowl Lamp Complete (Left)	3.25	25063	windshield Complete	30 00
24986	Cowl Lamp Rim Fastening Screw	.03	25064	Windshield Complete (R. I)	30.00
24987 24988	Cowl Lamp Rim and Glass		25065	Tire Carrier Bracket, Left	.75
24989	Rear Floor CarpetBacking Plate Bolt	4.75	25066 25068	Tire Carrier Bracket, Right	.75
24990	Sedan Body Complete Upon Appli	cation	25069	Hood Hinge Bracket—Front. Use No. Tail Lamp Bracket Complete (R.D.).	
24991	Sedan Body Complete (R.D.)	a reid	25070	Head Lamp Connector Plug	2.50
	Upon Applie	cation	25071	nead Lamp Connector Plug	16
24992	Door Complete with Glass (Right)		25074	Right Front Door Complete	16 50
24993	Upon Applic Door Complete with Glass (Left)	cation	25075	Left Front Door Complete	16 50
24333	Upon Applie	antion	25076	Right Rear Door Complete	16 50
24994	Rear Quarter GlassUse No.	24733	25077 25080	Left Rear Door Complete. Front Seat Cushion.	16.50
24995	Driver's Auxiliary Seat Complete	29.50	25081	Rear Seat Cushion.	14.00
24996	Driver's Auxiliary Seat Comp. (R.D.).	28.50	25082	Right Front Door Upholstery	1.00
24997	Passenger's Auxiliary Seat Complete.	29.50	25083	Left Front Door Upholstery	1.00
24998	Passenger's Seat Complete (R.D.)	28.50	25084	Right Rear Door Unholstery	1.00
24999 25000	Rear Seat Cushion	29.00	25085	Left Rear Door Upholstery	1.00
25001	Front Floor Mat (R.D.)	2.15	25086 25087	Front Floor Mat	2.15
25002	Rear Floor Carpet	6.25	25088	Front Floor Mat (R.D.)	2.00
	The second section of the second seco	10 m Act	2 to 8 1	Carpet Use No.	44101

Part No.	Part Name	Price	Part No.	Part Name Price
25089	Headlamp Connector Plug Cap	\$0.09	25201	Brake Pedal Rod \$0.35
25090	Instrument Panel Switch	.75	25202	Brake Pedal Rod (R.D.)
25091	Instrument Panel Switch Knob	.25	25203	Hand Brake Rod
25092 25093	Connecting Rod Comp.(.010"undersize) Connecting Rod Comp.(.020"undersize)		25204 25205	Accelerator Rod
20000			25206	Throttle Operating Rod (R.D.)
	Note: Rod returned for new bearing will be accepted at full credit less a charge of \$2.00		25207	Accelerator Lever (R.D.)
	list for a new bearing.		25208	Accelerator Rod, Front (R.D.)
25094	Propeller Shaft	7.50	25209	Accelerator Shaft, Front (R.D.)
25095 25096	Universal Joint Yoke Use No. Inside Casing (Axle End)	.65	25210 25213	Accelerator Shaft, Rear (R.D.)
25097	Inside Casing (Transmission End)	.65	25214	Door Complete, Right Front Upon Application
25098	Outside Casing with Packing (AxleEnd)		25215	Door Complete, Left Rear Upon Application
25099	Outside Casing (Transmission End)		25216	Door Complete, Right Rear Upon Application
07100	Use No		25217	Door Glass, Front
25100 25101	Casing Spring (Axle End)	$.06 \\ .12$	25218 25219	Door Glass, Rear
25102	Casing Spring Retainer Lock Ring		25220	Rear Seat Cushion
W. B	(Axle End)		25221	Front Floor Mat 2.15
25105	Left Door	16.00	25222	Rear Floor Carpet
25106	Right Door	16.00	25223	Front Floor Mat (R.D.) 2.00
25107 25109	Step Plate (Upper) Seat Cushion		25224 25225	Sedan Body CompleteUpon Application Sedan BodyComplete(R.D.)Upon Application
25110	Demountable Rim		25226	Front Floor Mat
25111	Hub Cap Wrench	.35	25227	Front Floor Mat (R.D.)
25112	Cowl Moulding, Top	2.50	25228	Coupe Body Complete Upon Application
25113 25114	Cowl Moulding, Side (Left)	$\frac{1.25}{1.25}$	25229 25230	Coupe Body Comp. (R.D.) Upon Application Sedan Body CompleteUpon Application
25115	Cowl Moulding, Side (Right) Cowl Moulding Washer	.02	25231	Sedan Body Comp. (R.D.). Upon Application
25116	Cowl Moulding Washer	. 03	25232	Touring BodyUpon Application
25117	Cowl Lamp Bracket, Left	1.00	25233	Touring Body (R.D.)Upon Application
25118	Cowl Lamp Bracket, Right	1.00	25234	Front Floor Mat
25119 25120	Cowl Lamp Bracket Nut		25235 25236	Front Floor Mat (R.D.) 2.00 Headlamp Complete 5.75
25121	Windshield Complete (R.D.)		25237	Headlamp Rim
25122	Rubber Grommet	.02	25238	Headlamp Rim Lock Ring
25123	Instrument Board		25239	Headlamp Gasket
25124 25125	Back Window CurtainBack Window Curtain	$\frac{4.00}{4.00}$	25240 25245	Headlamp Lens
25136	Windshield Swing Arm Complete		25246	Wind Deflector Inside Clamp 1.00
25137	Windshield Swing Arm Knob (Male)		25247	Wind Deflector Outside Clamp 1.15
	Use No.		25248	Wind Deflector Rubber Pad
25138	Windshield Swing Arm Knob (Female)		25249 25250	Wind Deflector Acorn Nut
25139	Hub Cap		25251	Wind Deflector Clamp Screw
25140	Rear Fender, Right	9.00	25252	Wind Deflector Headless Set Screw 10
25141	Rear Fender, Left	9.00	25253	Wind Deflector Friction Bolt
25142 25143	Steering Gear BracketUse No.		25254	Water Outlet Pipe
25144	Motor Underpan, Left		25255 25256	Starter Strap, Upper
25145	Rear Side Apron, Left (R.D.)		25257	Cylinder Block
25146	Pinion Housing	2.70	25258	Radiator Complete (Rugby) 42.00
25147	Pinion Roller Bearing		25260	Bumper Bracket Cap
25148 25149	Rear Axle Truss Rod		25262 25263	Bumper Bracket, Left 1.25
25150	Carburetor Nozzle		25264	Bumper Bracket Spacer, Right25
25151	Carburetor Throttle Shutter	.25	25265	Bumper Bracket Spacer, Left
25165	Cylinder Head	7.35	25272	Headlamp Complete 7.75
25181 25182	Windshield Complete	29.75	25273 25274	Headlamp Reflector
25187	Windshield Complete (R.D.) Left Door Upholstery	1.00	25275	Cowl Moulding, Side (Reft)
25188	Right Door Upholstery	1.00	25276	Cowl Lamp Bracket (Right) 1.25
25189	Front Spring Horn, Left	1.50	25277	Cowl Lamp Bracket (Left) 1.25
25190	Front Spring Horn, Right		25278 25281	Cowl Moulding Bolt
25191 25192	Tail and Stop Lamp Contact Plug Cylinder Block		25281 25282	Headlamp Connector Plug
25193	Frame Complete		25283	Headlamp Connector Plug Cap
25194	Radiator Complete	45.00	25284	Cowl Lamp Complete (Right) 3.00
25195	Radiator Core		25285	Cowl Lamp Complete (Left) 3.00 Cowl Lamp Rim and Glass Complete. 1.25
25196 25197	Clutch Pedal		25286 25290	Cowl Lamp Rim and Glass Complete. 1.25 Cowl Lamp Complete (Right) 3.00
25198	Gear Shift Lever		25291	Cowl Lamp Complete (Left) 3.00
25199	Foot Brake Pedal	1.25	25292	Headlamp Complete 7.25
25200	Foot Brake Pedal (R.D.)	1.25	25293	Headlamp Reflector 2.00

Part No.	Part Name	Price	Part No.	Part Name	Price
25303	Steering Gear Housing Gasket	\$0.05	25376	Pinion Housing	\$6.00
25306	Headlamp Complete	5.25	25377	Pinion Housing Oil Seal	.10
25307	Hub Cap Wrench		25378	Pinion Housing Oil Seal	.10
25309	Frame Complete		25379 25380	Drive Pinion and Shaft	8.75
25310 25311	Gasoline Tank SupportSteering Gear Bracket	3.50 3.30	25381	Drive Pinion and Shaft Pinion Roller Bearing (Inner)	8.75 5.85
25312	Steering Gear Bracket (R.D.)	4.00	25382	Pinion Roller Bearing (Inner)	6.50
25313	Steering Gear Bracket Bushing	.30	25383	Pinion Roller Bearing (Outer)	3.25
25314	Front Spring Horn	7.50	25384	Drive Pinion Oil Seal (Leather)	.45
25315	Rear Spring Bracket	.75	25385	Drive Pinion Oil Seal Retainer	.07
25316	Step Hanger (Center)	.50	25386 25387	Drive Pinion Oil Seal Spring Drive Pinion Oil Seal Spring Retainer.	.07
25317 25318	Tire Carrier Rim ClampUse No. Tire Carrier Complete	3.50	25388	Pinion Bearing Adjusting Nut	2.10
25319	Tire Carrier Bracket (Left)	.60	25389	Pinion Bearing Adjusting Nut	2.10
25320	Tire Carrier Bracket (Right)	.60	25390	Front Wheel Complete	10.00
25321	Front Spring	4.15	25391	Front Wheel	6.00
25322	Front Spring First Leaf Bushing	.16	25392	Front Wheel Hub	2.75
25323	Rear Spring	7.15	25393 25394	Front Wheel Brake Drum Front Wheel Inner Bearing	$\frac{2.50}{4.90}$
25324 25325	Front Spring Bolt Lock	.03	25395	Front Wheel Outer Bearing. Use No.	5054
25326	Front Spring Clip	.20	25396	Hub Cap	
25327	Rear Spring Bolt	.60	25397	Rear Wheel Complete	10.00
25328	Oil Filtrator Gasket	.17	25398	Rear Wheel Complete	
25329	Spring Bolt Oil Pipe	.20	25399	Rear Wheel	6.00
25330	Spring Snubber Clip	.40	25400 25401	Rear Wheel	$\frac{6.00}{2.50}$
25331 25332	Front Axle "I" Beam		25402	Rear Wheel Hub	2.50
25333	Steering Knuckle (Left)		25403	Rear Wheel Brake Drum	2.50
25334	Steering Knuckle (Right) (R.D.)	13.00	25404	Rear Wheel Brake Drum	2.50
25335	Steering Knuckle (Left) (R.D.)	13.00	25405	Special Cap Screw	.05
25336	Steering Knuckle Bushing	.25	25406	Demountable Rim	3.00
25337	Steering Knuckle Adjusting Washer	.25	25407 25408	Demountable Rim Bolt	
25338 25339	Steering Knuckle Thrust Bearing Steering Knuckle King Pin	.80	25409	Radiator Core	
25340	Steering Knuckle Arm, Right		25410	Radiator Shell	
25341	Steering Knuckle Arm, Left	4.90	25411	Radiator Inlet Hose	.20
25342	Steering Knuckle Arm, Right (R.D.)		25413	Cylinder Head	17.00
25343	Steering Knuckle Arm, Left (R.D.)	3.60	25414 25415	Cylinder Head Gasket	.90
25344	Primary Aux and SecondaryShoe Assy.	7.00	25416	Cylinder BlockUpon Appl Cylinder BlockUpon Appl	ication
	Note: Brake Shoe Assembly returned for relining will be accepted for full credit less a		25417	Intake Valve	.75
	charge of \$3.25 list for relining.		25418	Valve Spring	.20
25345	Primary and Auxiliary Shoe Lining	. 65	25419	Valve Spring Cup Complete	.17
25346	Brake Secondary Shoe Lining	.80	25420	Valve Chamber Cover Screw	.11
25347 25348	Front Brake Cam Lever Front Backing Plate Comp. (Right)		25421 25422	Valve Tappet with Adjusting Screw Valve Tappet Guide (Front)	$\frac{1.10}{4.90}$
25349	Front Backing Plate Comp. (Left)	3.95	25423	Valve Tappet Guide (Rear)	4.90
25350	Brake Reinforcement Plate Complete		25424	Valve Tappet Guide Screw	.10
	(Inner)	.90	25425	Valve Tappet Guide Screw Lock	.05
25351	Brake Reinforcement Plate (Outer)		25426 25427	Oil Level Gauge Complete	.80
25352 25353	Brake Anchor Pin Link Carburetor Complete		25428	Oil Level Gauge Rod Support Piston (Standard)	.30 4.50
25354	Front Axle Tie Rod		25429	Piston (.003" oversize)	4.50
25355	Rear Axle Housing (Left Half)		25430	Piston (.005" oversize)	4.50
25356	Rear Axle Housing (Right Half)		25431	Piston (.010" oversize)	4.50
25357	Oil Pump Cover Gasket		25432	Piston (.015" oversize)	4.50
25358 25359	Oil Filtrator Feed PipeOil Filtrator Pipe Nut	.80	25433	Piston (.020" oversize)	4.50
25360	Rear Backing Plate (Right)	3.95	25434	Piston (.023" oversize)	4.50
25361	Rear Backing Plate (Left)	3.95	25435	Piston (.025" oversize)	4.50
25362	Rear Backing Plate (Right)	3.95	25436	Piston (.030" oversize)	4.50
25363	Rear Backing Plate (Left)	3.95	25437	Piston (.035" oversize)	4.50
25364	Chain Case Stud	.04	25438	Piston Ring (Standard) Use No.	
25365 25366	Chain Case Cover Oil Retainer Cork Piston Pin (Standard)	.05	25439 25440	Piston Ring (.005" oversize) Use No. Piston Ring (.010" oversize) Use No.	
25367	Carburetor Inlet Screen		25441	Piston Ring (.010 oversize)Use No.	
25368	Bevel Ring Gear		25441	Piston Ring (.013 oversize) Use No.	
25369	Rear Axle Shaft	6.25	25443	Piston Ring (.025" oversize)Use No.	
25370	Rear Axle Shaft		25444	Piston Ring (.030" oversize)Use No.	
25371 25372	Rear Axle Shaft Outer Bearing Rear Axle Shaft Felt Washer Retainer		25445	Piston Ring (.035" oversize)Use No.	
25372 25373	Felt Washer	.10	25446	Piston Ring (Standard)	
25374	Outer Bearing Adjusting Nut	1.15	25447	Piston Ring (.005" oversize)	.25
25375	Pinion Housing	6.00	25448	Piston Ring (.010" oversize)	.25

Part No.	Part Name	Price	Part No.	Part Name	Price
25449	Piston Ring (.015" oversize)		25544	Fly Wheel\$17	
25450 25451	Piston Ring (.020" oversize)	.25	25545	Fly Wheel Housing	
25452	Piston Ring (.030" oversize)	.25	25546 25547	Fly Wheel Housing Stud	.05
25453	Piston Ring (.035" oversize)	.25	25548	Oil Filtrator Pipe Nut	.15
25454	Piston Ring (Lower) (Standard)	.75	25549	Fly Wheel Housing Dust Cover Gasket	.04
25455 25456	Piston Ring (Lower) (.005" oversize)	.75	25550		9.50
25457	Piston Ring (Lower) (.010" oversize) Piston Ring (Lower) (.015" oversize)	.75	25551 25552	Oil Pan Complete	7.50
25458	Piston Ring (Lower) (.013 oversize)	.75 $.75$	25553		4.50
25459	Piston Ring (Lower) (.025" oversize)	.75	25554		2.75
25460	Piston Ring (Lower) (.030" oversize)	.75	25555	Oil Pump Body with Bushing	6.70
25461 25462	Piston Ring (Lower) (.035" oversize)	. 75	25556	Oil Pump Body Bushing	.25
25463	Piston Pin (Standard). Piston Pin (.005" oversize).	.55	25557 25558	Oil Pump Body Bushing Pin Oil Pump Body Gasket	.02
25464	Piston Pin (.010" oversize)	.55	25559	Oil Pump Body Stud	.05
25465	Carburetor Body Upper Half Gasket	.05	25560	Oil Pump Lower Drive Gear	2.25
25466	Connecting Rod Complete		25561		2.30
	Note: Rod returned for new Bearing will be accepted at full credit less a charge of \$4.25		25562 25563		1.85
	list for new bearing.		25564	Oil Pump Drive Shaft Complete 1 Oil Pump Lower Drive Gear Stud	1.20
25467	Connecting Rod Bushing	.30	25565	Oil Pump Cover	.80
25468	Crankshaft	25469	25566	Oil Pump Cover Gasket	.02
25469 25470	Crankshaft	105.00	25567	Oil Pump Drive Gear Cover	.30
25474	CrankshaftFront Bearing(Upper)(Std.) Front Bearing (Lower) (Standard)	2.40	25568 25569	Oil Strainer Frame Complete (Lower) Oil Strainer Frame Complete (Upper)	.45
25478	Center Bearing (Upper) (Standard)	2.40 1.80	25570	Oil Strainer Spacer	.20
25482	Center Bearing (Lower) (Standard)	1 50	25571	Oil Strainer Spacer	.07
25486	Inter. Bearing (Upper) (Standard)	1 25	25572	Oil Strainer Spacer Gasket	.01
25490 25494	Inter. Bearing (Lower) (Standard)	1.45	25573	Oil Strainer Screw Lock	.03
25498	Rear Bearing (Upper) (Standard) Rear Bearing (Lower) (Standard)	2.20 2.20	25574 25575	Oil Pressure Valve Body Oil Pressure Valve Body Gasket	1.85
25502	Bearing Cap (Front)	1 90	25576	Oil Pressure Valve	.12
25503	Bearing Cap (Center)	1.95	25577	Oil Pressure Valve Spring	.04
25504 25505	Bearing Cap (Intermediate)	1 75	25578	Oil Pressure Valve Plug	.10
25506	Bearing Cap (Rear) Bearing Cap Stud (Rear) (3" long)	$\frac{1}{2}.40$ 17	$25579 \\ 25580$		1.00
25507	Bearing Cap Stud (Front, Center and	10.11	25581		1.10
	Intermediate)	25	25582	Oil Suction Pipe Packing	.04
25508	Bearing Cap Washer	02	25583		6.90
25509 25510	Bearing Pilot. Rear Bearing Oil Guard	05 25	25584		6.90
25511	Rear Bearing Filler Block	1.05	25585 25586		$\frac{1.60}{1.60}$
25512	Rear Bearing Filler Block Cork	07	25587	Water Pump Body Use No. 2	
25513	Rear Bearing Filler Block Gasket	01	25588	Water Pump Coupling Hose	1.00
25514 25515	Damper Complete	99 00	25589	Intake and Exhaust Manifold 1	
25516	Fan Drive Pulley Fan Drive Pulley Gasket	$7.00 \\ 01$	25590 25591	Intake and Exhaust Manifold Gasket Intake and Exhaust Manifold Gasket	8.00
25517	Damper Friction Disc.	40	25592		3.25
25518	Damper Plate (Front)	6 60	25593		2.70
25519	Damper Plate (Rear)	6 60	25594		1.15
25520 25521	Damper Plate Retainer	.85	25595 25596		1.30
25522	Damper Plate Retainer Dowel Damper Plate Dowel Nut Lock	$\begin{array}{c} .15 \\ .05 \end{array}$	25596 25597	Exhaust Pipe	.60
25523	Damper Spring	04	25598	Special Hex. Nut.	.05
25524	Water Outlet Pipe	1 35	25599	Exhaust Pipe Clamp	.10
25527	Camshaft	24.00	25600		7.25
25528 25529	Camshaft	$\frac{24.00}{1.40}$	25601 25602	Muffler Valve Knob Complete Muffler Valve Guide Complete	.25
25530	Camshaft Bushing (Third)	$\frac{1.40}{1.10}$	25603		1.25
25531	Camshaft Bushing (Second)	80	25604	Underpan (Right)	.80
25532	Front Motor Support Plate	3 10	25605	Underpan (Left)	.80
25533 25534	Motor Support Gasket	15	25606	Underpan (Right) (R.D.)	.75
25535	Chain Cover Complete ChainCase Oil Retainer Packing(Cork)	$7.\overset{25}{10}$	25607 25608	Underpan (Left) (R.D.)	.75
25536	Chain Cover Gasket	05	25609		5.00
25537	Chain Cover Nut	04	25610	Gasoline Tank 1	1.00
25538	Camshaft Sprocket	11.00	25611	Gasoline Tank Strap	. 50
25539	Generator Sprocket Cover Gasket	00=90	25612		1.30
25540	Generator Sprocket Shim	20789	25613 25614	Vacuum Tank Pipe Vacuum Tank Suction Pipe	.45
25541	Camshaft Sprocket Thrust Washer.	95	25615	Clutch Plate with Hub Use No. 2	
25542	Timing Sprocket Drive Chain	8 20	25616	Clutch Cover Plate	4.75
25543	Timing Chain Hunting Link	.75	25617	Clutch Pressure Ring	4.00

Part No.	Part Name	Price	Part No.	Part Name	Price
			25689	Worm Wheel and Shaft	\$3.00
2561 2561		23 00	25690	Worm Wheel and Shaft (R.D.)	3.30
2562			25691	Worm Wheel Thrust Screw Washer	.05
2562			25692	Pitman Arm	1.60
2562		.10	25693	Pitman Arm Nut	.14
2562		00505	25694	Steering Gear Thrust Bearing	.60
2562	Use No.	22507	25695 25696	Steering Gear Worm (P.D.)	$\frac{1.60}{1.95}$
2302	Clutch Shaft Operating Rod (R.D.) Use No.	24711	25697	Steering Gear Worm (R.D.)	.05
2562			25698	Main Tube with Silencer	2.25
2562		.02	25699	Main Tube Nut	.08
2562		3.25	25700	Worm Adjusting Nut	. 55
2562		.02	25701	Worm Adjusting Nut Spacer	.80
25629 2563		.02	25702 25703	Worm Adjusting Nut Spacer Bushing. Mast Jacket	$\frac{.20}{3.25}$
2563		.30	25704	Mast Jacket Bushing	.35
2563		.02	25705	Steering Wheel	7.25
2563		. 50	25706	Steering Control Tube with Base	1.30
25634		.30	25707	Spark Tube with Lever	1.30
2563		.30	25708 25709	Throttle Tube with Lever	1.30^{-75}
2563 2563		.04	25710	Control Cover	$.75 \\ .04$
2000	Washer	.02	25711	Control Cover Spring	.04
25638	Gear Shift Lever	4.10	25712	Control Friction Plate (Lower)	.04
2563	Gear Shift Lever Grip	.30	25713	Control Friction Plate (Upper)	.04
2564		.04	25714	Spark Lever (Lower)	.08
2564 2564	The state of the s	.07	25716 25717	Steering Gear Worm Wheel Adj. Screw Control Tube Base Clamp	.16 .08
2564		3.00	25718	Control Tube Base Clamp Gasket	.02
2564		3.00	25719	Control TubeBase ClampPlate (Lower)	.07
2564		3.00	25720	Throttle Wire	.06
2564		.10	25721	Accelerator Rod	.25
2564	- to Tatole bearing a see of the second second second		25722	Spark Rod Cross Shaft	.25
2564	Rev) Shifter Fork (First and Second)	1.90	25723 25724	Spark Rod Cross Shaft Spring Spark Rod Cross Shaft Lever	. 05 . 07
2564		1.50	25725	Spark Rod, Upper	.10
2565		2.00	25726	Spark Rod (Lower)	.12
2565		.20	25727	Mast Jacket Bracket (Upper)	.70
2565 2565			25728 25729	Mast Jacket Bracket Cap (Upper) Steering Connecting Rod Complete	2.40
25654		$6.50 \\ .09$	25730	Front Fender (Right)	27.00
2565		.60	25731	Front Fender (Left)	$\frac{27.00}{27.00}$
2565		6.90	25732	Front Fender (Right)	22.00
2565	Ball Bearing Lock Nut	.35	25733	Front Fender (Left)	22.00
2565 2565		.07	25734 25735	Rear Fender (Right)	
2566		23 00	25736	Side Apron (Right)	$8.25 \\ 3.75$
2566		.04	25737	Side Apron (Left)	3.75
25662	Main Drive Shaft Rear Ball Bearing	3.90	25738	Side Apron (Right)	3.75
2566		1.60	25739	Side Apron (Left)	3.75
2566		.80	$25740 \\ 25741$	Rear Top Apron	$\frac{4.25}{3.75}$
2566 2566		$\frac{.02}{2.10}$	25742	Running Board (Left)	3.75
2566		2.50	25743	Running Board Moulding (Outer)	.35
2566	Speedometer Gear Washer	.06	25744	RunningBoard Moulding(Inner)(Right)	.25
25669		4.40	25745	RunningBoard Moulding(Inner) (Left)	.25
2567 2567		4.65	25747 25748	Hood Sill (Left)	$\frac{1.25}{1.25}$
2567		.55	25751	Door Complete(Left Front) Upon Appl	
2567	Brake Cross Shaft	1.75	25752	Door Complete (Right Front)	icavion.
2567	Brake Cross Shaft (R.D.)	2.50	1000	Úpon Appl	ication
2567	Brake Cross Shaft Bearing Plate UseNo		25753	Door Complete (Left Rear) Upon Appl	ication
2567		.45	25754	Door Complete (Right Rear)	ication
2567 2567		. 55	25755	Upon Appl Door Window Reg. Handle	1.10
2567		.35	25756	Door Window Reg. Handle Escutcheon	.25
2568	Rear Brake Rod (Front)	.35	25757	Door Glass, Rear	6.00
2568	Steering Gear Housing	3.40	25758	Front Seat Cushion	27.00
25682	Steering Gear Housing (R.D.)	4.50	25759	Rear Seat Cushion	
2568 2568		.02	25760 25761	Back Window Curtain	
2568		.07	25762	Assist Cord	4.00
2568	Housing Oil Guard (Front)	.02	25763	Front Floor Mat	4.00
25688	Housing Oil Guard Retainer	.02	25764	Front Floor Mat (R.D.)	4.00

Part No.	Part Name	Price	Part No.	Part Name	Price
25765	Rear Floor Carpet	\$5.50	25854	Universal Joint Inside Casing	\$0.60
25766	Outside Door Handle	1.10	25855	Univ. Joint Outside Casing (Axle End)	. 55
25767	Outside Door Handle (With Key)		25856	Univ. Joint Outside Casing(Trans.End)	. 55
25768	Door Lock Handle (Inside)	1.10	25857	Univ. Joint Casing Spring (Trans.End)	.16
25770 25771	Cowl Ventilator Cover Complete Cowl Ventilator Lever	.80	25858	Univ. Joint Casing Spring (Axle End).	.16
25772	Cowl Ventilator Spring (Right)	.07	25859 25860	Universal Joint Casing Gasket Universal Joint Dust Cap	.06
25773	Cowl Ventilator Spring (Left)		25861	Universal Joint Dust Cap Washer(Felt)	.06
25774	Dummy Prop Iron (Right)	2.45	25862	Univ. Joint Dust Cap Washer (Split).	.06
25775	Dummy Prop Iron (Left)	2.45	25863	Universal Joint Flange (Trans. End)	2.00
25776 25777	Corner Lamp Rim Use No.		25864	Universal Joint Flange (Axle End)	1.65
25778	Corner Lamp GlassUse No. Corner Lamp Switch	.35	25865 25866	Universal Joint Flange Bolt Univ. Joint Flange Yoke (Trans. End)	5.00
25779	Corner Lamp Switch Plate	.25	25867	Carburetor Accelerator Lever	.25
25782	Door Comp. (Right Front). Upon Appl		25868	Carburetor Air Horn Assembly	4.00
25783	Door Comp. (Left Front) Upon Appl	ication	25869	Carburetor Air Horn Screw	.05
25784 25785	Door Comp. (Right Rear). Upon Appl	ication	25870	Carburetor Choke Lever	.30
25787	Door Comp. (Left Rear) Upon Appl Rear Quarter Regulator Handle		25871 25872	Carburetor Choke Shaft	.25
25789	Rear Quarter Glass	5.25	25873	Carburetor Choke Lift Lever	.25
25790	Front Seat Cushion	27.00	25874	Choke Lift Lever Connecting Rod	.10
25791	Rear Seat Cushion	27.00	25875	Carburetor Economizer Lift Lever	. 50
25792 25794	Back Window Curtain	$\frac{2.25}{6.25}$	25876 25877	Economizer Lift Lever Pinion Screw.	.05
25802	Foot Rest Bracket Complete (Right)	1.90	25878	Economizer Lift Lever Pinion Spacer. Carburetor Float	$\frac{.05}{1.00}$
25803	Foot Rest Bracket Complete (Left)	1.90	25879	Carburetor Float Bowl Cover	.35
25804	Hood Complete		25880	Carburetor	25.00
25805	Intake Manifold Gasket		25881	Carburetor Body (Upper Half)	7.00
25806 25807	Body Upper Half Left Rear Quarter Moulding	$\frac{7.00}{3.25}$	25882	Carburetor Nozzle Assembly	.75 $.75$
25808	Right Rear Quarter Moulding		25883 25884	Carburetor By-Pass Tube Carburetor Air Bleed Restriction Screw	.10
25809	Windshield Swing Arm	3.40	25885	By-Pass Aux. Restriction Screw	.05
25810	Windshield Swing Arm Knob (Male)		25886	Carburetor Pump Plunger	1.00
01011	Use No.	24767	25887	Carburetor Pump Lever	.40
25811	Windshield Swing Arm Knob (Female) Use No.	24768	25888 25889	Carburetor Throttle Lever Shaft Carburetor Throttle Shutter	$.30 \\ .30$
25812	Headlamp Tie Bar	1.50	25890	Carburetor Throttle Control Bell Crank	.60
25815	Ignition Lock with Wiring and Key	4.75	25891	Carburetor Bell Crank Ball Socket	.25
25816	Instrument Panel Switch Knob Bushing	.25	25892	Carburetor Bell Crank Connecting Rod	.10
25817 25818	Battery Clamp (Rear)	$.15 \\ .20$	25893 25894	Carburetor Bell Crank Stud Carburetor Accelerator Lever	$.10 \\ .40$
25819	Horn Button		25895	Carburetor Choke Lift Lever	.25
25820	Horn Button InsertUse No.		25896	Choke Lift Lever Connecting Rod	.10
25822	Gasoline Gauge Terminal Insulator	.10	25897	Carburetor Choke Lift Lever Swivel	.10
25824 25825	Oil Gun	.35	25898	Front Wheel Counterweight	$.16 \\ .04$
25826	Trunk Rack	4.50	25899 26000	Front Wheel Counterweight Bolt Tire Carrier Brace Bracket (Right)	.90
25827	Pedal Pad (Rubber)	.15	26001	Tire Carrier Brace Bracket (Left)	.90
25828	Carburetor Inlet Connection	.40	26002	Tire Carrier Brace	.35
25829	Carburetor Inlet Connection Gasket		26003	Hand Brake Lever Bracket	$\frac{1.15}{1.25}$
25830 25831	Carburetor Inlet Connection Screw Carburetor Nozzle	$.10 \\ .75$	26004 26005	Hand Brake Lever Bracket (R.D.) Radiator Splash Apron	$\frac{1.25}{3.50}$
25832	Carburetor Nozzle Gasket	.05	26006	Control Tube Base Clamp Plate (Lower)	0.00
25833	Carburetor By-Pass Tube	.75		(R.D.)	.15
25834	Carburetor By-Pass Adj. Needle Seat.	.20	26007	Pedal Shaft (R.D.)	2.75
25835 25836	Carburetor Air Bleed Restriction Screw Carburetor By-Pass Auxiliary Tube	$.06 \\ .20$	26008 26009	Accelerator Rod	$.30 \\ .25$
25837	Carburetor By-Pass Aux. Restric. Screw		26010	Steering Connecting Rod Comp.(R.D.)	2.50
25838	Carburetor Pump Plunger	1.00	26011	Air Cleaner Clamp Band	.10
25839	Carburetor Pump Lever	.40	26012	Accelerator Lever (R.D.)	.40
25840	Economizer Valve		26013	Spark Control Rod (R.D.)	.10
25841 25842	Front Delivery Plug Screw Economizer Air Bleed Restric. Screw	$.10 \\ .20$	26014 26015	Throttle Operating Shaft (R.D.) Accelerator Rod (R.D.)	$.25 \\ .25$
25843	Fuel Adjusting ScrewUse No.		26016	Throttle Operating Shaft Lever (R.D.)	.50
25844	Fuel Adjusting Needle Assembly	.75	26017	Cross Shaft to Carburetor Lever (R.D.)	.45
25845	Air Cleaner		26018	Throttle Operating Rod (R.D.)	.12
25846 25847	Air Cleaner Wing Nut		26019	Throttle Wire (R.D.)	$\frac{.06}{4.00}$
25848	Throttle Lever Shaft	.25	26020 26021	Running Board Complete (Left) Front Fender (Left)Use No.	
25849	Throttle Lever Shaft Bushing	.20	26022	Tire Carrier Bracket	1.00
25850	Throttle Shutter	.35	26023	Tire Carrier Bracket Support	.25
25851	Propeller Shaft with Yoke End		26024	Tire Carrier Cradle	4.75
25852 25853	Universal Joint Yoke (Axle End) Universal Joint Cross		26025 26026	Gasoline Gauge	$\frac{2.00}{.50}$
20000	Carrottar 601110 O1000	1.00	20020	TIOTH WHO COMPRETE,	.00

Part No.	Part Name	Price	Part No.	Part Name	Price
26027	Throttle Control Cover	\$0.25	26106	Radiator Tie Rod	\$0.20
26028	Horn Wire Connector	.05	26107	Radiator Tie Rod	.25
26029	Dome Lamp Wire Connector	.10	26108	Deck Door Lock Escutcheon	.25
26030 26031	Radiator Filler Cap Front Bumper	$\frac{1.00}{9.00}$	26109 26110	Gear Shift Lever (R. D.) Spring Bolt Oil Pipe Elbow	$\frac{3.90}{.07}$
26032	Front Bumper Bracket (Right)	.85	26112	Propeller Shaft	8.00
26033	Front Bumper Bracket (Left)	.85	26113	Universal Joint Outside Casing . Use No.	
26034	Front Bumper	9.00	26114	Universal Joint Inside Casing	.65
26035	Rear Bumperette (Left)	4.00	26115	Universal Joint Inside Casing Gasket	.05
26036	Rear Bumperette (Right)	4.00	26116	Universal Joint Flange (Axle End)	3.25
26037 26038	Front Bumper	$11.50 \\ 10.50$	26117 26118	Universal Joint Casing (Trans. End). Universal Joint Flange Yoke	$\frac{3.25}{2.00}$
26039	Rear Bumperette		26119	Universal Joint Flange Bolt	.10
26040	Rear Bumperette		26120	Universal Joint Dust Cap Felt Washer	.06
26041	Rear Spring Shackle Bolt	.05	26122	Outside Door Handle	.95
26042	Front Spring Shackle Bolt	.06	26123	Deck Door Handle	.35
26043 26044	Shackle Bolt Lock Washer (Pronged).	.01	26124 26125	Outside Door Handle	.95
26045	Spring Shackle Spring	$.05 \\ .05$	26126	Deck Hand Rail	8.00 2.60
26046	Gasoline Filter Shutoff Cock	.40	26127	Cowl Lamp Complete (Left)	2.60
26047	Gas. Filter Clamp Spring Thumb Nut	.30	26128	Coupling Hose	.50
26048	Gasoline Filter Strainer Screen	.25	26129	Corner Lamp Complete	1.90
26049	Radiator Complete		26130	Corner Lamp Hood	.45
26050 26051	Clutch PedalBrake Pedal	$\frac{1.50}{1.35}$	26131 26132	Rear Axle Truss Rod	1.00
26052	Running Board (Right)	4.50	20102	Cabriolet Body Complete (L. D.) Upon Appli	cation
26053	Running Board (Left)	4.50	26133	Cabriolet Body Complete (R. D.)	Caulon
26054	Clutch Pedal (R.D.)	2.70		Upon Appli	
26055	Brake Pedal (R.D.)	2.70	26134	Door Complete (Right)Upon Appli	
26056	Water Outlet Pipe	1.35	26135	Door Complete (Left)Upon Applie	cation
26057 26058	Horn Wire (R.D.)	$\frac{.25}{8.50}$	26136 26137	Seat CushionRumble Seat Cushion	
26059	Front Wheel Complete	8.50	26138	Top Complete, Less Slat Irons	
26062	Accelerator Rod	.20	26139	Back Curtain	12.00
26063	Throttle Operating Rod (R.D.)	.15	26140	Back Curtain	8.10
26064	Brake Pedal Pull Rod	.55	26141	Speedometer Gear Housing Screw	.04
26065 26066	Starter Strap, Upper (R.D.) Starter Strap, Lower (R. D.)	.45 .45	26142 26143	Carburetor WrenchSpark Control Rod (Lower)	$.35 \\ .12$
26067	Hood Complete	13.00	26144		12.50
26068	Radiator Filler Cap Gasket	.08	26145	Gasoline Tank Filler Cap	.30
26069	Radiator Core	38.50	26146	Starter Strap (Lower)	.30
26070	Radiator Outlet Pipe	.55	26147	Outside Door Handle with Lock and	0.00
26071 26072	Headlamp Complete Headlamp Rim (N.P.)	$9.00 \\ 2.35$	26148	KeyOutside Door Handle (Without Lock)	$\frac{2.25}{1.25}$
26073	Tail and Stop Lamp (N.P.)	3.25	26149	Outside Door Handle (Without Lock)	.25
26074	Cowl Lamp, Right (N.P.)	3.00	26150	Heat Indicator (On Dash)	2.50
26075	Cowl Lamp, Left (N.P.)	3.00	26151	Gasoline Gauge (On Dash)	2.50
26076	Cowl Lamp Rim and Glass Comp.	4 40	26152	Ammeter	1.50
26077	(N.P.)	$\frac{1.40}{.90}$	26153 26154	Oil Pressure Gauge	$\frac{2.00}{.25}$
26078	Cowl Moulding, Side (Right)	. 30	26155	Piston Ring (Standard)	.75
	(N.P.)	.90	26156	Piston Ring (.005" oversize)	.75
26079	Cowl Moulding, Top (N.P.)	2.25	26157	Piston Ring (.010" oversize)	.75
26080	Cowl Lamp Bracket, Right (N.P.)	.95	26158	Piston Ring (.015" oversize)	.75
26081 26082	Cowl Lamp Bracket, Left (N.P.) Cowl Lamp Bracket Nut (N.P.)	.95	26159 26160	Piston Ring (020" oversize)	.75
26083	Radiator Shell (N.P.)	$\frac{.10}{17.00}$	26161	Piston Ring (.025" oversize) Piston Ring (.030" oversize)	.75 .75
26084	Radiator Complete		26162	Piston Ring (.035" oversize)	.75
26085	Radiator Filler Cap (N.P.)	2.35	26163	Front Universal Joint Complete	12.00
26086	Cowl Moulding, Side (Right) (N.P.)	.95	26164	Top Bumper Bracket Adapter	.30
26087	Cowl Laws Brocket (Bight) (N.P.)	.95	26165	Expansion Plug, 25%"	.20
26088 26089	Cowl Lamp Bracket, (Right) (N.P.) Cowl Lamp Bracket (Left) (N. P.)	.95 .95	26166 26167	Gasoline Tank Support Felt Washer	3.75
26090	Front Motor Plate Gasket	.08	26168	Felt Washer	.09
26091	Tire Carrier Complete	2.70	26169	Cowl Lamp Moulding Washer	.02
26093	Headlamp (N.P.)	7.25	26170	Universal Joint Casing Spring	.11
26094	Headlamp Rim (N.P.)	2.25	26171	Fender Lamp Complete (Left)	3.10
26095 26096	Radiator Complete		26172 26173	Fender Lamp Complete (Right) Fender Lamp Complete (Left)	3.10
26097	Dash Body Bracket (N.P.) Use No.		26174	Fender Lamp Complete (Left)	$\frac{2.75}{2.75}$
26102	Lamp Socket Complete	.50	26175	Steering Wheel	6.50
26103	Air Cleaner Assembly	2.00	26176	Spark Control Tube with Lever	1.35
26104	Air Cleaner Clamp Band	.10	26177	Throttle Control Tube with Lever	1.25
26105	Radiator Tie Rod Bracket	.17	26178	Control Tube with Base	1.30

Part	Part Name	Tre*L	Part No.	Part Name Price
No.		Price	26258	Rear Door Bumper Rubber \$0.06
26179	Choke Housing Complete	\$0.35	26259	Driver's Seat Complete
26180	Flywheel and Clutch Cover Underpan	4.50	26260	Right Rear Door Hinge (Upper) 35
26181 26182	Flywheel and Clutch Cover Underpan Brake Camshaft Bearing Bushing	4.50	26261	Left Rear Door Hinge (Upper)
26183	Front Brake Lever Adjusting Screw	.30	26262	Right Rear Door Hinge (Center)40
26184	Front Brake Lever Adjusting Screw	19800.00	26263	Left Rear Door Hinge (Center)40
25	Nut	.02	26264	Right Rear Door Hinge (Lower)45
26185	Brake Cam Shaft	. 50	26265	Left Rear Door Hinge (Lower)
26186	Brake Cam Shaft Dust Shield	.06	26266 26267	Back Panel Door Lock
26191	Front Brake Cam Lever (Left)	.45	26268	Back Panel Door Lock Rod Guide
26192 26194	Front Brake Cam Lever (Right)	.45	20200	Spring
20194	Steering Worm Wheel and Shaft (R. D.)	2.75	26269	Running Board Complete (Left) 4.15
26195	Coupling Hose.	.45	26270	Front Backing Plate (Right) 2.50
26196	Gasoline Gauge	1.50	26271	Front Backing Plate (Left) 2.50
26197	Gasoline Gauge Cap	.30	26272	Tire Carrier Bracket (Right)
26198	Gasoline Gauge Gasket	.07	26273 26274	Tire Carrier Bracket (Left)
26199	Gasoline Gauge Glass	.10	26275	Exhaust Pipe Support
26200 26201	Tire Carrier Bracket (R. D.)	1.50	26276	Frame Complete (L. D.)
26202	Spark Control Bell Crank (R. D.) Cross Shaft Lever Support	.70	26277	Frame Complete (R. D.) 37.00
26203	Spark Control Rod Cross Shaft Lever	Salvies .	26278	Frame Complete
- 654	Support Bolt	.04	26279	Frame Front Cross Member 2.50
26204	Spark Rod Cross Shaft Lever	1.20	26280	Rear Motor Support Complete 2.75
26205	Spark Control Rod Lower	.12	26281	Transmission Support (Rear) 1.15 Flywheel and Clutch Cover 2.15
26206	Dummy Prop Shield	.20	26283 26284	Flywheel and Clutch Cover Underpan 2.35
26207 26208	Spark Lever (Lower) (R. D.)	.08 1.60	26285	Flywheel and Clutch Cover 2.15
26209	Radiator Shell		26286	Flywheel and Clutch Cover Underpan 2.35
26210	Rear Bearing Filler Block	1.20	26287	Radiator Complete 44.00
26211	Rear Bearing Oil Guard	.30	26288	Radiator Complete
26212	Filler Block Gasket	.02	26289 26290	Radiator Complete
26213	Filler Block Cork (Rear)	.03	26291	Radiator Shell
26214 26215	Headlamp Complete	8.75	26292	Radiator Shell
26216	Headlamp Rim	$\frac{2.25}{25.00}$	26293	Crankshaft
26218	Tire Cover	2.15	26294	Damper Complete
26219	Tire Cover	2.50	26295	Fan Drive Pulley 6.25
26220	Tire Cover	2.15	26296 26297	Carburetor Complete
26221 26222	Tire Cover	2.85	26298	Front Wheel
26223	Tire Cover	2.15	26299	Rear Wheel Complete 9.50
26224	Rear Backing Plate Comp (Right) Use	25362	26300	Rear Wheel 5.50
26225	Damper Complete		26301	Demountable Rim
26226	Fan Drive Pulley	5.00	26302	Demountable Rim Bolt
26227	Damper Plate (Front)	5.40	26303 26304	Wheel Brake Drum Hole Cover05 Rear Spring Horn (Right) 1.60
26228 26229	Damper Plate (Rear)	5.40	26305	Rear Spring Horn (Left)
26230	Damper Dowel Pin	.09	26306	Back Window Glass 3.00
26231	Accelerator Rod (R. D.)	.30	26307	Foot Rest Bracket (Left) 3.00
26232	Tail and Stop Lamp Complete	3.00	26308	Foot Rest Bracket (Right) 3.00
26233	Tail Lamp Bracket and Tube	2.15	26309 26310	Back Window Moulding (U. and L.) .25 Back Window Moulding (Sides)20
26234	Rear Spring Clip	.30	26311	Running Board (Left)
26235 26236	Rear Fender (Right)	11.00	26312	Running Board (Right)
26237	Rear Fender (Left)	$6.75 \\ 6.75$	26313	Speedometer Gear Housing 2.50
26238	Radiator Shell (N. P.)	16.00	26314	Transmission Case
26239	Radiator Complete (N. P.)	48.00	26315	Transmission Bearing Retainer (Front) .45
26240	Tire Carrier Bracket	1.05	26316	Gasoline Tank Filler Cap
26241	Body to Frame Step Bolt	.10	26317	Cross Shaft Bearing Plate
26242 26243	Rear Spring. Clutch Pedal (R. D.)	1.25	26318	Cross Shaft Bracket (Center)
26244	Clutch Pedal (R. D.)	1.25	26319	Cross Shaft Bearing Plate Shim02
26245	Clutch Pedal Shaft (R. D.)	1.50	26320	Brake Pedal Pull Rod45
26246	Pedal Return Spring Lever (R. D.)	.15	26321	Front Brake Rod (Rear)
26247	Accelerator Rod (R. D.)	.17	26322	Front Brake Rod (Right Rear) (R. D.) .40
26248	Bevel Drive Pinion	16.25	26323	Rear Brake Rod (Front)
26249 26250	Bevel Ring Gear	23.50	26324	Coupe Body with Rumble Seat (L. D.) Upon Application
26250 26251	Speedometer Drive Pinion	$5.00 \\ 2.10$	26325	Full Automatic Dist. Spark Control
26252	Speedometer Drive Gear			Upon Application
26255	Rear Door Complete (Left)	28.00	26326	Coupe Body with Rumble Seat (R. D.)
26256	Rear Door Complete (Right)	24.00	00000	Upon Application
26257	Rear Door Glass	1.50	26327	Door Complete (Left Front) Upon Application

Part No.	Part Name	Price	Part No.	Part Name	Price
26328	Door Complete (Right Front)	Security	26391	Hood Complete (Closed Bodies)\$	
	Úpon Ap	plication	26392	Radiator Shutter	
26329	Door Complete (Left Rear) Upon Ap	plication	26393	Radiator Shutter	
26330	Door Complete (Right Rear)	FV	26394	Radiator Shutter	
00001	Upon Ap	plication	26395	Headlamp Complete	5.75
26331	Door Complete (Left Front)	nliantion	26396	Headlamp Complete	
26332	Upon Ap Door Complete (Right Front)	pheation	26397 26398	Headlamp Reflector. Headlamp Rim	3.25
20332	Upon Ap	nlication	26399	Headlamp Internal Band	2.50
26333	Door Complete (Left Rear) Upon Ap		26400	Headlamp Gasket	.20
26334	Door Complete (Right Rear)	pheation	26401	Headlamp Lens	.35
20004	Upon Ap	nlication	26402	Headlamp Rim Locking Screw	.10
26335	Door Complete (Left)Upon Ap		26403	Headlamp Focus Screw	.06
26336	Door Complete (Right)Upon Ap	plication	26404	Headlamp Focus Spring	.06
26337	Door Complete (Left) Upon Ap		26405	Headlamp Connector Socket	1.00
26338	Door Complete (Right)Upon Ap		26406	Headlamp Connector Plug	.10
26339	Window Regulator Handle		26407	Spark Control Rod (Lower) (L. D.)	.17
26340	Regulator Handle Escutcheon		26408	Spark Control Rod (Lower) (L. D.)	.17
26341	Door Glass (Front)Use N		26409	Spark Control Rod (Upper)	.12
26342	Front Floor Mat		26410	Throttle Cross Shaft Bushing	.05
26343 26344	Tail and Stop Lamp Rim	$\begin{array}{ccc} . & .80 \\ . & 2.00 \end{array}$	26411 26412	Control Cross Shaft Spring	.05
26344	Front Floor Mat (R. D.) Front Floor Mat (L. D.)		26413	Spark Control Cross Shaft Lever Accelerator Rod (R. D.)	.10
26346	Front Floor Mat (R. D.)		26414	Accelerator Rod (R. D.)	.20
26347	Left Door Lock with Locking Device		26415	Accelerator Bell Crank (R. D.)	.30
26348	Right Door Lock without Locking		26416	Accelerator Rod (Front) (R. D.)	.20
06.1	Device	. 1.35	26417	Accelerator Cross Shaft Lever (R. D.)	.55
26349	Left Front Door Lock with Locking	ng	26418	Throttle Cross Shaft (R. D.)	.25
	Device	. 1.35	26419	Spark Control Bell Crank (R. D.)	. 65
26350	Right Front Door Lock without Lock		26420	Throttle Operating Rod (Upper)	Prog.
A PART AND	ing Device	. 1.35		(R. D.)	.14
26351	Left Rear Door Lock with Locking		26421	Inrottle Operating Rod (Lower)	THE R
00000	Device	1.35	00400	(R. D.)	.12
26352	Right Rear Door Lock with Lockin		26422	Throttle Operating Rod (Lower)	10
26353	Device		26423	(R. D.)	.10
26354	Rear Floor Carpet	4.00	26424	Spark Control Rod (Lower) (R. D.)	.16
26355	Rear Floor Carpet (L. D.)	4.00	26425	Spark Control Rod (Lower) (R. D.)	.16
26356	Rear Floor Carpet (R. D.)	5.00	26426	Throttle Control Rod (Upper) (R. D.)	.16
26357	Door Lock Handle (Inside)	65	26427	Cowl Lamp Complete (Left)	2.50
26358	Dummy Prop Iron (Right)		26428	Cowl Lamp Complete (Right)	2.50
26359	Dummy Prop Iron (Left)		26429	Cowl Lamp Complete (Left)	3.50
26360	Dome Lamp Reflector	1.10	26430	Cowl Lamp Complete (Right)	3.50
26361	Radiator Complete		26431	Cowl Lamp Complete (Left)	3.00
26362	Radiator Shell	18.00	26432	Cowl Lamp Complete (Right)	3.00
26363	Radiator Filler Cap	. 2.35	26433	Cowl Lamp Rim	. 85
26364 26365	Door Complete (Right)Upon Ap	plication	26434 26435	Cowl Lamp Glass	.20
26366	Door Complete (Left)Upon Ap Rear Quarter Window Regulator	pheation	26436	Cowl Lamp Bracket Lead Washer	.02
20000	Handle	75	26437	Cowl Lamp Bracket (Left)	1.00
26367	Left Front Door		26438	Cowl Lamp Bracket (Right)	1.00
26368	Right Front Door		26439	Cowl Lamp Bracket (Left)	1.00
26369	Left Front Door		26440	Cowl Lamp Bracket (Right)	1.00
26370	Right Front Door		26441	Cowl Moulding (Top)	
26371	Left Rear Door		26442	Cowl Moulding (Side)	. 65
26372	Right Rear Door		26443	Cowl Moulding (Side)	. 65
26373	Left Rear Door		26444	Crankshaft	44.00
26374	Right Rear Door	. 16.50	26445	Cylinder Block Complete1	
26375	Front Floor Mat (L. D.)	2.15	26446	Steering Wheel	6.50
26376 26377	Front Floor Mat (R. D.)		26447 26448	Front Bumper Complete	10.50
26378	Left Door Complete		26449	Rear Bumper Complete	
26379	Front Floor Mat (L. D.)		26450	Rear Bumperette Complete Steering Control Tube with Base	8.00
26380	Front Floor Mat (R. D.)	2.10	20400	(L. D.)	1.00
26381	Camshaft Thrust Plug		26451	Steering Control Tube with Base	1.00
26382	Camshaft Thrust Plug Button			(R. D.)	.90
26383	Camshaft Thrust Plug Spring		26452	Steering Control Tube with Base	1.00
26384	Motor Underpan (Right) (L. D.)	80	26453	Spark Control Tube with Lever	1 September
26385	Motor Underpan (Left) (L. D.)		100	(L. D.)	1.25
26386	Motor Underpan (Right) (R. D.)		26454	Spark Control Tube with Lever (R. D.)	
26387	Motor Underpan (Left) (R. D.)		26455	Spark Control Tube with Lever Use No.	
26388	Hood Complete (Open Bodies)		26456	Throttle Tube with Lever (L. D.)	1.15
26389	Hood Complete (Closed Bodies)		26457		1.10
26390	Hood Complete (Open Bodies)	10.00	26458	Throttle Tube with LeverUse No.	20177

Part		298	Part	Dead Name	Price
No.	Part Name	Price	No. 26534	Part Name Radiator Complete\$	
26459	Gasoline Tank Support	.15	26535	Steer. Housing Cover	3.50
26461 26462	Choke Mounting PlateSteering Control Tube with Base	. 10	26536	Steer. Worm Adjusting Screw	.12
20402	(L. D.)	1.25	26537	Spark Control Rod (Lower) (L. D.)	.30
26463	Steering Control Tube with Base	METER:	26538	Spark Control Rod (Lower) (R. D.)	.20
100	(R. D.)	1.15	26539	Accelerator Rod (R. D.)	.15
26464	Spring Covers (Unit Package)	10.00	26540 26541	Clutch Pedal (R. D.)	$\frac{2.70}{1.50}$
26465 26466	Spring Covers (Unit Package)	10.00	26542	Clutch Pedal (R. D.)	2.70
26467	Oil Pressure Gauge Pipe	.50	26543	Clutch Pedal Spring (R. D.)	.15
26468	Choke Complete	. 50	26544	Clutch Pedal Spr. Lever (R. D.)	.15
26469	Tire Carrier (Left)	3.25	26545	Clutch Pedal Shaft (R. D.)	1.25
26470	Tire Carrier (Right)	3.25	26546	Accelerator Shaft (R. D.)	.25
26471	Tire Carrier Bracket (Left)	.60	26547 26548	Throttle Control Rod (Upper) (R. D.) Throttle Control Rod (Lower) (R. D.)	.10
26472 26473	Tire Carrier Bracket (Right) Tire Carrier Bracket (Left)	.60	26549	Throttle Control Lever (R. D.)	.70
26474	Tire Carrier Bracket (Right)	.60	26550	Foot Brake Pedal (R. D.)	2.25
26475	Tire Carrier Brace	.45	26551	Brake Pedal Shaft (R. D.)	.70
26476	Tire Carrier Brace	.45	26552	Speedo. Drive Gear (3 teeth)	3.00
26477	Tire Carrier Brace Bracket (Left)	1.00	26553	Speedo. Drive Pinion (12 teeth) Speedo. Drive Gear (3 teeth)	$\frac{2.10}{3.00}$
26478 26479	Tire Carrier Brace Bracket (Right)	$1.00 \\ .10$	26554 26555	Speedo. Drive Gear (5 teeth)	2.10
26480	Demountable Rim Bolt Demountable Rim Bolt Nut. Use No.		26556		16.00
26481	Windshield Complete (L. D.)		26557	Hood Complete	16.00
26482	Windshield Complete (R. D.)	17.50	26558	Light. and Ign. Switch	2.50
26483	Windshield Glass	8.00	26559	Tail Lamp Bracket and Tube	$\frac{2.50}{10.50}$
26484	Tail and Stop Lamp	$\frac{2.15}{3.25}$	26560 26561	Front Bumper Complete	4.00
26485 26486	Tail and Stop Lamp	00	26562	Steer. Gear Bracket (L. D.)	2.15
26487	Tail and Stop Lamp Rim		26563	Steer. Gear Bracket (R. D.)	2.50
26488	Trunk with Two Suit Cases	37.50	26564	Battery Insp. Cutout Cover	.15
26489	Trunk Less Suit Cases	25.00	26565	Acc. Cross Shaft Lever (R. D.)	.25
26490	Tail and Stop Lamp Rim Fast. Screw.	.03	26566	Starting Motor Clamp Screw	.06
26491	Tail Lamp Lens	. 65	26567 26568	Gas Strainer Bowl	
26492	Tail Lamp Bee Hive Semaphore Use No.	26491	26570	Demountable Rim Bolt (Export)	.10
26493	Tail Lamp Lower Glass (Plain)	.16	26571	Trans. Bearing Retainer (Front)	1.50
26494	Tail Lamp Lower Glass Lug	.05	26572	Trans. Case with Studs	5.75
26495	Tail Lamp Bracket	.25	26573	Hand Brake Lever Ratchet Hand Brake Lever Ratchet Pawl	.35 $.15$
26497 26498	Front Spring Front Fender (Right)	4.25	26574 26575	Carburetor Gasket	.02
26499	Front Fender (Left)	20.00	26576	In. and Ex. Manifold Stud	.06
26500	Lighting and Ignition Switch	2.50	26577	Valve Tappet Guide Dowel Ring	.06
26501	Lighting and Ignition Switch Key	.25	26578	Expansion Plug, 2" dia	.10
40.00	(Series SD-251 to 500)	F 00	26579	Spec. Cap Screw	.05
26506 26507	Windshield Side Arm (Right) Windshield Side Arm (Left)	5.00 5.00	26580 26581	Uni. Jt. Spider Bushing Ring	.05
26508	Brake Cross Shaft Bearing Plate	.25	26582	Generator Sprocket Cover	.18
26509	Brake Cross Shaft Bracket (Center)	.40	26583	Oil Relief Valve Plug Gasket. Use No.	24529
26510	Service Brake Cross Shaft Lever (Inner)		26584	Front Brake Backing Plate, Right	1.60
26511	Emergency Brake Cross Shaft Lever		26585	Oil Filler Body	$\frac{1.10}{.05}$
26512	(Outer)	.70 .08	26586 26587	Special Stud	.15
26512 26513	Brake Lever Connecting Link Rear Brake Rod (Front)	.45	26588	Spark Plug Wire Tube	.95
26514	Jack with Handle	2.50	26589	Drive Pinion Housing Shim	.25
26515	Tire Cover (For 28x4.75 Tires)	3.25	26590	Differential Bearing	6.25
26516	Tire Cover (For 29x5.00 Tires)	3.25	26591	Diff. Bearing Adj. Nut Lock	$.15 \\ .75$
26517	Tire Cover (Export)	$\frac{2.00}{.16}$	26592 26593	Diff. Bearing Adjuster Diff. Side Gear	3.60
26518 26519	Side Apron (Left)	3.00	26594	Diff. Pinion	1.50
26520	Side Apron (Right)	3.00	26595	Diff. Pinion Shaft Ret. Screw	.12
26521	Side Apron (Left)	3.00	26596	Diff. Pinion Shaft	.90
26522	Side Apron (Right)	3.00	26597	Diff. Thrust Block	$\frac{1.10}{1.10}$
26524	Flywheel and Clutch Cover Underpan		26598 26599	Diff. Pinion Spacer Diff. Bearing Nut Lock Gasket	.06
26525	CompleteFlywheel and Clutch Cover Stud	$4.50 \\ .10$	26700	Diff. Case	6.75
26526	Spark Lever (Lower) Clip	.03	26701	Oil Pump Drive Shaft Gear	1.75
26527	Accelerator Bell Crank (R. D.)	.45	26702	Crankshaft Sprocket	3.25
26528	Floor Mat (L. D.)	2.15	26703	Camshaft Bushing	1.60
26529	Floor Mat (L. D.)	2.15	26704	Conn. Rod Bearing Shim	.05
26530 26531	Front Wheel Complete Front Wheel	9.50 5.50	26705 26706	Crankshaft Thrust Shim	
26532	Demountable RimUse No.		26707	Crankshaft Thrust Plate	1.30
26533	Expansion Plug, 15/8" dia	.07	26708	Valve Chamber Cover	1.00

Part No.	Part Name	Price	Part No.	Part Name	Price
26709	Crankshaft Starting Jaw		26780	Oil Pressure Gauge	\$1.65
26710	Starting Jaw Collar	.90	26781	Ammeter	1.20
26711 26712	Valve Chamber Cover Gasket Flywheel Housing Dowel Pin	.08	26782	Gasoline Gauge (on Dash)	2.50
26713	Valve (marked Ex.)	$\begin{array}{c} .35 \\ 1.25 \end{array}$	26783	Choke Mounting Plate	.40
26714	Conn. Rod Bolt	.30	26784 26785	Light, and Ign. Switch	2.50
26715	Crankshaft Spacing Washer	.90	26786	Instrument Board	
26716	Rear Bearing Filler Block Screw	.10	26787	Inst. Board Bezel and PlateGas Tank Complete	2.20
26717	Cyl. Head Stud	.15	26788	Gas Gauge Gasket (Tank Unit)	
26718	Oil Control Valve Body Stud	.05	26789	Gas Tank Filler Cap	.04
26719	Clutch and Brake Shaft Spring	.05	26790	Gas Tank Support	4.25
26720	Brake Shaft Spring Washer	.03	26791	Front Fender Welt	.14
26721	Control Rod Spring Washer	.02	26792	Rear Fender Welt	.35
26722 26723	Spark Rod Cross Shaft Spring	.03	26793	Hood Sill Spacer	.08
26724	Flywheel Housing Dust Cover Gasket Flywheel Housing Stud	$.25 \\ .05$	26794	Inst. Board Wire with Socket	.35
26725	Crankshaft Oil Thrower	.10	26795	Hub Cap Wrench	.30
26726	Clutch Pedal (L. D.)	1.00	26796 26797	Cowl Lamp Complete (Right)	3.00
26727	Clutch Pedal (R. D.)	1.25	26798	Cowl Lamp Complete (Left)	3.00
26728	Clutch Pedal Adj. Lever (L. D.)	.60	26799	Light. & Ignition Switch. Choke Mounting Plate.	2.50
26729	Clutch Pedal Adj. Lever (R. D.)	1.25	26800	Inst. Board Bezel and Plate.	$\frac{.40}{4.40}$
26730	Clutch Pedal Adj. Lever Washer	.10	26801	Oil Pump Gear Hole Cover	.10
26731	Front Brake Backing Plate (Left)	1.60	26802	Oil Pump Gear Hole Cover Gasket	.02
26732	Rear Brake Backing Plate (Right)	1.60	26803	Spare Tire Lock with Key	5.00
26733 26734	Rear Brake Backing Plate (Left)	1.60	26810	Rear Axle Housing (Right)	19.00
20134	Brake Shoe Assembly	6.00	26811	Rear Axle Housing (Left)	19.00
	Note: Brake Shoe Assembly returned for re- lining will be accepted for full credit less a		26812	Frame Complete	41.00
	charge of \$2.35 list, for relining.		26813 26814	Frame Complete	50.00
26735	Brake Shoe Lining (export only)	4.20	26815	Frame Complete (R. D.)	
26736	Front Wheel Complete	10.00	26816	Steering Gear Bracket (R. D.)	2.75
26737	Brake Reinforcement Plate	.80	26817	Steer. Gear Bracket Bushing.	$\frac{2.70}{.35}$
26738	Brake Anchor Pin	.35	26818	Gas Tank Support Complete	3.50
26739	Brake Take Up Cam	.45	26819	Gas Tank Support Complete	3.50
26740 26741	Brake Adjusting Screw	. 50	26820	Rear Spring Bracket	1.00
26742	Brake Backing Plate Cover Plate Brake Adj. Screw Pivot Nut (Right)	.07	26821	Step Hanger (Front)	.60
26743	Brake Adj. Screw Pivot Nut (Right) Brake Adj. Screw Pivot Nut (Left)	.30	26822	Tire Carrier Complete	3.00
26744	Brake Primary Brake Shoe Spring.	.14	26823 26824	Tire Carrier Brace	.20
26745	Brake Shoe Spacer Pin Washer	.02	26825	Tire Carrier Brace Bracket Tire Carrier Brace	.45
26746	Front Wheel	6.50	26826	Tire Carrier Bracket (Right)	.50
26747	Brake Adj. Screw Spring	.07	26827	Tire Carrier Bracket (Left)	.65
26748	Brake Shoe Spacer Pin Spring	.05	26828	Front Spring Complete	3.75
26749	Brake Camshaft and Crank	. 50	26829	Rear Spring Complete	6.25
26750 26751	Brake Cam Plates and Blocks	.45	26830	Rear Spring Complete	5.85
26752	Brake Carrier Bracket Front Wheel Brake Drum	. 65	26831	Front Shock Absorber Clin	.30
26753	Rear Wheel Complete	2.25	26832	Rear Shock Absorber Clin	. 50
26754	Front Brake Crank Lever	.70	26833	Brake Shoe Assembly	8.00
26755	Brake Cam Shaft Ret, Washer, Use No.	24289		Note: Brake Shoe Assembly returned for re- lining will be accepted for full credit less a	
26756	Rear Wheel	6.50		charge of \$4.00 list for relining.	
26757	Demountable Rim	3.25	26834	Rear Brake Lever (Right)	1.70
26758	Demountable Rim Wedge	.10	26835	Rear Brake Lever (Left)	1.70
26759 26760	Demountable Rim Bolt Nut	.05	26836	Brake Shoe Lining (Export Only)	1.15
26761	Demountable Rim Bolt Front Brake Control Lever (Left)	1.25	26837	Brake Backing Plate (Front) (Left)	3.40
26762	Front Brake Control Lever (Right)	$\frac{1.25}{1.25}$	26838	Brake Backing Plate (Front) (Right)	3.40
26763	Propeller Shaft	9.00	26839 26840	Brake Backing Plate (Rear) (Left)	3.40
26764	Uni. Jt. Casing Spring	.11	26841	Brake Backing Plate (Rear) (Right) Front Brake Crank Lever	3.40
26765	Flywheel Ring Gear	2.15	26842	Bevel Ring Gear	.80
26766	Front Wheel Complete	10.00	26843	Drive Pinion and Shaft	8.75 7.75
26767	Front Wheel Complete	10.00	26844	Propeller Shaft with Yoke End	7.75
26768	Front Brake Dust Cover	.20	26845	Front Wheel Complete (Wood)	13.50
26769 26770	Demount. Rim Wrench	.50	26846	Front Wheel Complete (Wood)	12.50
26771	Hub Cap (Monogrammed)	1.15	26847	Front Wheel (Wood)	8.00
26772	Grease Cup.	.25	26848	Front wheel Hub	3.50
26773	Trunk Rack	2.75	26849 26850	Front Wheel Hub.	3.50
26774	Cowl Lamp Lens (Convex)	.25	26851	Hub Bolt with Nut. Front Wheel Brake Drum.	.07
26775	Rear Apron Top	5.50	26852	Front Wheel Brake Drum.	3.00
26776	Rear Apron, Side (Right) (L. D.)	.80	26853	Brake Drum Hole Cover High No.	2.25
26777	Rear Apron, Side (Left) (L. D.)	.80	26854	Hub Cap	1.25
26778	Rear Apron, Side (Right) (R. D.)	.60	26855	near wheel Complete (Wood)	12 00
26779	Rear Apron, Side (Left) (R. D.)	.60	26856	Rear Wheel Complete (Wood)	12.00

Part No.	Part Name	Price	Part No.	Part Name	Price
26857	Rear Wheel (Wood)	\$8.00	26933	Rear Brake Rod (Front) Front Brake Rod (Rear)	\$0.40 .50
26858 26859	Rear Wheel (Wood)	8.00 2.50	26934 26935	Steering Gear Housing (L. D.)	3.00
26860	Rear Wheel Hub.	2.50	26936	Steering Gear Housing (R. D.)	3.25
26861	Rear Wheel Brake Drum	3.00	26937 26938	Steering Housing Gasket	2.75
26862 26863	Rear Wheel Brake Drum Demountable Rim	2.25 3.25	26939	Worm Wheel and Shaft (R. D.)	2.70
26864	Radiator Complete	59.00	26940	Pitman Arm	1.30
26865	Radiator Complete	62.00	26941 26942	Steering Worm Gear (L. D.) Steering Worm Gear (R. D.)	$\frac{1.00}{.95}$
26866 26867	Radiator Core		26943	Worm Adjusting Nut	.35
26868	Radiator Shell	27429	26944	Worm Adjusting Nut Spacer	.65 $.02$
26869 26870	Radiator Tie Rod	$\begin{array}{c} .25 \\ 1.25 \end{array}$	26945 26946	Steering Housing Oil Seal Oil Seal Retainer	.02
26871	Radiator Cap Gasket	.03	26947	Steering Housing Felt Washer	.02
26872	Radiator Cap Gasket	.07	26948	Accelerator Rod (R. D.)	.50
26873 26874	Crank Hole Flange	.30	26949 26950	Mast Jacket Bracket (Opper) Mast Jacket Bracket	.85
26877	Water Outlet Header		26951	Radiator Splash Apron	3.75
26878	Flywheel	18.00	26952 26953	Radiator Splash Apron Shield Front Fender (Left)	20 00
26879 26880	Flywheel	$\frac{16.00}{2.15}$	26954	Front Fender (Right)	20.00
26881	Oil Pan Complete	5.00	26955	Front Fender (Left)	16.00
26882	Oil Pan Trough Complete	4.90	26956 26957	Front Fender (Right)Front Fender (Left)	20.00
26883 26884	Flared Tube Union, $\frac{7}{16}''$	$\begin{array}{c} .16 \\ 1.10 \end{array}$	26958	Front Fender (Right)	20.00
26885	Fan Hub	2.25	26959	Front Fender (Left)	16.00
26886	Fan Hub Gasket	.07 1.80	26960 26961	Front Fender (Right) Front Fender Welt	.35
26887 26888	Fan Spindle Thrust Collar	.10	26962	Front Fender Welt	.35
26889	Fan Spindle Thrust Collar Cap	.13	26963	Rear Fender (Left)	$8.25 \\ 8.25$
26890	Fan Spindle Washer	.25 $.25$	26964 26965	Rear Fender WeltUse No.	
26891 26892	Fan Spindle	1.50	26966	Rear Fender Welt	.30
26893	Fan Hub		26967	Side Apron (Left)	
26894 26895	Carburetor Choke Complete Carburetor Choke Complete	$\frac{1.00}{1.00}$	26968 26969	Side Apron (Left)	
26896	Muffler Valve Control Knob	. 50	26970	Side Apron (Right)	4.00
26897	Muffler Toil Ding	$\frac{2.40}{1.10}$	26971 26972	Rear Top Apron	5.00
26898 26899	Muffler Tail Pipe		26973	Running Board (Left)	5.00
26900	Muffler Tail Pipe Clamp	.11	26974	Running Board (Right)	
26901	Muffler Tail Pipe BracketGas Tank Complete		26975 26976	Running Board (Left)	
26902 26903	Gas Tank Complete		26977	Running Board Moulding (Inner)	.50
26904	Gasoline Gauge Gasket Use No	. 26788	26978	Running Board Moulding (Inner) Running Board Moulding (Outer)	1.15
26905 26906	Gas Tank to Vacuum Pipe Vacuum to Carburetor Pipe		26979 26980	Running Board Moulding (Inner)	.60
26907	Clutch Plate with Hub		26981	Running Board Moulding (Inner)	. 60
26908	Clutch Friction Sector		26982 26983	Hood Complete	19.75 20.50
26909 26910	Gear Shift Lever (L. D.)	6.00 . 26909	26984	Hood Sill (Right)	1.30
26911	Shift Lever Guide Pin	.12	26985	Hood Sill (Left)	$\frac{1.30}{1.25}$
26912	Shift Lever Guide Pin		26986 26987	Hood Sill (Right) Hood Sill (Left)	
26913 26914	Shift Lever SpringShift Lever Cap		26989	Sedan Body Complete (L. D.)Upo	n App.
26915	Shift Lever Cover Pin	.12	26990	Sedan Body Complete (R. D.)Upo Sedan Body Complete (L. D.)Upo	n App.
26916	Shift Lever Spring Retainer Reverse Stop Plunger		26991 26992	Sedan Body Complete (R. D.)Upo	n App.
26917 26918	Reverse Stop Plunger Cap		26993	Door Complete with Glass. Upon App	lication
26919	Reverse Stop Plunger Spring		26994	Door Complete with Glass. Upon App Door Complete with Glass. Upon App	lication
26920 26921	Reverse Stop Plunger Washer Speedometer Drive Pinion		26995 26996	Door Complete with Glass. Upon App	lication
26922	Speedometer Drive Gear	2.50	26997	Door Complete with Glass. Upon App	lication
26923	Brake Pedal Pull Rod	50	26998	Door Complete with Glass. Upon App Door Complete with Glass. Upon App	lication
26924 26925	Brake Pedal Pull Rod		26999 27000	Door Complete with Glass. Upon App	lication
26926	Hand Brake Pull Rod	55	27001	Door Bumper (Rubber)	
26927	Front Brake Rod (Rear)		27002 27003	Door Bumper Retainer Window Regulator Complete	04
26928 26929	Hand Brake Pull Rod		27004	Window Regulator Complete	. 1.40
26930	Rear Brake Rod (Front)	40	27005	Door Window Regulator Handle	
26931	Rear Brake Rod (Front)	35 50	27006 27007	Rear Quart. Wind. Reg. Handle Regulator Handle Escutcheon	
26932	TVORT DIARC TVOG (TIUM)				

Part No.	Part Name	Price	Part No.	Part Name	Price
27008	Door Window Glass		27082	Door Glass Upper Bumper	\$0.20
27009 27010	Rear Quarter Window Glass	4.25 2.00	27083 27084	Rear Window Glass Upper Bumper Deck Door Lock Handle	$\frac{.25}{2.40}$
27011	Door Glass (Front)	5.00	27085	Right Door Moulding	2 65
27012	Door Glass (Rear)	5.75	27086	Right Door Moulding	2.50
27013	Rear Quarter Glass	5.25	27087	Left Door Moulding	2.50
27014 27015	Front Seat Cushion		27088 27089	Left Door Moulding	$\frac{2.50}{1.80}$
27016	Rear Seat Cushion		27090	Back Window Moulding (Side)	.10
27017	Front Seat Cushion		27091	Back Window Moulding (U. and L.)	.15
27018 27019	Rear Seat Cushion	$\frac{28.00}{2.75}$	27092 27093	Windshield Frame (L. D.)	18.50
27020	Rear Quarter Window Curtain	2.40	27094	Windshield Frame (R. D.)	18.50 18.50
27021	Robe Rail Complete	5.00	27095	Windshield Frame (R. D.)	18.50
27022	Assist Cord	4.00	27096	Windshield Glass	8.00
27023 27024	Assist Cord Front Floor Mat (L. D.)	$\frac{3.00}{3.25}$	27097 27098	Windshield Glass	$8.00 \\ 4.00$
27025	Front Floor Mat (R. D.)	3.25	27099	Windshield Swing Arm	3.40
27026	Front Floor Mat (L. D.)	3.25	27100	Windshield Swing Arm Knob	.20
27027	Front Floor Mat (R. D.)	3.25	27101	Tail Lamp Bracket and Tube (L. D.).	2.50
27028 27029	Rear Floor Carpet	6.50	27102 27103	Windshield Swing Arm Knob Tail Lamp Bracket and Tube (R. D.).	2.50
27030	R. F. Door Hinge (Upper)	.35	27104	Cowl Moulding (Top)	2.25
27031	R. F. Door Hinge (Center)	.35	27105	Cowl Moulding (Side) (Right)	1.40
27032 27033	L. F. Door Hinge (Upper) L. F. Door Hinge (Center)	.35	27106 27107	Cowl Moulding (Side) (Left)	1.40
27034	R. F. Door Lock	.80	27108	Headlamp Complete	10.00
27035	L. F. and R. R. Door Lock	.80	27109	Headlamp Reflector	3.10
27036 27037	L. R. Door Lock	.80	27110 27111	Headlamp Door	
27038	L. F. Remote Control Lock Plate	.40	27112	Headlamp Complete	1.90 10.00
27039	R. R. Remote Control Lock Plate	.40	27113	Headlamp Door	2.50
27040 27041	L. R. Remote Control Lock Plate Outside Door Handle	$\frac{.40}{2.75}$	27115 27116	Ignition Lock	4.75
27041	Outside Door Handle	1.60	27117	Inst. Panel Switch Knob	.50
27043	Outside Door Handle KeyUse No.		27118	Inst. Panel Lamp Socket	.35
27044 27045	Door Lock Handle (Inside)	$\begin{array}{c} .70 \\ 2.00 \end{array}$	27119 27120	Ammeter Instrument Gasket	1.10
27046	Cowl Side Vent Hinge Pin	.10	27121	Spark Control Rod (Lower)	.01
27047	Cowl Side Vent Frame Complete	.75	27122	Oil Pressure Gauge	1.25
27048 27049	Inst Board Cowl Bar Cover Panel Door Glass Upper Bumper	$\frac{4.00}{.20}$	27123 27124	Oil Pressure Gauge Pipe	.85
27050	Rear Quarter Glass Upper Bumper	.18	27125	Heat Indicator (on Dash)	2.05
27051	Dome Lamp Reflector and Rim	1.10	27126	Heat Indicator Element	1.95
27052 27053	Dome Lamp Glass Retaining Ring	.25	27127 27128	Gas Gauge (on Dash)	2.35
27054	Right Front Door Moulding	1.80	27129	Hub Cap Wrench	.30 26514
27055	Left Front Door Moulding	1.80	27130	Tire Cover	26516
27056 27057	Rear Door Moulding	$\frac{1.80}{1.80}$	$27131 \\ 27132$	Tire Cover Trunk Rack Support Bracket	3.25
27058	Rear Quarter Moulding (Left)	1.80	27132	Hex. Hd. Cap Screw (Special)	1.25
27059	Under Door Belt Moulding	1.55	27134	Hex. Hd. Cap Screw (Special)	.04
27060	Right Front Door Moulding Left Front Door Moulding	2.50	27135 27136	Oil Tube Union Nut. Trunk Rack Support Arm	.20
27061 27062	Rear Door Moulding	2.65	27137	Trunk Rack Hinge Lever	.35
27063	Rear Quarter Moulding (Right)	2.65	27138	Trunk Rack Latch Handle	.35
27064	Rear Quarter Moulding (Left)	2.65	27139	Trunk Rack Bumper	.05
27065 27066	Back Window Moulding (Side) Back Window Moulding (U. and L.)	.10	27140 27141	Front Bumper Complete	$9.50 \\ 9.75$
27067	Coupe Body Complete (L. D.) Upon	App.	27142	Rear Bumperette Complete	8.25
27068	Coupe Body Complete (R. D.)Upon	App.	27143	Rear Bumper Complete	11.50
27069 27070	Coupe Body Complete (L. D.)Upon Coupe Body Complete (R. D.)Upon		27144 27145	Rear Bumperette Complete Inst. Panel Back Plate	10.00
27071	Door Complete with Glass. Upon Appli	cation	27146	Inst. Panel Bezel	2.20
27072	Door Complete with Glass. Upon Appli		27147	Inst. Panel Bezel Gasket	.12
27073 27074	Door Complete with Glass. Upon Appli Door Complete with Glass. Upon Appli		27148 27149	Inst. Panel Face Gasket	1.00
27075	Door Window Glass		27150	Inst. Panel Face Plate Spring	.01
27076	Back Window Glass	1.75	27151	Clutch Driven Plate Complete.	6.00
27077 27078	Door Glass		27152 27153	Clutch Driven Plate Complete. Use No. Clutch Friction Sector	2.50
27079	Rumble Seat Cushion	20.00	27154	Clutch Friction Sector Use No.	26908
27080	Rumble Seat Cushion		27155	Clutch Cover with Levers	3.35
27081	Deck Floor Carpet	0.00	27156	Clutch Cover with Levers	4.45

Part No.	Part Name	Price	Part No.	Part Name	Price
27157	Clutch Release Pad	\$0.15	27230		\$0.75
27158	Clutch Release Pad Cap Screw	.05	27231	Clutch Collar Complete Use No. Clutch Pedal (L. D.)	1.40
27159 27160	Clutch Release Pad Cap Washer Clutch Cover Release Lever (Sets of 3)	$\frac{.01}{1.05}$	27233 27234	Clutch Pedal (R. D.)	2.25
27161	Clutch Cover Release Lever (Sets of 3)	1.35	27235	Clutch Pedal Adj. Lever (R. D.)	1.50
27162	Clutch Cover Release Lever Pin	.10	27236	Pedal Return Spring Lever (R. D.)	.05
27163 27164	Clutch Cover Release Lever Pin Clutch Release Lever Spring	.10	27237 27238	Clutch Pedal Shaft (R. D.) Gear Shift Lever and BallUse No.	
27165	Clutch Release Lever Spring	.10	27239	Foot Brake Pedal	1.35
27166	Clutch Release Spring Button	.05	27240	Foot Brake Pedal (R. D.) Brake Pedal Return Spring	$\frac{2.00}{.20}$
27167 27168	Clutch Spring	.10	27241 27242	Brake Cross Shaft	1.65
27169	Clutch Spring Cup	.15	27243	Brake Cross Shaft (R. D.)	1.95
27170	Clutch Spring Insulator	.05	27244	Brake Pedal Shaft (R. D.)	.50
27171 27172	Clutch Pressure Ring	$\frac{2.50}{3.50}$	27245 27246	Brake Idler Lever (Front)	.70
27173	Clutch Thrust Bearing	3.50	27247	Brake Idler Lever (Rear) (Right)	.70
27174	Back Window Curtain	2.40	27248	Brake Idler Lever (Rear) (Left)	$.70 \\ .70$
27175 27176	Choke Mounting Plate	.15	27249 27250	Cross Shaft Lever (Inner) Cross Shaft Lever (Rear) (Outer)	1.25
27177	Light, and Ignition Switch	2.50	27251	Brake Lever Overrunning Link	.12
27178	Light. and Ignition Switch	2.50	27252	Cross Shaft Lever Conn. Link	.07
27180	Oil Pump to Filtrator Tube Oil Pump to Oil Relief Tube	$\frac{1.50}{1.60}$	27253 27254	Brake Pedal Pull Rod (L. D.) Hand Brake Rod	.35 .35
27181 27182	Oil Pump to Oil Relief Tube Tee	.65	27255	Hand Brake Rod	.35
27183	Frame Complete	65.00	27256	Front Brake Rod (Front)	.25
27184 27185	Tire Carrier Cradle (Rear)	$\frac{1.05}{1.05}$	27257 27258	Front Brake Rod (Rear)	.45
27186	Tire Carrier Cradle (Front) Tire Carrier Rim Seat	.60	27259	Rear Brake Rod (Front)	.35
27187	Tire Carrier Rim Clamp	.30	27260	Rear Brake Rod (Front)	$.35 \\ .03$
27188	Tire Carrier Rim Clamp	26497	27261 27262	Brake Rod Conn. Link (R. D.) Steering Gear Housing (R. D.)	5.00
27189 27190	Front Spring Complete Use No. Rear Spring Complete	9.50	27263	Worm Wheel and Shaft (R. D.)	3.90
27191	Rear Spring Center Bolt	.10	27264	Worm Wheel Bracket with Bushings	3.30
27192	Spring Bolt		27265 27266	Worm Wheel Bracket Bushing	$\frac{.25}{2.00}$
27193 27194	Rear Spring Clip Rear Brake Backing Plate (Left)	$\frac{.55}{3.40}$	27267	Main Tube with Silencer	3.60
27195	Rear Brake Backing Plate (Right)	3.40	27268	Mast Jacket with BushingUse No.	
27196	Rear Brake Shoe Assembly	9.50	27269 27270	Steering WheelSteering Control Tube with Base	5.00
	Note: Brake Shoe Assembly returned for re- lining will be accepted for full credit less a	1141	27271	Spark Control Tube with Lever	.90
	charge of \$4.40 list for relining.	27.65	27272	Throttle Control Tube	1.10
27197	Rear Brake Reinforcement Plate	1.35	27273 27274	Steering Conn. Rod (L. D.) Steering Con. Rod (R. D.)	$\frac{2.50}{2.25}$
27198 27199	Rear Brake Anchor PinUse No. Rear Brake Anchor Pin Washer		27275	Throttle Control Wire	.03
27200	Rear Brake Take up Cam	.70	27276	Spark Control Rod (Lower)	.15
27201	Rear Brake Adjusting Screw		27277 27278	Spark Control Rod (Lower) (R. D.) Throttle Control Rod (R. D.)	.15
27202 27203	Rear Brake Adj. Screw Pivot Nut Rear Brake Adj. Screw Pivot Nut	Comment of the Commen	27279	Throttle Operating Rod (R. D.)	.15
27204	Rear Brake Shoe Spring	.20	27280	Radiator Splash Apron	3.00
27205	Rear Brake Shoe Spring		27281 27282	Side Apron (Right)	$\frac{3.50}{3.50}$
27206 27207	Rear Brake Carrier Bracket		27283	Running Board Complete (Left)	3.50
27208	Rear Brake Control Lever	. 90	27284	Running Board Complete (Right)	3.50
27209	Rear Brake Oil Drain Propeller Shaft with Yoke End		27285 27286	Hood Sill (Left)	$\frac{1.10}{1.10}$
27210 27211	Front Wheel Complete		27287	Front Wheel Hub Cap	.25
27212	Front Wheel Brake Drum Bolt	.15	27288	Headlamp Complete	6.15
27213 27214	Rear Wheel Complete			Horn	$7.50 \\ .20$
27214	Rear Wheel Brake Drum Bolt	THE RESERVE TO THE		Battery Clamp Bolt	. 50
27216	Demountable Rim (6" Rim)	10.00	27292	Hub Cap Wrench	.75 .60
27217	Demountable Rim (5" Rim)			Front Bumper Complete	3.25
27218 27219	Demountable Rim Side Ring (6" Rim Demountable Rim Clamping Ring			Tire Carrier Complete	3.75
27220	Demountable Rim Bolt	. 15	27296	Front Wheel Hub Cap	1.40
27221	Demountable Rim Bolt Nut			Crankshaft Bearing (Front) (Lower) Crankshaft Bearing (Center) (Lower)	$\frac{1.40}{.85}$
27222 27223	Demountable Rim Clamp Radiator Complete			Crankshaft Bearing (Rear) (Lower)	1.35
27224	Brake Adjusting Tool	20	27300	Crankshaft Bearing (Front) (Upper).	1.00
27226	Fan BeltExhaust Pipe			Crankshaft Bearing (Center) (Upper) Crankshaft Bearing (Rear) (Upper)	$\begin{array}{c} .90 \\ 1.35 \end{array}$
27227 27228	Muffler Tail PipeUse No			Crankshaft Bearing Cap (Front)	1.20
27229	Motor Underpan (Right) (R. D.)				1.20

Part No.	Part Name	Price	Part No.	Part Name	Price
27305	Crankshaft Bearing Cap (Rear)	\$1.35	27379	Rear Axle Gear Shift Lever	
27306	Crankshaft Bearing Dowel	.05	27380	Rear Axle Gear Shift Lever Bushing	.20
27307 27308	Running Board Complete (Left)	3.75	27381	Rear Axle Gear Shift Lever Bracket	1 40
27309	Running Board Complete (Right) Running Board Moulding (Outer)	$\frac{3.75}{1.15}$	27382 27383	Rear Axle Shift Lever Shaft. Use No.	
27310	Running Board Moulding (Inner)	.60	27384	Rear Axle Shift Lever Shaft Pin Rear Axle Shift Lever Spring	$.04 \\ .04$
27311	Running Board Moulding (Inner)	. 60	27385	Rear Axle Shift Idler Bracket	1.65
27312	Hood Sill (Right)	1.25	27386	Rear Axle Shift Idler Bracket Pin	.20
27313 27314	Hood Sill (Left)	$\frac{1.25}{3.75}$	27387 27388	Rear Axle Shift Idler Lever	.70
27315	Side Apron (Left)	3.75	27389	Rear Axle Shift Idler Lever Bushing Rear Axle Control Tube	.15
27316	Side Apron (Right)	3.75	27392	Rear Axle Control Tube (Rear)	1 75
27317	Side Apron (Left)	3.75	27393	Control Gear and Pinion Housing	24 00
27318 27319	Windshield Complete	18.50	27394 27395	Inter. Reduction Gear	14.00
27320	Windshield Glass	8.00	27396	Roller Bearing Complete. Roller Bearing Spacer.	7.25
27321	Front Door Moulding (Left)	2.50	27397	Reduction Gear Thrust Washer (Large)	$.35 \\ .70$
27322 27323	Front Door Moulding (Right)	2.50	27398	Thrust Washer Lock Pin	01
27324	Door Moulding	2.50	27399 27400	Control Reduction Drive Gear	
27325	Door CompleteUpon App	lication	27401	Control Drive Gear Roller Bearing Control Dr. Gear Roller Bearing Race	$\frac{5.00}{7.00}$
27326	Door Glass (Front)	5.00	27402	Control Roller Bearing Retainer	.18
27327	Door Complete (Right)Upon App	ication	27403	Control Rol'r Bear's and Gear Retainer	.20
27328 27329	Door Complete (Left)Upon Appl Door Glass	5.50	27404 27405	Control Sliding Clutch Gear	7.50
27330	Front Door Hinge (Right)	.30	27406	Sliding Clutch Shift Bar. Sliding Clutch Gear Fork.	1.50
27331	Front Door Hinge (Left)	.30	27407	Sliding Clutch Fork Pin	$\frac{1.50}{.01}$
27332	Front Door Hinge (Right)	50	27408	Shift Bar Retaining Nut	.40
27333 27334	Front Door Hinge (Left)	$\frac{.50}{9.75}$	27409 27410	Shift Bar Retaining Nut Lock Nut.	.25
27335	Rear Brake Rod (Front)	.35	27411	Shift Bar Washer Shift Bar Retainer Screw Gasket	.01
27336	Rim Side Ring (5" rim)	3 00	27412	Shift Bar End	$\frac{.01}{1.60}$
27337	Rear Fender (Left)	7 00	27413	Shift Bar Spring	.02
27338 27339	Rear Fender (Right) Demountable Rim Wrench	$\frac{7.00}{.60}$	27415 27416	Control Housing Hole Cover	.12
27340	Carburetor Feed Pipe	.35	27417	Control Housing Hole Cover Gasket Adjusting Cage Locking Cap	.02
27341	Governor Complete	14.50	27418	Adjusting Cage Locking Can Gasket	.02
27342 27343	Governor Stud.		27419	Leather Washer	.30
27344	Shift Lever Control Cover	$\frac{3.00}{.02}$	27420 27421	Leather Washer Cup. Pinion Leather Washer Retainer	.08
27345	Shift Lever Control Cover	2.15	27422	Oil Baffle Washer	$.05 \\ .05$
27346	Cross Shaft Bracket	1.05	27423	Governor Gasket	05
27347 27348	Cross Shaft Bracket	1.70	27429	Radiator Shell Complete	17.25
27349	Air Cleaner Assembly	$\frac{.50}{3.50}$	27430 27431	Hunting Link Timing Chain Rocker Pin	.70
27350	Bell Crank Lever Pivot Stud	.15	27432	Rocker Pin Bushing	$.12 \\ .02$
27351	Floor Mat (L. D.)		27433	Timing Chain Washer	.02
27352 27353	Floor Mat (R. D.). Front Wheel Brake Drum	$\frac{2.15}{4.85}$	27434 27435	Hunting Link	.70
27354	Front Shock Absorber Clip (Right)	.18	27436	Timing Chain Rocker Pin. Rocker Pin Bushing.	.12
27355	Front Shock Absorber Clip (Left)	.18	27437	Timing Chain Washer	$\begin{array}{c} .02 \\ .02 \end{array}$
27356	Air Cleaner Assembly	3.50	27438	Front Spring Bracket (Right)	1.50
27357 27358	Air Cleaner Dust Cap	$\begin{array}{c} .25 \\ 14.25 \end{array}$	27439	Front Spring Bracket (Left)	1.50
27359	Differential Side Gear	6.00	27440 27441	Front Spring Bracket (Right)	$\frac{1.50}{1.50}$
27360	Bevel Ring Gear	19.00	27442	Rear Brake Rod Adjustable Yoke	.30
27361	Rear Axle Shaft	8.50	27443	Spring Bolt	. 50
27362 27363	Pinion Shaft Housing Pinion Housing Gasket	8.00	27444 27446	Front Spring Complete	4.00
27364	Drive Pinion and Shaft	9.50	27447	Trunk Rack Support (Left)	$\frac{2.50}{.40}$
27365	Pinion Shaft	11.00	27448	Trunk Rack Support (Right)	.40
27366 27367	Ball Bearing (5307)	9.00	27449	Rear Spring Bracket	.80
27368	Pinion Bearing Ret. Screw	.30	27450 27451	Horn Bracket. Idler Gear Bushing	.25
27369	Pinion Shaft Roller Bearing	1.25	27452	Countershaft Sleeve Bushing	$.25 \\ .25$
27370	Pinion Thrust Washer (Small)	.45	27455	Tire Carrier Brace	.45
27371 27372	Pinion Adjusting Nut	. 55	27456	Rear Spring Complete (9 Leaves)	5.50
27373	Pinion Ball Bearing (Outer) (5309)	$\begin{array}{c} .05 \\ 12.70 \end{array}$	27457 27459	Rear Spring Complete (7 Leaves) Spring Bolt 34"	5.50
27374	Pinion Bearing Retainer	.75	27461	Cigar Lighter.	$\frac{.35}{2.00}$
27375	Pinion Bearing Adjusting Nut	3.40	27462	Steering Gear Sector Tube Silencer	
27376 27377	Pinion Bearing Oil Guard Universal Joint Flange	2.50	27463	(Upper)	.10
27378	Universal Joint Flange Nut Washer	.05	21403	Steering Gear Sector Tube Silencer (Lower)	.10
		7.5			.10

Part No.	Part Name	Price	Part No.	Part Name	Price
27464	Rear Spring Complete	\$7.75	27538	Steering Gear Control Tube with Base	\$1.10
27465	Cylinder Block Complete1	15.00	27539	Running Board Complete (Left)	5.00
27466	Oil Pan Trough	3.75	27540	Running Board Complete (Right)	5.00
27467	Oil Delivery Pipe	4.50	27541	Running Board Moulding (Outer)	.90
27468	Crankshaft	57.00	27542	Running Board Moulding (Inner)	.45
27469	Univ. Joint Flange (Trans. End)	3.50	27543	(Right) Running Board Moulding (Inner)	11375
27470 27471	Propeller Shaft	7.75	21040	(Left)	.45
27472	Front Wheel Complete	15 00	27544	Front Floor Mat (L. D.)	2.15
27473	Rear Wheel Complete	12.50	27545	Front Floor Mat (R. D.)	2.15
27474	Demountable Rim (5" Rim)		27547	Foot Rest Bracket Complete (Left)	1.10
27475	Demountable Rim Side Ring (5" Rim)	3.00	27548	Foot Rest Bracket Complete (Right)	1.10
27476	Demountable Rim Clamp	.10	27549	Front Floor Mat (L. D.)	3.25
27477	Brake Pedal Rod (R. D.)	.40	27550	Front Floor Mat (R. D.)	3.25
27478	Grease Cup	.15	27551	Instrument Board Cowl Bar Cover Panel	6.50
27481	Throttle Operating Rod Lever (R. D.) Radiator Complete	.85	27552	Right Door Moulding	2.00
27482 27483	Radiator Complete	26 00	27553	Left Door Moulding	2.00
27484	Hood Complete	17.00	27554	Headlamp Complete	9.50
27485	Hood Complete	18.00	27555	Headlamp Complete	6.00
27486	Head Lamp Connector Plug and Cap.	.10	27556	Lighting Switch	1.85
27487	Speedometer Drive Pinion	2.10	27557	Ignition Switch with Key	2.00
27488	Speedometer Drive Pinion	2.10	27558	Ignition Switch to Gauge Wire Ignition Switch to Light Switch Wire.	.25
27489	Speedometer Drive Pinion Sleeve	.60	27559 27560	Oil Pressure Gauge	1.80
27490 27491	Tail and Stop Lamp Complete	3.50 6.50	27561	Headlamp Wire Conduit	.16
27491	Head Lamp Complete	1.65	27562	Oil Pressure Gauge Pipe with Nuts	.45
27494	Head Lamp Double Contact Plug	13	27563	Heat Indicator	2.40
27495	Front Seat Cushion	24.00	27564	Top Deck	10.50
27496	Brake Cross Shaft (R. D.)	2.25	27565	Gasoline Gauge Complete	2.75
27497	Brake Cross Shaft	2.25	27566	Top Deckth Page	9.00 1.10
27498	Windshield Swing Arm Bumper	.05	27567	Steering Gear Control Tube with Base Spark Control Tube with Lever	1.25
27499	Windshield Swing Arm Bumper		27568 27569	Front Floor Mat (L. D.)	3.25
27501	Trunk Suit Case (Per Pair) Suit Case (Per Pair)	30.00	27570	Front Floor Mat (R. D.)	3.25
27502 27503	Shift Lever Grip		27571	Hub O-meter	25.00
27504	Headlamp Complete		27572	Lighting Switch Knob and Rod	.40
27505	Head Lamp Lens	2.10	27573	Lighting Switch Knob and Rod	10014
27506	Horn Bracket	.25	08	Housing	.10
27507	R. F., L. R. Door and Left Quarter		27574	Under Door Belt Moulding	$\begin{array}{c} .65 \\ 1.30 \end{array}$
-	Glass Channel		27575 27576	Under Door Belt Moulding Under Door Belt Moulding	
27508	L. F., R. R., Door and Right Rear		27577	Under Door Belt Moulding	
27509	Quarter Glass Channel Rear Bumper Complete		27578	Under Door Belt Moulding	1.30
27511	R. F., L. R. Door, and Left Rear		27582	Side Tire Carrier Complete (Right)	3.25
ten	Quarter Glass Channel		27583	Side Tire Carrier Complete (Left)	3.25
27512	L. F., R. R. Door and Right Rear		27584	Adjustable Seat Frame	2.00
401	Quarter Glass Channel		27585	Adjustable Seat Guide Plate	.75
27513	Left Door and Right Rear Quarter		27586 27587	Adjustable Seat Worm Housing	粉色物等定
27514	Glass Channel		2.00.	(Upper)	.45
21014	Glass Channel		27588	Adjustable Seat Worm Housing	1901
27515		10.50		(Lower)	. 08
27517	Front Bumper Complete	. 10.50	27590	Adjustable Seat Worm Rod with	. 90
27518			97501	HandleAdjustable Seat Slide	
27519		85 . 3.00	27591 27592		1.25
27520 27521			27593		
27522			27594	Right Rear Scuff Plate	80
27523			27595		
27524		14	27597		
27525			97700	(R. D.)	
27526	Vacuum Tank	. 10.75	27598 27599		
27527		e .35 40	27600		5.90
27528 27529			27601		
27530			27603		
27531			27604		
27532	Head Lamp Wire Conduit	14	27605	그리고 그리고 하는 아이를 하는데 그리고 하는데 하는데 그리고 하는데 하는데 그리고 하는데 그리고 그렇게 된다.	6 3 S S S S S S S S S S S S S S S S S S
27533			27606		10 A.A. A.A. A.A.
27534			27607		
27535		35 r 3.00	27608		
2753 2753		ng 1.75	27609		
2.00	Drice or hi	ect to el		without notice	
	Trices subje		-arry c	W-1110000 100000	

		100	717 I		SIAR
Part No.	Part Name	Price	Part No.	Part Name	Price
27610	Steering Gear Mast Jacket with Bush-	8-12-1	27673	Top Boot	
UC. IL	Steering Gear Control Tube with Base	\$1.65	27674	Front Curtain Rod	80
27611	Steering Gear Control Tube with Base		27675	Center Curtain Rod	1 10
27612	Steering Gear Main Tube with Silencer	3.75	27676	Rear Curtain Rod	65
27613	Steering Gear Main Tube Silencer	40000	27677	Curtain Rod Socket	17
97614	(Upper)	.10	27678	Curtain Rod Socket	25
27614	Steering Gear Main Tube Silencer	434 4	27679	Top Strap	30
97615	(Lower)	.10	27680	Door Check Strap	. 25
27615	Steering Gear Mast Jacket with		27681	Strap Loop	02
27616	Bushing	1.65	27682	Windshield Bracket Thumb Screw	. 30
21010	Touring Body Complete (L. D.)	1 1 1 1 1 1 1 1	27683	Windshield Bracket Wing Lock Nut.	. 30
27617	Touring Body Complete (R. D.)	cation	27684	Top Bow No. 1	4.50
21011	Upon Appl	ination	27685	Top Bow No. 2.	3.30
27618	Instrument Board	3.75	27686 27687	Top Bow No. 3	3.30
27619	Left Front Door Complete	27 50	27688	Top Bow No. 4.	4.50
27620	Right Front Door Complete	27 50	27689	Top Slat Iron (Right)	17.45
27621	Left Rear Door Complete	27 50	27690	Top Slat Iron (Right) Top Slat Iron (Left)	6.25
27622	Right Rear Door Complete	27 50	27691	Top Slat Iron (Left)	17.40
27623	Rear Door Lower Bumper	.10	27692	Top Slat Iron Support	6.25
27624	Right Front and Right Rear Door		27694	Windshield Complete (Black Enamel).	.80
	Hinge (Body Half)	.40	27695	Windshield Complete (Chrome Plated)	39.00
27625	Left Front and Left Rear Door Hinge	WAS TO	27696	Windshield Glass	7 50
	(Body Half)	.40	27697	Windshield Side Arm (Right) (Black	1.00
27626	Right Front and Right Rear Door		144	Enamel)	4.50
The state of	Hinge (Door Half)	.40	27698	Windshield Side Arm (Right) (Chrome)	6 75
27627	Left Front and Left Rear Door Hinge		27699	Windshield Side Arm (Left) (Black	C8145
07400	(Door Half)	.40		Enamel)	4 50
27628	Door Lock Complete	. 80	27700	Windshield Side Arm (Left) (Chrome)	6 75
27629	Outside Door Handle	1.00	27701	Windshield Bracket (Left)	50
27630	Inside Door Handle (Right)	.20	27702	Windshield Bracket (Right)	50
27631 27632	Inside Door Handle (Left)	.20	27703	Windshield Thumb Screw (Unner)	45
27633	Door Handle Escutcheon	.70	27704	Windshield Thumb Nut (Lower)	.45
27634	Door Striker Plate	.10	27705	Windshield Pivot Stud	.09
27635	Door Dove Tail (Male) Door Dove Tail (Female)	.10	27706	Windshield Weather Strip (Lower)	.90
27636	Front Door Scuff Plate (Right)	.30	27707	Door Scuff Plate (Left)	1.50
27637	Front Door Scuff Plate (Left)	$1.10 \\ 1.10$	27708 27709	Door Scuff Plate (Right)	1.50
27638	Rear Door Scuff Plate (Right)	.80	27710	Rear Window Curtain Complete	1.50
27639	Rear Door Scuff Plate (Left)	.80	27711	Gasoline Tank Filler Cap Front Brake Lever Spring (Left)	.25
27640	Robe Rail Complete	1.00	27712	Front Brake Lever Spring (Right)	.04
27641	Robe Rail Complete	1.00	27713	"Lift the Dot" Stud No. 550	.04
27642	Front Seat Cushion	33 00	27714	Tire Carrier Brace (Right)	$02 \\ 0.40$
27643	Rear Seat Cushion	27.50	27715	Front Brake Rod (Front)	.65
27644	Right Front Door Upholstery	3.30	27716	Rear Brake Rod (Rear)	40
27645	Left Front Door Upholstery	3.30	27717	Brake Control Rod Spring	.03
27646	Right Rear Door Upholstery	2.20	27718	Brake Control Rod Spring Retainer	.03
27647	Left Rear Door Upholstery	2.20	27719	Rear Side Curtain Evelet No. 550A	.02
27648	Front Floor Mat (R. D.)	3.50	27720	"Lift The Dot" Stud No. 853	06
27649	Front Floor Mat (L. D.)	3.50	27721	Gypsy and Back Curtain Socket No. 609	06
27650	Rear Floor Carpet	8.25	27722	Side Curtain Socket No. 548	03
27651	Top Complete (Less Curtains)	and and	27723	Side Curtain Button No. 670	.04
27652	Upon Appli Top Complete (Less Curtains)	cation	27724	"Lift The Dot" Stud No. 844	.06
41004		()型化 () ()	27725	"Lift The Dot" Plate No. 844A	.04
27653	Front Side Curtain (Right)	cation	27726	Curtain "Lift The Dot" Stud No. 857	.06
27654	Front Side Curtain (Right)	12.00	27727	Side Curtain "Lift The Dot" Stud	
27655	Center Side Curtain (Right)	11 95	97790	Plate No. 708A	.03
27656	Center Side Curtain (Right)	11 25	27728 27729	Side Curtain Socket No. 608.	.08
27657	Rear Side Curtain (Right)	9 60	27730	"Lift The Dot" Stud No. 852	.06
27658	Rear Side Curtain (Right)	9.60	27731	Side Curtain Button Stud No. 552 "Lift The Dot" Stud No. 457	.07
27659	Front Side Curtain (Left)	12.50	27732	Hood Hinge Bracket (Rear)	.01
27660	Front Side Curtain (Left)	12.50	27733	Front Floor Mat (L. D.)	$\frac{.03}{2.00}$
27661	Center Side Curtain (Left)	11.25	27734	Front Floor Mat (R. D.)	
27662	Center Side Curtain (Left)	11 25	27736	Touring Body Complete (R. D.)	2.00
27663	Rear Side Curtain (Left)	9 60	200 m	Upon Appl	ication
27664	Rear Side Curtain (Left)	9.60	27737	Touring Body Complete (L. D.)	icamon
27665	Back Curtain Complete	16.50	No. of Land	Ilnon Appl	ication
		19 75	27743	Headlamp Reflector	1 95
27666	Back Curtain Complete	10.10			
27666 27667	Left Rear Gypsy Curtain	5.25	27744	Headlamp Door	2 20
27666 27667 27668	Left Rear Gypsy Curtain Right Rear Gypsy Curtain	5.25 5.25	27744 27745	Headlamp Door Screw with Retainer	2 20
27666 27667 27668 27669	Back Curtain Complete. Left Rear Gypsy Curtain Right Rear Gypsy Curtain Back Curtain Light Glass	5.25 5.25 .45	27744 27745 27746	Headlamp Door	2.20
27666 27667 27668	Back Curtain Complete. Left Rear Gypsy Curtain. Right Rear Gypsy Curtain. Back Curtain Light Glass.	5.25 5.25 .45 2.20	27744 27745	Headlamp Door	2.20 .10 .20

Part No.	Part Name	Price	Part No.	Part Name	Price
27750	Transmission Case Cover	\$4.00	27826	Clutch Shaft Cup Gear	\$22.00
27752	Gear Shift Lever Pin	.04	27827	Clutch Shaft Cup Gear Roller Bearing	8.25
27753	Gear Shift Lever Pin	.04	27828	Cup Gear Front Bearing Retainer	.10
27754 27755	Shifter ForkShifter Fork	.95	27829 27830	Cup Gear Rear Bearing Retainer First Speed Sliding Gear	7.25
27756	Instrument Panel Lamp Socket	.35	27831	Second and Reverse Sliding Gear	4.75
27757	Carburetor V-2B		27832	Third and Fourth Sliding Gear	8.00
27760	Piston Ring (Superoyl) (Standard)	. 30	27833	Sliding Gear Bearing	6.45
27761 27762	Piston Ring (Superoyl) (.005" Oversize)	.30	27835 27836	Main Drive Shaft Bearing Retainer	.07
27763	Piston Ring (Superoyl) (.010" Oversize) Piston Ring (Superoyl) (.015" Oversize)	.30	27837	Reverse Idler Gear Shaft	3.30
27764	Piston Ring (Superoyl) (.020" Oversize)	.30	27838	Countershaft	1.00
27765	Piston Ring (Superoyl) (.025" Oversize)	.30	27839	Countershaft Lock Plate	.04
27766	Piston Ring (Superoyl) (.030" Oversize)	. 30	27840	Countershaft Cluster Gear with Bush-	10.00
27767 27768	Piston Ring (Superoyl) (.035" Oversize)	.30	27841	ing	$\frac{19.00}{.35}$
27769	Ammeter Oil Pressure Gauge	$\frac{1.20}{1.45}$	27842	Speedometer Gear Housing	2.25
27770	Gear Shift Lever	2.75	27843	Speedometer Gear Housing Gasket	.02
27771	Gear Shift Lever Spring	.04	27846	Fan Blades Complete	1.30
27772	Gear Shift Lever Spring Retainer	.20	27847	Fan Hub	1.25
27773 27775	Gear Shift Lever Cover	$\begin{array}{c} .35 \\ 3.15 \end{array}$	27848 27849	Fan Spindle	$\frac{1.65}{3.50}$
27776	Front Floor Mat	3.50	27850	Propeller Shaft	7.75
27777	Front Floor Mat (R.D.)	3.50	27851	Clutch Housing with Shaft L. D	8.25
27778	Front Floor Mat	3.50	27853	Rear Motor Support	2.75
27779	Front Floor Mat (R.D.)	3.50	27854 27856	Crankshaft Counterweight Screw	.09
27780 27781	Front Floor Mat (R.D.)	$\frac{3.50}{3.50}$	21800	Brake Linings and Rivets (Unit Package)	
27782	Foot Dimmer Switch	1.00	27857	Package) Brake Linings and Rivets (Unit	
27785	Tire Cover	1.70		Package)	00
27786	Transmission Case		27858	Windshield Pivot Clamp (Left) External Brake Band Yoke Locating	.30
27787 27788	Transmission Case Gasket (Front) Transmission Lower Case Cover	1.00	27859	Nut	.08
27789	Transmission Lower Case Cover	1.00	27860	Windshield Side Arm Lower (Right)	7.00
	Gasket	.07	27861	Windshield Side Arm Lower (Left)	7.00
27790	Transmission Lower Case Cover Plug	.07	27862	Windshield Side Arm Lower Pivot	.35
27791 27792	Transmission Cap FrontTransmission Cap Gasket (Front)		27863 27864	Windshield Handle (Black Enamel) Windshield Handle (Chrome)	.15
27793	Transmission Case Cover (Upper)	.30	27865	Windshield Handle Screw (Black	.10
27794	Transmission Case Cover Gasket			Enamel)	.06
07707	(Upper)	.04	27866	Windshield Handle Screw (Chrome)	.06
27795 27796	Transmission Oil Cover		27867 27868	Windshield Pivot (Black Enamel) Windshield Pivot (Chrome)	.45 .55
27797	Shift Lever Guide Pin	.02	27869	Windshield Pivot Stud Lock	.03
27798	Shift Lever Spring	.10	27870	Windshield Pivot Cap	.35
27799	Shift Lever Ball Friction Plate	.07	27871	Windshield Pivot Cap Screw	.18
27800 27801	Shift Lever Control Cover Low Speed Plunger	$\frac{2.50}{.65}$	27872 27873	Headlamp Connector Socket Complete Carburetor Inlet Connection Screw	1.05
27802	Low Speed Plunger Spring	.04	27874	Carburetor Inlet Connection Gasket.	.05
27803	Low Speed Stop Plunger Cap	.04	27875	Clutch Throwout Bearing Spacer	.06
27804	Shifting Shaft (1st Speed)	1.50	27876	Rear Spring Complete	5.80
27805 27806	Shifting Shaft (2d and Reverse Speed) Shifting Shaft (3rd and Fourth Speed)		30045 30046	Hand Brake Lever Ratchet Use No. Hand Brake Lever Ratchet Pawl	20013
27807	Shifting Shaft Spacer	.07	00010	Use No.	26574
27808	Shifting Shaft Lock Ball Spring	. 02	30283	Carburetor GasketUse No.	
27809	Shifter Fork (1st, 3rd and 4th Speed).	.20	30405	Intake and Exhaust Manifold Stud	96576
27810 27811	Shifter Fork (2nd and Reverse Speed) Main Drive Shaft	7.00	30531	Use No. Dowel Ring	
27812	Clutch Shaft with Bushing	19.50	30547	Expansion Plug	26578
27813	Clutch Shaft Bushing	.35	30635	Special Cap ScrewUse No.	26579
27814			30928 30967	Hand Brake Lever RatchetUse No. Universal Joint Spider Bushing Ring	26580
27815	Clutch Shaft Sleeve Gear Bearing Spacer		90301	Use No.	26581
27816	Sleeve Gear Spacer Pin	.04	30972	Universal Joint Flange Bolt Nut	
27817	Sleeve Gear Thrust Washer	. 14		Use No.	
27818	Clutch Shaft Sleeve Gear Roller Brg		31085	Generator Sprocket Cover Use No.	26582
27819	RaceClutch Shaft Roller Bearing	$\frac{4.00}{3.05}$	31090	Oil Relief Valve Plug Gasket. Use No.	
27820	Clutch Shaft Rear Bearing Retainer.		31141	Oil Filler Body	
27821	Clutch Shaft Bearing Spacer	. 14	31285	Special Stud	
27822	Clutch Shaft Ball Bearing Retainer		31314 31515	Spark Plug Wire TubeUse No.	
27823 27824	Clutch Shaft Ball Bearing Oil Sling Clutch Shaft Front Bearing Retainer.		32390	Drive Pinion Housing Shim Use No.	
27825	Clutch Shaft Front Bearing Snap Ring	.07	32391	Differential BearingUse No.	
ALETA:					

Fragmitt Windshield brandis Scient (Coronal), Windshield Pivot (Linck Enaged), Windshield Pivot Teams Windshield Pivot Studikock

abilgang Campila. Ak Jali sadahir tapa laja da bini Kali tabbi sayal ajad bak

Carborrer Gasker

Carborrer Gasker

Intakn and Eghadak Marilish April

Intakn and Eghadak Marilish April

Davel Ring and assess a fire No.

Carborrer Pro.

Carborrer Const.

Hand Braker Sever Recalls. Also han Hand Braker Sever Recalls.

Part No.	Part Name	Price	Part No.	Part Name	Price
32396	Differential Bearing Adj. Nut Lock		33093	Crankshaft Starting Jaw Use No.	26709
	use No.		33094	Starting Jaw CollarUse No.	26710
32397	Differential Bearing Adjuster. Use No.	26592	33096	Valve Chamber Cover Gasket Use No.	26711
32400	Differential Side GearUse No.	26593	33102	Fly Wheel Housing Dowel Pins Use No.	
32401	Differential Pinion	26594	33127	Exhaust Valve	26713
32402	Diff. Pinion Shaft Retaining Screw	10000	33868	Connecting Rod BoltUse No.	20714
(11)	Use No.	26595	33869	Crankshaft Spacing Washer. Use No.	20714
32403	Differential Pinion Shaft Use No.		33888	Rear Bearing Filler Block Screw	20/10
32404	Differential Thrust BlockUse No.		99000		00510
The second secon			00000	Use No.	26716
32405	Differential Pinion SpacerUse No.		33892	Cylinder Head StudUse No.	26717
32406	Diff. Bearing Adj. Nut Lock Gasket		33893	Stud, $\frac{5}{16}$ "—18x1 $\frac{3}{8}$ "	26718
- 10 I	Use No.		34119	Clutch and Brake Shaft Spring Use No.	26719
32411	Differential Case Use No.	26700	34120	Brake Shaft Spring Washer Use No.	26720
33048	Oil Pump Drive Shaft Gear Use No.	26701	34276	Control Rod Spring Washer Use No.	26721
33050	Crankshaft SprocketUse No.	26702	34283	Spark Control Rod Cross Shaft Spring	10.21
33057	Camshaft Bushing (Rear)Use No.		STA CT	Use No.	
33066	Connecting Rod Bearing Shim. Use No.		34659	Oil Filler Body Cover Comp. Use No.	24450
33067	Crankshaft Thrust Shim Use No.		34687	Fly Wheel Housing Cover Codest	24409
33068	Crankshaft Thrust Shim Use No.		04001	Fly Wheel Housing Cover Gasket	00500
			94710	Use No.	
33079	Crankshaft Thrust PlateUse No.		34718	Fly Wheel Housing StudUse No.	26724
33082	Valve Chamber CoverUse No.	26708	34992	Crankshaft Oil ThrowerUse No.	26725

I minutesto fine (over the control of proper of the control of the

Spacer Sleeve tlear Spacer Pro Sleeve (Jeer 7 bits) A artis Capter Shafe Sweve Coar Textor of

Part No.	Part Name	Price	Part No.	Part Name	Price
40000	Rear Wheel (Wood)		40060	Piston Ring (Superoyl No. 3) (.035"	111111111111111111111111111111111111111
40001	Rear Wheel Hub	2.75	12.0	O. S.)	\$0.30
40002 40003	Rear Wheel Brake Drum		40061 40062	Piston Ring (Oil Grooved) (Standard) Piston Ring (Oil Grooved) (.005" O. S.)	.75 .75
40003	Demountable Rim Complete Radiator Complete	52 00	40063	Piston Ring (Oil Grooved) (.005 °C. S.)	.75
40005	Radiator Core	34.00	40064	Piston Ring (Oil Grooved) (.015" O. S.)	.75
40006 40007	Radiator Shell with Name Plate	18.00	40065 40066	Piston Ring (Oil Grooved) (.020" O. S.)	.75 .75
40007	Radiator Name Plate	.75 .45	40067	Piston Ring (Oil Grooved) (.025" O. S.) Piston Ring (Oil Grooved) (.030" O. S.)	.75
40009	Radiator Hose (Inlet)	.20	40068	Piston Ring (Oil Grooved) (.035" O. S.)	.75
40010	Radiator Hose (Outlet)	.06	40069	Piston Pin (Standard)	. 50
40011 40012	Radiator Tie Rod	$.25 \\ .02$	40070 40071	Piston Pin (.005" Oversize) Piston Pin (.010" Oversize)	.50
40012	Radiator Filler Cap Complete	1.00	40072	Connecting Rod Complete (Nos. 1-3-5	45104
40014	Starting Crank Hole Cap Complete	.70		cylinders)	4.35
40016	Rear Motor Support Insulator Com-			Note-Rod returned for new bearing will be	
40017	plete Oil Filler Body Cover Complete			accepted at full credit less a charge of \$2.40 list for new bearing.	86.44
40018	Rear Motor Support Bracket Complete	1.00	40073	Generator Strap	.18
40019	Cylinder Head	7.75	40074	Connecting Rod Bolt	.10
40020 40021	Cylinder Head Gasket Cylinder Block	08.00	40075	Crankshaft	32.00
40022	Exhaust Valve (Marked In.)	.60	40076	Crankshaft Front Bearing (Upper)	2.05
40023	Exhaust Valve (Marked Ex.)	80	40077	(Std.)	4.05
40024 40025	Valve Stem GuideValve Spring	.25		(Std.)	2.05
40026	Valve Spring Seat	.03	40078	Crankshaft Inter. Bearing (Upper)	1 90
40027	Valve Chamber Cover (Front)	.35	40079	(Std.)	1.30
40028 40029	Valve Chamber Cover Complete (Rear)	35	200.0	(Std.)	1.30
40029	Valve Chamber Cover Gasket Valve Chamber Cover Stud	.05	40080	Crankshaft Rear Bearing (Upper)	1 00
40031	Valve Tappet	.70	40081	(Std.) Crankshaft Rear Bearing (Lower)	1.60
40032	Valve Tappet Guide	1.55	40001	(Std.)	1.60
40033 40034	Oil Filler Body CompleteOil Lever Gauge Rod	.55	40082	Crankshaft Bearing Cap (Front)	.70
40035	Piston (Standard)	4.30	40083 40084	Crankshaft Bearing Cap (Inter.)	$\begin{array}{c} .70 \\ .75 \end{array}$
40036	Piston (.003" Oversize)	4.30	40085	Crankshaft Bearing Cap (Rear) Crankshaft Bearing Dowel (Upper)	.05
40037 40038	Piston (.005" Oversize) Piston (.010" Oversize)		40086	Front Bearing Filler Block	.75
40039	Piston (.015" Oversize)	4.30	40087	Rear Bearing Filler Block	
40040	Piston (.020" Oversize)	4.30	40088 40089	Crankshaft Rear Bearing Oil Guard Front Filler Block Gasket	
40041 40042	Piston (.023" Oversize)	$\frac{4.30}{4.30}$	40090	Rear Filler Block Gasket	
40042	Piston (.030" Oversize)	4.30	40091	Filler Block to Oil Pan Gasket	
40044	Piston (.035" Oversize)	4.30	40093 40094	Crankshaft Starting Jaw Collar Crankshaft Thrust Plate	
40045	Piston Ring (Plain No. 1 and 2	20	40096	Water Outlet Header	. 60
40046	(Standard) Piston Ring (Plain No. 1 and 2) (.005		40097	Water Outlet Header Gasket	.02
85	0. S.)		40098 40099	Camshaft	
40047	Piston Ring (Plain No. 1 and 2) (.010	20	40100	Camshaft Bushing Pin	
40048	O. S.)		40101	Camshaft Thrust Button	
- Theorem	0, S.)	20	40102 40103	Camshaft Thrust Button Guide Front Motor Support Plate	
40049	Piston Ring (Plain No. 1 and 2) (.020	"	40104	Motor Support to Crankcase Gasket.	
40050	O. S.)		40105	Chain Cover Complete	2.50
20000	0. S.)	20	40106	Chain Cover Gasket	
40051	Piston Ring (Plain No. 1 and 2) (.030	"	40107 40108	Crankshaft Sprocket	
40052	O. S.)		40109	Generator Drive Pulley	100
10002	0. S.)	20	40110	Timing Sprocket Drive Chain	
40053	Piston Ring (Superoyl No. 3) (Std.).		40111	Flywheel with Steel Ring Gear	
40054	Piston Ring (Superoyl No. 3) (.005 O. S.)	30	40112	Flywheel Bolt	
40055			40113 40114		
	0. S.)	30	40114		
40056		90	10110	Cover)	. 65
40057	O. S.)	30	40116		4 - 4
	0. S.)	30	40117	Oil Pan Complete	
40058			40118 40119		
40059	O. S.)		40120		
	0. S.)		40121		

Part No.	Part Name	Price	Part No.	Part Name	Price
40122	Oil Pump Drive Gear (Driven)	Descriptions	40191	Clutch Release Lever Eye Bolt	\$0.25
40123	Oil Pump Drive Shaft, Complete	1.30	40192	Clutch Spring	.10
40124	Step Plate Bracket (Lower)	.25	40193	Front Spring Cover (Front)	3.00
40125	Oil Pump Body Cover	.45	40194	Rear Spring Cover (Rear)	3.00
40126 40127	Oil Strainer Frame Complete (Upper). Oil Pressure Relief Spring, Adjusting	.60	40195 40196	Clutch Pressure Ring	2.50
40121	Washer	.01	40197	Clutch Throwout Bearing Retainer	1.20
40128	Oil Pump Suction Pipe	.45	40198	Clutch Throwout Bearing Retainer	
40129	Oil Pressure Tube Complete	.70	4.	Spring	.02
40130	Oil Filter Return Tube Complete	.30	40199	Clutch Throwout Yoke	1.75
40131 40132	Oil Filter Inlet Tube Complete Oil Filter to Crankcase Connector	.30	40200 40201	Clutch Throwout Yoke Bearing Clutch Pedal (L. D.)	.45
40133	Water Pump Body with Bushings	3.00	40202	Clutch Pedal Return Spring	$\frac{1.15}{.04}$
40134	Water Pump Body Bushing	.18	40203	Clutch Pedal Adjusting Yoke	.35
40135	Water Pump Grease Cup	.06	40204	Clutch Release Yoke "C" Washer	.01
40136	Water Pump Body to Cylinder Gasket	.01	40205	Clutch and Brake Pedal Stop Bracket	.17
40137 40138	Water Pump Impeller	$.25 \\ .70$	40206 40207	Oil SealClutch Throwout Yoke (R. D.)	1.50
40139	Step Plate Lower Bracket Clamp	.17	40208	Transmission Case	6.25
40140	Water Pump Packing Nut	.40	40209	Hand Brake Lever Stud	.16
40141	Water Pump Body Cover	1.60	40210	Hand Brake Lever Stud Spring	.05
40142 40143	Water Pump Body to Cover Gasket Water Pump Packing Gland	$.02 \\ .03$	40211 40212	Gear Shift Lever (Nickel Plated)	3.25
40143	Water Pump Packing Nut Gland	.20	40213	Gear Shift Lever (Black Enamel) Step Plate	$\frac{2.80}{.85}$
40145	Water Pump Shaft Coupling Hose	.35	40214	Step Plate Bracket (Upper)	.40
40146	Water Pump Shaft Coupling Hose	176.12	40215	Transmission Spline Shaft	3.10
40147	Clamp	. 03	40216	Transmission Oil Guard (Rear)	.03
40147 40148	Intake and Exhaust Manifold Intake and Exhaust Manifold Gasket.	9.50	40217 40218	Transmission Spline Shaft Bearing Transmission Bearing Retainer Gasket	4.10
40149	Exhaust Manifold Clamp	.07	10210	(Rear)	.02
40150	Fan Blades Complete	1.30	40219	Main Drive Gear with Bushings	6.00
40151	Fan Hub	1.30	40220	Transmission Bearing Retainer (Front)	2.35
49152 40153	Fan Hub Gasket	$\frac{.02}{1.30}$	40221	Transmission Bearing Retainer Gasket	00
40154	Fan Spindle Fender Lamp Complete, Right (Chrome	1.00	40222	(Front) Speedometer Gear Housing	1.30
707	Plated)	3.00	40223	Speedometer Gear Housing Gasket	.02
40155	Fender Lamp Complete, Left (Chrome	0.00	40224	Speedometer Drive Gear	2.50
40156	Plated) Fan Spindle Bearing	3.00	40225 40226	Hand Brake Lever (Black Enamel)	2.05
40157	Fender Lamp Base (Chrome Plated)	.35	40227	Hand Brake Lever (Nickel Plated) Hand Brake Lever Latch Rod	$\frac{2.50}{.35}$
40158	Fender Lamp Wiring Guide	1.75	40228	Hand Brake Lever Latch Rod Cap	.10
40159	Fender Lamp Door	.17	40229	Hand Brake Lever Ratchet Pawl	.13
40160 40161	Fender Lamp Lens	.20	40230 40231	Hand Brake Lever Ratchet	.25
40162	Fender Lamp Body Screw	.02	40232	Hand Brake Lever To Cross Shaft Link Fan Blade Spacer	.14
40163	Fan Belt	.90	40233	Foot Brake Pedal (L. D.)	1.20
40164	Fan Bracket	. 50	40234	Brake Pedal to Cross Shaft Link	.18
40165 40166	Motorstat Complete	2.00	40235	Brake Cross Shaft Complete	2.75
40167	Carburetor Choke Complete Fuel Pump Hole Cover	$\begin{array}{c} .75 \\ .12 \end{array}$	40236 40237	Brake Cross Shaft Complete Brake Cross Shaft Bracket (Left)	$\frac{2.55}{.17}$
40168	Fuel Pump Hole Cover Gasket	.01	40238	Brake Cross Shaft Bracket (Right)	.17
40169	Fuel Pump to Crankcase Stud	.07	40239	Brake Cross Shaft Grease Retainer	
40170	Exhaust Pipe	1.90	40240	Washer Brake Cross Shaft Bracket Shim	.01
40171 40172	Exhaust Pipe GasketExhaust Pipe Flange	.06	40240	Front Brake Rod Complete	.50
40173	Muffler Complete	1.75	40242	Rear Brake Rod Complete	.45
40174	Muffler Front Clamp	.05	40243	Brake Conduit Bracket (Front)	.18
40175	Muffler Tale Pipe Procket	1.20	40244	Brake Conduit Bracket Complete,	90
40176 40177	Muffler Tale Pipe Support Bracket Motor Underpan (Left)	.08	40245	Rear (Right)	.30
40178	Motor Underpan (Right)	.80	10110	Rear (Left)	.30
40179	Motor Underpan (Front)	.60	40246	Brake Rod Anti-Rattler	.10
40180	Gasoline Tank Complete	9.00	40247	Steering Gear Housing with Stud	2.90
40181 40182	Gasoline Gauge (Tank Unit)	1.65	40248 40249	Steering Gear Worm Wheel and Shaft Pitman Arm	$\frac{2.25}{1.30}$
40183	Gasoline Tank Strap Complete	.25	40250	Steering Gear Roller Bearing	.85
40184	Special Cut Washer (.622" I. D. x 11/4"		40251	Steering Worm	.95
4010	O. D.)	1.07	40252	Steering Gear Worm Key	.07
40185 40186	Fuel Pump to Carburetor Pipe	$\frac{1.00}{.25}$	40253 40254	Steering Gear Main Tube Steering Gear Adjusting Nut	$\frac{1.75}{.40}$
40187	Clutch Cover	1.50	40255	Steering Gear Mast Jacket	1.75
40188	Clutch Release Lever (Sets of 3)	.75	40256	Steering Gear Housing Felt Washer	
40189	Drive Pinion and Shaft	7.50	10927	(Lower)	.04
40190	Clutch Release Lever Spring	.10	40257	Expansion Plug (1¼")	.07

Part No.	Part Name	Price	Part No.	Part Name	Price
40258	Steering Wheel		40323	Left Front Door Hinge (Upper)	
40259	Spark Control Complete	.75	40324	Right Front Door Hinge (Upper)	.75
40260 40261	Throttle Control Complete		40325	Left Front Door Hinge (Lower)	.75 .75
40262	Spark Control Wire Clip	$03 \\ 04$	40326 40327	Right Front Door Hinge (Lower) Left Rear Door Hinge (Upper)	.75
40263	Throttle Rod Swivel Joint	.04	40328	Right Rear Door Hinge (Upper)	.75
40264	Accelerator Rod	.05	40329	Left Rear Door Hinge (Lower)	.75
40265	Accelerator Cross Shaft	.40	40330	Right Rear Door Hinge (Lower)	.75
40266	Accelerator Cross Shaft Bracket	.02	40331	Left Rear Door Hinge, Lower (Body	
40267	Steering Connecting Rod	2.50	10000	Half)	.40
40268 40269	Radiator Splash Apron	3.50	40332	Right Rear Door Hinge, Lower (Body	.40
40209	Radiator Splash Apron Bracket Front Fender, Right (Without Well)	$05 \\ 15.00$	40333	Half) Front Door Hinge, Upper (Body Half)	.40
40271	Front Fender, Left (Without Well)	15.00	40334	Front Door Hinge, Lower (Body Half)	.40
40272	Front Fender, Right (With Well)	19.00	40335	Rear Door Hinge, Upper (Body Half)	
40273	Front Fender, Left (With Well)	19.00	40336	Door Hinge Pin	.02
40274	Rear Fender, Right (L. D.)	7.25	40337	Left Front Door Lock and Remote	
40275	Rear Fender, Left (L. D.)	7.25	40000	Control	1.25
40276	Rear Fender, Right (R. D.)	7.25	40338	Right Front Door Lock and Remote	1.25
40277 40278	Rear Fender, Left (R. D.)	7.25	40339	ControlLeft Rear Door Lock and Remote	
40279	Side Apron (Right)	$\frac{4.00}{4.00}$	40009	Control	1.25
40280	Rear Splash Apron	6.00	40340	Right Rear Door Lock and Remote	
40281	Running Board Complete (Left)	3.75		Control	1.25
40282	Running Board Complete (Right)	3.75	40341	Door Striker Plate	.08
40283	Running Board Bolt	.03	40342	Door Dovetail (Male)	.20
40284	Running Board Moulding (Inner)	.30	40343	Door Dovetail (Female)	.50
40285 40286	Running Board Moulding (Outer)	.95	40344	Door Lock Handle (Inside) Front Door Check Strap	. 60
40287	Hood Complete	23.00	40345 40346	Rear Door Check Strap	.45
40201	Upon Appl	ication	40347	Door Check Strap Guide (Front)	.05
40288	Sedan Body Complete (R. D.)	Icavion	40348	Door Check Strap Clamp	.03
	Upon Appl	ication	40349	Front Door Glass Run Channel Felt	.25
40289	Door Complete with Glass (Left Front)	. Okeal	40350	Quarter Window Glass Run Channel	
10000	Upon Appl			Felt	.20
40290	Door Complete with Glass (Right Front		40351	Front Door Glass Upper Bumper, Felt	
40291	Upon Appl Door Complete with Glass (Left Rear)	ication	40352 40353	Rear Door Glass Upper Bumper, Felt Quarter Window Glass Upper Bumper,	
40201	Upon Appl	ication	40000	Felt	.03
40292	Door Complete with Glass (Right Rear)	1.0.	40354	Front Door Glass Lower Channel	
60.1	Upon Appl	ication	5	Rubber	.13
40293	Door Bumper (Rubber)	.12	40355	Rear Door Glass Lower Channel	
40294 40295	Door Bumper Retainer	.05	10056	Rubber	$.12 \\ .06$
40296	Door Window Regulator (Left Front) Door Window Regulator (Right Front)	$\frac{1.25}{1.25}$	40356 40357	Quarter Window Glass Lower Channel Window Glass Bumper (Rubber)	.01
40297	Door Window Regulator (Left Rear)	1.25	40358	Right Front Door Scuff Plate	1.25
40298	Door Window Regulator (Right Rear)	1.25	40359	Left Front Door Scuff Plate	1.25
40299	Quarter Window Regulator (Left)	1.25	40360	Right Rear Door Scuff Plate	. 50
40300	Quarter Window Regulator Complete	1.25	40361	Left Rear Door Scuff Plate	. 50
40301	Door Regulator Channel (Left Front).	.35	40362	Ash Receiver Complete	1.25
40302 40303	Door Regulator Channel (Right Front)	.35	40363	Hood Catch Complete	$.40 \\ .15$
40303 40304	Door Regulator Channel (Left Rear) Door Regulator Channel (Right Rear)	$.35 \\ .35$	40364 40365	Battery Inspection Cover	1.45
40305	Quarter Window Regulator Channel	.00	40366	Seat Adjuster Lower Bracket	. 55
10000	(Left)	.30	40367	Seat Adjustment Screw Shaft	.85
40306	Quarter Window Regulator Channel	.00	40368	Seat Adjuster Screw Shaft	. 80
	(Right)	.30	40369	Seat Adjuster Handle	. 60
40307	Door Window Regulator Handle	. 65	40370	Seat Adjuster Handle Screw	.07
40308	Windshield and Rear Quarter Regu-		40371	Dome Lamp Reflector and Rim	1.10
10200	lator Handle	.65	40372	Dome Lamp Glass	$.12 \\ .03$
40309 40310	Window Regulator Handle Escutcheon Regulator Handle Escutcheon Spring.	$.13 \\ .01$	40373 40374	Dome Lamp Retaining Ring Dome Lamp Switch Lever	.03
40311	Front Door Glass	3.40	40374	Left Front Door Moulding	2.25
40312	Rear Door Glass	3.40	40376	Right Front Door Moulding	2.25
40313	Rear Quarter Glass	3.25	40377	Instrument Panel Bezel	1.40
40314	Rear Quarter Glass	3.25	40378	Rear Door Moulding	2.25
40315	Rear Window Glass	2.00	40379	Left Rear Quarter Window Moulding.	2.25
40316	Front Seat Cushion	21.50	40380	Right Rear Quarter Window Moulding	
	Dans Gard Carl	(1/1)	40381	Back Window Moulding	2.25
40317	Rear Seat Cushion				
40318	Rear Seat Cushion	1.50	40382	Instrument Panel Back Plate	.70
40318 40319	Rear Seat Cushion	$\frac{1.50}{2.15}$	40382 40383	Instrument Panel Back Plate Windshield Glass	$\frac{.70}{7.00}$
40318	Rear Seat Cushion	1.50	40382	Instrument Panel Back Plate	.70

Part No.	Part Name	Price	Part No.	Part Name	Price
40387	Windshield Regulator Board Adjuster		40453	Front Motor Support Bracket (Left)	\$0.16
10000	Screw		40454	Front Spring Horn (Right)	1.25
40388	Windshield Bumper (Rubber)	$.03 \\ .04$	40455 40456	Front Spring Horn (Left)	1.25
40390	Windshield Rubber Bumper Retainer. Tail and Stop Lamp Bracket and Tube	.50	40457	Rear Spring Horn (Left)	$\frac{1.25}{1.25}$
40391	Carriage Bolt with Nut	.02	40458	Rear Spring Bracket	.45
40392	Tail Lamp and License Plate Bracket.	.10	40459	Tire Carrier Bracket (Left)	.70
40393	Tail Lamp and License Plate Bracket	10	40460 40461	Tire Carrier Bracket (Right) Tire Carrier Clamp Stud	.70
40394	(R. D.)	$.10 \\ .40$	40462	Tire Carrier Rim Lock Clamp	.08
40395	Stop Light Switch Operating Clip	.01	40463	Tire Carrier Rim Lock Clamp (Plain).	.05
40396	Lighting Switch	1.50	40464	Tire Carrier Lock Nut	.05
40397	Ignition Coil Mounting Bracket	.35	40465	Tire Carrier Tie Bar	.40
40398 40399	Horn Wire Complete	.40	40466 40467	Lock Cylinder Key Tire Carrier Complete (Left)	.25 3.75
40400	Horn Button Spring	.02	40468	Tire Carrier Complete (Right)	3.75
40401	Oil Pressure Gauge Pipe with Nuts	.50	40469	Tire Carrier Bracket	.65
40402	Gasoline Gauge Complete (On Dash).	2.60	40470	Tire Carrier Brace	.15
40403	Trunk Rack Support Arm Bracket	$\frac{1.00}{1.65}$	40471 40472	Tire Carrier Brace Bracket Front Spring Complete	.12
40404	Socket Wrench Complete Jack with Handle	$\frac{1.05}{2.75}$	40473	Front Spring Complete	4.25
40406	Front Bumper Complete	8.00	40474	Front Spring Center Bolt with Nut	.10
40407	Rear Bumper Complete (Used with	41171	40475	Rear Spring Complete (Sedan)	6.50
40400	Side Tire Carrier)	9.25	40476	Rear Spring Complete (Coupe)	6.50
40408	Rear Bumperette Complete (Used with Rear Tire Carrier)	8.50	40477 40478	Rear Spring First Leaf Bushing Rear Spring Center Bolt with Nut	.20
40409	Front Bearing (Upper) (.005" U. S.)	2.05	40479	Front Spring Bolt 3/4"-16x3" S. A. E.	.25
40410	Headlamp Complete	9.50	40480	Front Spring Bolt 34"-16x3" S. A. E Rear Spring Bolt 34"-16x3\(\frac{1}{2}\)" S. A. E. Spring Bolt Nut 34"-16 S. A. E.	.40
40411	Front Bearing (Lower) (.005" U.S.)	2.05	40481	Spring Bolt Nut 3/4"-16 S. A. E	.05
40412 40413	Headlamp Complete	9.20	40482 40483	Spring Shackle Pin (Rear)	.17
40419	Intermediate Bearing (Upper) (.005" U. S.)	1.30	40484	Rear Spring Bumper (Rubber)	.05 .14
40414	Headlamp Complete	6.10	40485	Rear Spring Bumper Bolt	. 03
40415	Intermediate Bearing (Lower) (.005"	10316	40486	Rear Spring Bumper Clip	.01
10116	U. S.)	1.30	40487 40488	Rear Spring Clip Plate	.25
40416 40417	Headlamp Complete	$\frac{5.85}{1.60}$	40489	Rear Spring Clip Plate Steering Knuckle Adjusting Washer	.04
40418	Rear Bearing (Upper) (.005" U. S.) Headlamp Reflector	2.00	40490	Front Axle "I" Beam	15.00
40419	Rear Bearing (Lower) (.005" U. S.)	1.60	40491	Steering Knuckle (Left)	7.75
40420	Headlamp Reflector	1.85	40492	Steering Knuckle (Right)	7.75
40421 40422	Oil Filter Strap	.04	40493 40494	Hub Shell Cover (For Wire Wheels) Front Spring Cover, Front (Special	1.75
40423	Deck Door Bumper, Rubber	.02		Equipment)	3.00
40424	Deck Door Bumper Retainer	.02	40495	Equipment)	1000
40425	Deck Door Lock	.65	40.400	(L. D.)	3.75
40426	Deck Door Handle with Lock and Key Front Door Moulding (Specify Finish)	$\frac{1.55}{2.35}$	40496 40497	Steering Knuckle Arm, Right (L. D.) Steering Knuckle Arm, Left (R. D.)	$\frac{1.90}{1.95}$
40428	Back Window Moulding (Standard)	1.85	40498	Steering Knuckle Arm with Ball.	
40429	Door Check Strap Clamp (Pronged)	.01		Right (R. D.). Front and Rear Brake Shoe with Lining	4.20
40430	Steering Gear Bracket with Bushing	2.65	40499	Front and Rear Brake Shoe with Lining	0.00
40431 40432	Trunk Rack Support (Left)	$.45 \\ .45$	40500	(Left) Front and Rear Brake Shoe with Lining	3.00
40432	Trunk Rack Support (Right) Cylinder Lock		40.0	(Right)	3.00
40434	Propeller Shaft with Yoke End	7.75	40501	Adjuster Wrench	. 90
40435	Hood Catch Bracket	.10	40502	neadlamp Reflector Spring	07
40436	Brake Rod Adjusting Screw	.05	40503 40504	Headlamp Door Lug	
40437 40438	Brake Rod Adjusting Screw Lock Nut Rubber Grommet	000.03	40504	Headlamp Door Lug. Headlamp Door Screw.	.10
40439	Steering Column Steady Bracket	.45	40506	Headlamp Gasket	.19
40440	Rear Fender, Right (L. D.)	7.25	40507	Brake Adjusting Screw	.06
40441	Rear Fender, Left (L. D.)	7.25	40508	Brake Adjusting Compression Spring.	.02
40442	Rear Fender, Right (R. D.)		40509 40510	Brake Adjusting Screw Washer Brake Adjusting Nut Spring Washer	.01
40443	Rear Fender, Left (R. D.)	7.25	40511	Brake Adjusting Screw Nut	.02
40444	Side Apron (Right)	4.00	40512	Clevis Pin 1/6" x 1/8"	.04
40445	Side Apron (Left)	4.00	40513	Headlamp Lens	1.75
40446	Heat Indicator Element		40514	Brake Adjuster (Right)	.35
40447	Frame Complete	38.00	40515	Brake Adjuster (Left)	.35
40448 40449	Front Cross MemberStep Hanger (Front)	1.60	40516	Brake Shoe Extension Spring	.11
40449	Step Hanger (Front)	. 55 . 55	40517 40518	Brake Shoe Extension Spring	.05
40451	Gas Tank Support Complete		40518	Brake Shoe Anti-Rattle Spring Front Brake Backing Plate Complete	.05
40452	Front Motor Support Bracket (Right)		40919	(Left)	9 95
Sep. 21 To 25	1 1 (40.800)	0		\	2.35

Part No.	Part Name	Price	Part No.	Part Name	Price
40520	Front Brake Backing Plate Complete	60.90	40584	Front and Rear Wheel Hub Cap	\$0.60
40521	(Right)		40585 40586	Rear Wheel Complete (Less Rim) Front Spring Cover, Rear (Special	12.00
40522	(Left) Rear Brake Backing Plate Complete	2.25	40587	Equipment)Ventilator Pipe	$\frac{3.00}{.35}$
40523	(Right) Headlamp Lens Retaining Spring	$\frac{2.25}{.07}$	40588 40589	Ventilator Pipe Washer Retainer Ventilator Pipe Washer (Felt)	$.02 \\ .03$
40524	Headlamp Connector Socket	1.00	40590	Distributor Adapter	.65
40525 40526	Brake Backing Plate Centralizing Cam Front Brake Adjuster Hole Cover	$.18 \\ .05$	40591	Distributor Adapter to Cylinder Head Stud	.03
40527	Rear Brake Adjusting Hole Cover	Bar Dan	40592	Distributor Drive Shaft	1.50
40528	(Left)	.05	40593 40594	Distributor Drive Shaft Thrust Washer Distributor Drive Coupling	$.10 \\ .45$
40529	(Right) Shakeproof Lock Washer ¼"	.05	40595	Horn Button Retainer Horn Button Contact Plate	.35
40530	Headlamp Connector Socket	$\begin{array}{c} .02 \\ .90 \end{array}$	40596 40597	Horn Button Insulating Washer	.00
40531 40532	Double Contact Plug. Triple Contact Plug.	$.14 \\ .17$	40598	(Fibre)	$02 \\ 04$
40533	Headlamp Wire Conduit	.25	40599	Instrument Panel Lamp Socket	. 55
40534 40535	Front Brake Cable Conduit	$\frac{2.40}{2.70}$	40600 40601	Lighting Switch Knob and Rod Lighting Switch Knob and Rod	.18
40536	Front Brake Dust Shield	.25	40001	Housing	.17
40537 40538	Front Axle Tie Rod Tie Rod Ball Stud	$.85 \\ .45$	40602 40603	Rear Window Curtain	$\frac{1.60}{1.70}$
40539	Tie Rod Adjustable Socket (Left)	1.00	40604	Rear Quarter Window Curtain	1.50
40540 40541	Tie Rod Adjustable Socket (Right) Tie Rod Ball Adjusting Plug	$1.00 \\ .11$	40605 40606	Foot Rest Complete	$\frac{1.60}{2.00}$
40542	Tie Rod Spring and Ball Seat	.09	40607	Deck Door Lock Striker Plate	.08
40543 40544	Tie Rod Ball Seat Spring. Tie Rod Dust Cover	$.01 \\ .02$	40608 40609	Deck Door Lock Striker Plate Battery Hanger	$.04 \\ .25$
40545	Tie Rod Dust Cover Spring	.02	40610	Battery Hanger Bracket (Front)	.25
40546 40547	Tie Rod Dust Cover Felt. Rear Axle Housing (Left Half)	.01	40611 40612	Battery Hanger Bracket (Rear) Battery Clamp	.25
40548	Rear Axle Housing (Right Half)	16.00	40613	Rear Door Glass Run Channel (Felt)	.20
40549 40550	Axle Shaft Felt Retainer. Felt Washer 1¼" I. D. x 2¼" O. D. x	.10	40614 40615	Windshield Complete (Closed Bodies). Frame Complete (R. D.)	
40551	%" Thick	.07	40616	Gasoline Gauge Gasket (Tank Unit)	.01
40552	Differential Case Differential Pinion Shaft	$\frac{5.25}{.65}$	40617 40618	Headlamp Wire Conduit Fender Lamp Wire (Right) (69" Long).	.80
40553 40554	Differential Pinion. Differential Side Gear	$\frac{1.00}{4.00}$	40619 40620	Fender Lamp Wire (Left) (41" Long) Brake Pedal Return Spring	$\begin{array}{c} .75 \\ .12 \end{array}$
40555	Differential Bearing	5.70	40621	Hood Handle Rivet 1/2" x 1/4"	.01
40556 40557	Differential Bearing Adjusting Nut Differential Bearing Adjusting Nut	.80	40622 40623	Rubber Grommet	.02
	Lock	.13		Upon Appl	ication
40558 40559	Bevel Ring Gear (44 Teeth) Rear Axle Shaft	$\frac{7.85}{5.00}$	40624	Door Complete with Glass (Right) Upon Appl	ication
40560	Rear Axle Shaft Bearing	3.25	40625	Door Complete with Glass (Left)	
40561 40562	Rear Axle Shaft Bearing Thrust Plate. Rear Axle Shaft Bearing Adjusting	.16	40626	Upon Appl Back Window Regulator Channel	
40563	Shim	.04	40627 40628	Front Door Glass	
	Shim	.07	40629	Front Seat Cushion	21.50
40564 40565	Rear Wheel Felt Washer Flange Felt Washer.	$.10 \\ .16$	40630 40631	Rumble Seat Cushion Deck Floor Mat	$\frac{20.00}{2.00}$
40566	Rear Wheel Felt Retainer	.07	40632	Top Deck	6.00
40567 40568	Pinion Housing Drive Pinion and Shaft (10 Teeth)	$\frac{2.90}{7.50}$	40633	Outside Door Handle with Lock and Key	1.60
40569	Pinion Roller Bearing	5.85	40634	Outside Door Handle without Lock	1.15
40570 40571	Drive Pinion Oil Seal. Pinion Bearing Spacer.	. 65	40635	Back Window Glass Upper Bumper (Felt)	
40572 40573	Pinion Bearing Shim (.005"). Pinion Bearing Shim (.015").	.02	40636	Dome Light Ground Wire	.15
40574	Pinion Housing Shim (Thin)	000.05	40637	Dome Light Wire Complete to Light Switch	.40
40575	Pinion Housing Shim (Thick)	.06	40638	Coupe Body Complete (L. D.)	
40576 40577	Propeller Shaft with Yoke End Universal Joint Flange	$7.75 \\ 2.65$	40639	Upon Appl Sedan Body Complete (L. D.)	
40578	Universal Joint Flange (Axle End)	1.60	40640	Upon Appl Sedan Body Complete (R. D.)	ication
40579 40580	Universal Joint Flange Bolt	.02		Upon Appl	ication
40581	Front Wheel (Wood)	7.00	40641	Coupe Body Complete (L. D.) Upon Appl	ication
40582 40583	Front Wheel Hub	3.00	40642	Coupe Body Complete (R. D.)	
Z0000	From wheel Drake Drum	2.25		Upon Appl	ication

40643 Parking Light Wire (Short) \$0.10 40661 Bevel Ring Gear (47 Teeth) \$0.10 40644 Parking Light Wire (Long) .16 40662 Headlamp Tire Bar 40645 Connecting Rod Complete (Nos. 2-4-6 Cylinders) 40663 Bumper Bolt Note—Rod returned for new bearing will be accepted at full credit less a charge of \$2.40 list for new bearing. 40664 Bumper Clamp 40646 Crankshaft Starting Jaw 1.25 40666 Gil Filter Return Tube Nut 40647 Damper Complete 40668 Rubber Grommet 40648 Fan Drive Pulley 7.25 40669 Steering Connecting Rod (R. D.) 40649 Headlamp Wire Conduit 16 40670 Clutch Pedal (R. D.) 40651 Damper Plate Retainer 40 40672 Clutch Pedal Adj. Sleeve (R. D.) 40652 Headlamp Wire Conduit 18 40672 Clutch Release Yoke "C" Washer (R. D.) 40653 Damper Spacer (Rubber) 17 40674 Foot Brake Pedal (R. D.) 40654 Headlamp Wire Conduit 18 40674	Price
40644 Parking Light Wire (Long) 40662 Headlamp Tire Bar 40663 Bumper Bolt <td< td=""><td>87.85</td></td<>	87.85
A0645 Connecting Rod Complete (Nos. 2-4-6 Cylinders) A0664 Bumper Bolt	2.10
Note—Rod returned for new bearing will be accepted at full credit less a charge of \$2.40 list for new bearing.	1.000
Note—Rod returned for new bearing will be accepted at full credit less a charge of \$2.40 list for new bearing.	
A0646 Crankshaft Starting Jaw 1.25 A0667 Rubber Grommet A0647 A0648 Fan Drive Pulley 7.25 A0669 Steering Connecting Rod (R. D.) A0651 Damper Plate Redlamp Wire Conduit 18 A0652 Headlamp Wire Conduit 18 A0653 Damper Spacer (Rubber) 07 A0654 Door Bumper (Rubber) 11 A0655 Under Door Belt (Front) 80 A0671 Steering Connecting Rod (R. D.) A0672 Clutch Pedal (R. D.) Clutch Pedal Adj. Sleeve (R. D.) Clutch Pedal Adj. Sleeve (R. D.) A0672 Clutch Release Yoke "C" Washer (R. D.) A0673 Foot Brake Pedal (R. D.) A0674 Foot Brake Pedal Stop Bracket (R. D.) A0675 Stop Light Switch Operating Clip	.15
40646 Crankshaft Starting Jaw 1.25 40667 Rubber Grommet 40647 Damper Complete 40668 Rubber Grommet 40648 Fan Drive Pulley 7.25 40669 Steering Connecting Rod (R. D.) 40649 Headlamp Wire Conduit 16 40670 Clutch Pedal (R. D.) 40650 Damper Plate 80 40671 Clutch Pedal Adj. Sleeve (R. D.) 40651 Damper Plate Retainer 40 40672 Clutch Release Yoke "C" Washer 40652 Headlamp Wire Conduit 18 (R. D.) (R. D.) 40653 Damper Spacer (Rubber) 07 40673 Foot Brake Pedal (R. D.) 40674 40654 Door Bumper (Rubber) 11 40675 Stop Light Switch Operating Clip	.08
40647 Damper Complete 40668 Rubber Grommet 40648 Fan Drive Pulley 7.25 40669 Steering Connecting Rod (R. D.) 40649 Headlamp Wire Conduit 16 40670 Clutch Pedal (R. D.) 40650 Damper Plate 80 40671 Clutch Pedal Adj. Sleeve (R. D.) Clutch Pedal Adj. Sleeve (R. D.) Clutch Release Yoke "C" Washer 40652 Headlamp Wire Conduit 18 40653 Damper Spacer (Rubber) 07 40673 Foot Brake Pedal (R. D.) 40654 Door Bumper (Rubber) 11 40674 Foot Brake Pedal Stop Bracket (R. D.) 40655 Under Door Belt (Front) 80 40675 Stop Light Switch Operating Clip	.02
40648 Fan Drive Pulley 7.25 40669 Steering Connecting Rod (R. D.) 40649 Headlamp Wire Conduit 16 40670 Clutch Pedal (R. D.) 40650 Damper Plate 80 40671 Clutch Pedal Adj. Sleeve (R. D.) 40651 Damper Plate Retainer 40 40672 Clutch Release Yoke "C" Washer 40652 Headlamp Wire Conduit 18 (R. D.) (R. D.) 40653 Damper Spacer (Rubber) 07 40673 Foot Brake Pedal (R. D.) 40655 Under Door Belt (Front) 80 40675 Stop Light Switch Operating Clip	.02
40649 Headlamp Wire Conduit 16 40670 Clutch Pedal (R. D.) 40650 Damper Plate 80 40671 Clutch Pedal Adj. Sleeve (R. D.) 40651 Damper Plate Retainer 40 40672 Clutch Release Yoke "C" Washer 40652 Headlamp Wire Conduit 18 (R. D.) 40653 Damper Spacer (Rubber) 17 40673 Foot Brake Pedal (R. D.) 40655 Under Door Belt (Front) 80 40675 Stop Light Switch Operating Clip	2.50
40650 Damper Plate 80 40671 Clutch Pedal Adj. Sleeve (R. D.) 40651 Damper Plate Retainer 40 40672 Clutch Release Yoke "C" Washer 40652 Headlamp Wire Conduit 18 (R. D.) (R. D.) 40653 Damper Spacer (Rubber) 10 40673 Foot Brake Pedal (R. D.) 40655 Under Door Belt (Front) 80 40675 Stop Light Switch Operating Clip	1.15
40652 Headlamp Wire Conduit. 18 (R. D.)	
40652 Headlamp Wire Conduit. 18 (R. D.)	STUR
40653Damper Spacer (Rubber).0740673Foot Brake Pedal (R. D.)40654Door Bumper (Rubber).1140674Foot Brake Pedal Stop Bracket (R. D.)40655Under Door Belt (Front).8040675Stop Light Switch Operating Clip	.01
40655 Under Door Belt (Front)	1.20
40655 Under Door Belt (Front)	.17
40656 Under Door Belt (Rear)	Table.
CONTRACTOR OF THE CONTRACTOR O	.01
40657 Special Finished Washer	2.75
40658 Flared Tube Nut, ¼"	.05
40659 Oil Filter Inlet Tube Elbow .08 40678 Body Shim (Rubber) 40660 Front Motor Bolt .04 40679 Body Shim (Rubber)	.03
4000 Finit Motor Bott	.02
Policing the property of the contract of the c	
APLA - AND	1804
FO	
t The Roy Link Step Spring Town Lot 1980s Deed Door Lots Suffer Plates. Little States Links Link	LEGIA
	Hous.
	MALES.
ather the second control of the second secon	
Felt Washer 14, L.D. x 212, O.D. z	ALLE .
After the state of	

Prices subject to change without notice

this Designific deligned took

STANDARD PARTS

Part No	D	Part Name CO " CIT AN Adda W to Chinada Sta	Price
M- 1	1137	Hex. Head Cap Screw, 3/8"—24x31/2" S.A.E	\$0.06
R- 1	137	Hex. Head Cap Screw, $\frac{3}{8}''$ —24x3 $\frac{3}{4}''$ S.A.E	.08
I- 1	1138	Hex. Head Cap Screw, $\frac{76}{6}$ — 20x4° S.A.E.	.08
M- 1	1140	Hex. Castle Nut, 1¼"—12 S.A.E.	.14
A- 1		Hex. Nut, ½"—20 S.A.E.	.05
B- 1		How Hood Can Canow 3/" 1Cv21/" II C C	.05
I- 1		Hex. Head Cap Screw, $\frac{3}{8}$ "—16x3 $\frac{1}{2}$ " U.S.S. Round Head Iron Rivet, $\frac{5}{16}$ "x1 $\frac{5}{16}$ ".	.08
R- 1		Woodruff Key No. 6	.02
B- 1		Woodruff Key No. 9.	.02
IC- 1		Woodruff Key No. 13.	.02
D- 1		Woodruff Key No. 11	.02
E- 1		Woodruff Key No. 3.	.02
F- 1		Woodruff Key No. 5 Woodruff Key No. 25	.02
H- 1		Woodruff Key No. 15.	.02
	1149	Woodruff Key No. A	.02
U- 1		Woodruff Key No. 18	.04
	1149	Woodruff Key No. 21	.05
B- 1		Clevis Pin, 5%"x25%2" Clevis Pin, 3%"x29%2" Clevis Pin, 3%"x141%4"	.02
D- 1		Clevis Pin. 3 x 1414,"	.07
E- 1		Clevis Pin, 38"x1". Clevis Pin, 56"x18". Clevis Pin, 56"x18".	.03
H-		Clevis Pin, 5/6"x13/6"	.04
J-	1223	Clevis Pin, 38" x116". Clevis Pin, 308" .310"x116".	.03
	1223	Clevis Fili, 300 310 X ¹ / ₁₆	.02
	1223	Clevis Pin, ¼"x5%". Clevis Pin, ¼"x115½".	.05
S-	1223	Clevis Pin, 433" 435"x1". Clevis Pin, 371" 373"x1'\(\frac{3}{2}\)".	.04
	1223	Clevis Pin, 371" 373"x1%"	.05
	1223 1223	Clevis Pin. %"X11%"	.05
	1223	Clevis Pin, 5%"x 34". Clevis Pin, 5%"x29\(\frac{1}{2}\)".	.03
	1223	Clevis Pin, 308" 310"x 76". Clevis Pin, 183" .185"x 154". Clevis Pin, 371" .373"x 174".	.06
2C-		Clevis Pin, 183" 185"x15'x"	.03
2D-		Clevis Pin, .371" .373"x17 ₆ "	.04
2E- 2K-		Clevis Fin, % X1 1/42 Clavis Pin 3.6 V-25.6 V	.04
2M-		Clevis Pin, 3%"x1"14" Clevis Pin, 3%"x25%" Clevis Pin, 76"x1"3%" Clevis Pin 3%" x 116" Clevis Pin 3%" x 116" Clevis Pin 3%" x 116"	.04
20-		Clevis Pin 3%" x 11/6"	.05
2Q-		Clevis Pin, 433" 435"x1834". Carriage Bolt, with Nut, 38"—16x2" U.S.S. Carriage Bolt with Nut, 38"—16x1½" U.S.S. Carriage Bolt with Nut, 38"—16x2" U.S.S. Carriage Bolt with Nut, 38"—16x2" U.S.S. Use No.	.04
	1241 1241	Carriage Bolt, with Nut, $\frac{3}{6}$ "—16x2" U.S.S	.10
	1241	Carriage Bolt with Nut. 3%"—16x2" U.S.S. Use No.	26850
	1322	Round Head Carriage Bolt with Nut, ¼"—20x3" U.S.S. Hex. Mach. Nut No. 10-32	.08
	1324	Hex. Mach. Nut No. 10-32	.01
	1327 1328	Rd. Hd. Mach. Screw 1/4"—20x5%"	.01
	1334	Flat Head Machine Screw, No. 10—24x3 1/4". Felt Washer, 21/6" I D. 23/4" O D. 3/6" thick	.06
400	1334	Felt Washer, 2½" I.D., 2 ⁵⁵ / ₄₄ " O.D., ½" thick.	.20
2C-		Felt Washer, 11/6" I.D., 11/4" O.D., 1/8" thick.	.03
2D- 2K-		Felt Washer, 2½" I.D., 2¾" O.D., ¾" thick. Felt Washer, 2½" I.D., 2⁵½" O.D., ½" thick. Felt Washer, ¹¼" I.D., 1¼" O.D., ½" thick. Felt Washer, 1½" I.D., 2⁵½" O.D., ½" thick. Felt Washer, 1½" I.D., 2¾" O.D., ½" thick. Felt Washer, 1½" I.D., 2¾" O.D., ½" thick.	.20
	1334	Felt Washer 11/" ID 91/" OD 1/" thick	.07
	1335	Special Finished Washer, 21 I.D. x1 1/4" O.D. x 1/4" thick.	.03
	1335	Special Finished Washer, 1.185" I.D., 19/6" O.D., .154" thick	.05
	1335	Special Finished Washer, 33/4" I.D., x1" O.D., 109" thick	.03
	1335 1335	Special Finished Washer, 1/2" I.D., X/8" U.D., 1/8" thick	.03
	1335	Special Finished Washer, 21/6" I.D., 13/8" O.D., 78 thick	.03
	1335	Special Finished Washer, 21/2" I.D., 13/8" O.D., 3/6" thick.	.03
	1335	Special Finished Washer, 25/2" I.D., 15/6" O.D.	.05
	1336 1336	Cut Washer, ½" I.D., 1½" O.D.	.02
	1336	Cut Washer. 3/" I.D., 7/4" O.D.	.01
	1336	Felt Washer, 1½ " I.D., 2½ " O.D., ½ " thick. Felt Washer, 1½ " I.D., 2½ " O.D., ½ " thick. Special Finished Washer, 1½ " I.D., x1½ " O.D., x ½ " thick. Special Finished Washer, 1.185" I.D., 1½ " O.D., 154" thick. Special Finished Washer, 1½ " I.D., x1" O.D., 109" thick Special Finished Washer, 1½ " I.D., x½ " O.D., ½ " thick. Special Finished Washer, 1½ " I.D., 1½ " O.D., ½ " thick. Special Finished Washer, 1½ " I.D., 1½ " O.D., ½ " thick. Special Finished Washer, 1½ " I.D., 1½ " O.D., ½ " thick. Special Finished Washer, 15½ " I.D., 1½ " O.D., ½ " thick. Special Finished Washer, 15½ " I.D., 1½ " O.D., ½ " thick. Special Finished Washer, 15½ " I.D., 1½ " O.D. Cut Washer, ½ " I.D., 1¼ " O.D. Cut Washer, ½ " I.D., 1¾ " O.D.	.02
	1336	Cut Washer, $\sqrt{6}$ I.D., 1" O.D	.01

Part N	0.	Part Name	Price
	1336	Cut Washer, ¼" I.D., ½" O.D Special Cut Washer, ¼" I.D., 1" O.D Special Cut Washer, ½" I.D., 1½" O.D. Special Cut Washer, ½" I.D., ¾" O.D. Special Cut Washer, ½" I.D., 1½" O.D. Special Cut Washer, ½" I.D., ½" O.D. Special Cut Washer, ½" I.D., ½" O.D.	\$0.01
	1422	Special Cut Washer, 4 4 I.D., 1 O.D.	.03
	1422	Special Cut Washer, 254" I.D., 11/2" O.D.	.03
	1422	Special Cut Washer, 254, I.D., 54, O.D.	.02
	1422 1422	Special Cut Washer, 78 I.D., 174 O.D.	.03
	1422	Special Cut Washer, 15/2" I.D., 1" O.D.	.03
	1422	Special Cut Washer, 4944" I.D., 1" O.D.	.02
1	1422	Special Cut Washer, 294 I.D., 34 O.D.	.02
	1422	Special Cut Washer, 1.D., 5% O.D	.02
	1422	Special Cut Washer, 113/6" I.D., 23/6" O.D.	.07
	1422 1422	Special Cut Washer, 12, 17, 17, 0.D.	.04
	1422	Special Cut Washer, ¹⁵ / ₂₆ " I.D., 1" O.D. Special Cut Washer, ⁴⁹ / ₄₄ " I.D., 1" O.D. Special Cut Washer, ²⁹ / ₄₄ " I.D., ⁵ / ₈ " O.D. Special Cut Washer, ¹¹ / ₂₆ " I.D., ² / ₈ " O.D. Special Cut Washer, ¹¹ / ₁₄ " I.D., ²³ / ₆ " O.D. Special Cut Washer, ¹¹ / ₄₄ " I.D., ¹⁵ / ₈ " O.D. Special Cut Washer, ¹¹ / ₄₄ " I.D., ¹¹ / ₄ " O.D. Special Cut Washer, ¹¹ / ₂₂ " I.D., ¹¹ / ₆ " O.D. Special Cut Washer, ¹¹ / ₂₂ " I.D., ¹¹ / ₆ " O.D. Special Cut Washer, ¹³ / ₂₂ " I.D., ¹⁸ / ₆ " O.D. Special Cut Washer, ¹³ / ₄₄ " I.D., ¹⁴ / ₄ " O.D. Special Cut Washer, ¹⁴ / ₄₄ " I.D., ¹⁴ / ₄ " O.D. Special Cut Washer, ²⁵ / ₂₄ " I.D., ¹⁴ / ₄ " O.D. Special Cut Washer, ²⁵ / ₂₄ " I.D., ¹⁴ / ₄ " O.D. Special Cut Washer, ²⁵ / ₂₄ " I.D., ¹⁴ / ₄ " O.D. Special Cut Washer, ²⁵ / ₂₂ " I.D., ¹⁴ / ₄ " O.D. Special Cut Washer, ²⁵ / ₂₂ " I.D., ¹¹ / ₄ " O.D. Special Cut Washer, ¹⁵ / ₂₄ " I.D., ¹¹ / ₄ " O.D. Special Cut Washer, ¹⁵ / ₂₄ " I.D., ¹¹ / ₄ " O.D. Special Cut Washer, ¹⁵ / ₂₂ " I.D., ¹¹ / ₄ " O.D.	.02
	1422	Special Cut Washer, 1922" I.D., 1" O.D.	.03
	1422	Special Cut Washer, ¹³ / ₈₂ I.D., ⁷ / ₈ O.D.	. 03
	1422	Special Cut Washer, %" I.D., 34" O.D.	.02
	1422	Special Cut Washer, 144 I.D., 144 U.D.	.05
	1422 1422	Special Cut Washer, 7,44 I.D., 7/6 C.D.	.02
21-	1422	Special Cut Washer. 21.0" I.D. 11.1" O.D.	.03
2M-	1422	Special Cut Washer, 17,2" I.D., 1" O.D.	.03
20-	1422	Special Cut Washer, 2½" I.D., 1½" O.D. Special Cut Washer, 1½" I.D., 1½" O.D. Special Cut Washer, 1½" I.D., 1½" O.D. Special Cut Washer, 1½" I.D., 1½%" O.D. Special Cut Washer, 2½" I.D., 1½%" O.D. Special Cut Washer, 1¾¼" I.D., 1½%" O.D. Special Cut Washer, 1¾¼" I.D., 1½" O.D. Special Cut Washer, 1¾½" I.D., 1½%" O.D. Special Cut Washer, 1¾½" I.D., 1½%" O.D. Special Cut Washer, 1¾½" I.D., 3¾" O.D. Special Cut Washer, 1¼¼" I.D., 3¾" O.D. Special Cut Washer, 1¼¼" I.D., 1¾%" O.D. Special Cut Washer, 1¼¼" I.D., 1¾%" O.D. Special Cut Washer, 1½%" I.D., 1¾%" O.D. Special Cut Washer, 1½%" I.D., 1¾%" O.D. Special Cut Washer, 1½%" I.D., 1½%" O.D.	.02
2Q-	1422	Special Cut Washer, 1" I.D., 1254" O.D.	.03
2R-	1422	Special Cut Washer, 25 I.D., 178 U.D.	.03
20-	1422	Special Cut Washer, 732 I.D., 178 C.D.	.02
3A-	1422A	Special Cut Washer, 25, I.D., 15, O.D.	.03
3B-	1422A	Special Cut Washer, 1%4" I.D., %6" O.D.	.01
3H-	1422A	Special Cut Washer, 294 I.D., 11/2" O.D.	.03
3I-	1422A	Special Cut Washer, 3/2" I.D., 1½%" O.D.	.03
3L-	1422A	Special Cut Washer, 15, 1D., 94 U.D.	.02
30-	1422A	Special Cut Washer, 784 I.D., 78 O.D.	.03
3V-	1422A	Special Cut Washer, 214" I.D., 58" O.D.	.02
4D-	1422A	Special Cut Washer, ²¹ 6, I.D., ¹⁹ 2, O.D.	.03
4L-	1422A	Special Cut Washer, 1 1 1.D., 1 1. U.D., 1 1. U.D.	.03
4P-	1422A	Special Cut Washer, 1½" I.D., 2.555 U.D.	.04
4W-	1422A	Special Cut Washer, 1,22 I.D., 1,4 O.D.	.04
A-	1476	Special Cut Washer, 11/2" I.D., 1" O.D. Flared Tube Elbow, 1/4" x 1/8" S.A.E. Flared Tube Elbow, 5/6" x 1/8" S.A.E.	.08
В-	1476	Flared Tube Elbow, 5/6"x 1/8" S.A.E	.08
C-	1476	Flared Tube Elbow, % x\frac{1}{8}" S.A.E. Flared Tube Union Nut, \frac{1}{2}" x20 S.A.E. Flared Tube Union Nut, \frac{1}{46}" x20 S.A.E.	.08
400	1477	Flared Tube Union Nut, 7% XZU S.A.E.	.06 .06
1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	1477 1477	Flared Tube Union Nut. 36 x24 S A E.	.05
	1478	Flared Tube Union Nut, 38"x24 S.A.E Flared Tube Union, ½"x20 S.A.E Flared Tube Union, ½"x20 S.A.E	.06
	1478	Flared Tube Union, 76 x20 S.A.E.	.07
	1478	Flared Tube Union, $\frac{3}{8}$ "—24 S.A.E. Flared Tube Union, $\frac{5}{8}$ "—18 S.A.E. Flared Tube Union, $\frac{1}{16}$ "x16 S.A.E.	.06
2 2 2 2	1478	Flared Tube Union, % —18 S.A.E.	.07
	1478 1548	Down d Hood Coming Rolf with Nilt	05
12 - I - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	2039	Oval Countersunk Head Cap Screw, 5/6"—18x11/4" U.S.S. Oval Countersunk Head Cap Screw, 5/6"—18x3" U.S.S.	.06
	2039	Oval Countersunk Head Cap Screw, 5/6"—18x3" U.S.S.	.10
	2039	Oval Countersunk Head Cap Screw, 5%"—18x½" U.S.S. Oval Countersunk Head Cap Screw, 5%"—18x½" U.S.S. Square Head Machine Bolt, 3%"—16x3" U.S.S. Square Head Machine Bolt, 3%"x2½".	.04
	2039	Uval Countersunk Head Cap Screw, %6 — 18x % U.S.S	.04
	2625 2625	Square flead Machine Bolt, 78 — 103 0.5.5.	04
	3297	Taper Pin. No. 2x1 %	.05
	3324	Taper Pin, No. 0—1	.05
	5140	Flat Head Tubular Rivet, ½ "x½"	.01
	5800	Special Cut Washer, *%4" I.D., I*%2" U.D. Ston Polt with Nut 32"_16x232" II S S	.03
	7235 7235	Sten Rolt with Nut. 3%"—16x21/" U.S.S.	.06
	8026	Step Bolt, with Nut, \\(\frac{1}{2} \)"—18x1\(\frac{1}{2} \)" U.S.S.	.05
	8026	Step Bolt, with Nut, 5/6"—18x5" U.S.S	. 09
G-	8026	Step Bolt, with Nut, 5/6"—18x4" U.S.S	.08
	8026	Step Bolt, with Nut, %6"—18x1 4" U.S.S	.05
	8026	Step Rolt with Nut. 56"—18x41/" IISS	.08
	8026 8026	Step Bolt, with Nut. \(\frac{5}{6}'' \)—18x2\(\frac{2}{3}''' \) U.S.S.	.06
	8612	Taper Pin, No. $0-1''$. Flat Head Tubular Rivet, $\frac{5}{2}$ " $x^{\frac{5}{2}}$ ". Special Cut Washer, $\frac{4}{2}$ ", $\frac{1}{1}$ I.D., $\frac{1}{1}$ 1.5. $\frac{1}{2}$ " O.D. Step Bolt, with Nut, $\frac{3}{2}$ " $-16x^{\frac{5}{2}}$ Y" U.S.S. Step Bolt, with Nut, $\frac{5}{4}$ " $-18x^{\frac{5}{2}}$ Y" U.S.S. Step Bolt, with Nut, $\frac{5}{4}$ " $-18x^{\frac{5}{2}}$ U.S.S. Step Bolt Wire (No. $15x^{\frac{5}{2}}$ U.S.S.	.06
J-		Spring Steel Wire (No. 15x41" long) (Cut to Fit) Oval Countersunk Head Wood Screw, No. 9x1" N.P.	.05
A-	9765	Oval Countersunk Head Wood Screw, No. 9x1" N.P	.02

Part No.	Part Name		Price
2X-10360	Oval Head Machine Screw, 1/4"—20x4"		\$0.06
2Y-10360	Oval Head Machine Screw, ½"—20x3½"		.05
A-12359	Flared Tube Union Nut, 3/2"—24 S.A.E		
D-12359	Flared Tube Union Nut 5% -18 S A E	e income	. 12
F-12359	Flared Tube Union Nut, (¾"—16). Hex. Check Nut, ¾"—24 S.A.E		.03
C-12693	Hex. Check Nut. 3/8"—24 S.A.E		.06
D-12693	Hex. Check Nut. 1/6"—20 S.A.E		.06
E-12693	Hex. Check Nut, ½"—20 S.A.E Hex. Check Nut, ½"—20x¼" thick, U.S.F		.07
A-15307	Special Toggle Bolt, (13/4" long)		. 09
H-15307	Special Toggle Bolt (2" long)		10
C-21637	Flat Head Stove Bolt with Nut, $\frac{1}{4}''-20x\frac{5}{8}''$. Flat Head Stove Bolt with Nut, $\frac{1}{4}''-20x\frac{1}{8}''$.		.08
G-21637	Flat Head Stove Bolt with Nut, $\frac{1}{4}$ "— $20x1\frac{1}{8}$ "		.02
H-21637	Flat Head Stove Bolt with Nut, $\frac{1}{4}''$ —20x1 $\frac{1}{4}''$.02
B-21642	Flat Head Stove Bolt with Nut, $\frac{1}{4}''$ — $20x1\frac{1}{4}''$.05
C-21642	Round Head Stove Rolt with Nut No. 10-23v5/"		02
B-21644	Round Head Stove Bolt with Nut, $\frac{1}{4}$ "— $20x\frac{1}{2}$ " Round Head Stove Bolt with Nut, $\frac{1}{4}$ "— $20x\frac{1}{2}$ "		.02
C-21644	Round Head Stove Bolt with Nut, $\frac{1}{4}''-20x\frac{5}{6}''$.02
D-21644	Round Head Stove Bolt with Nut. $\frac{1}{3}$ "— $\frac{20x^3}{3}$ "		. 02
F-21644	Round Head Stove Bolt with Nut. 1/4"—20x1"		.02
G-21644	Round Head Stove Bolt with Nut, 1/4"—20x11/8" Round Head Stove Bolt with Nut, 1/4"—20x13/8"		.02
J-21644	Round Head Stove Bolt with Nut, $\frac{1}{4}$ "—20x1 $\frac{3}{8}$ "		.02
C-21645	Round Head Stove Bolt with Nut. %"—18x%"		. 02
I-21645	Round Head Stove Bolt with Nut. \[\frac{5}{6}'' \]—\(18x\) \[\frac{1}{4}'' \]		.02
H-26180	Standard S.A.E. Washer, 11/22" I.D.—11/16" O.D.—1/16" thick		.03
D-27334	Inverted Flared Tube Nut		.05
C-27335	Flared Tube Connector. Hex. Check Nut 5/16"—24 S. A. E.		.05
114493	Hex. Check Nut 5/6"—24 S. A. E		.02
114785	Clevis Pin, 3/8" x 13/2"		.05
118537	Flared Tube Union Nut ¼"		.06
109741	Carriage Bolt, 5/6"—18 x 3/4"		.02
122587	Hex. Hd. Cap Screw. \%"—12x1\%" U. S. S		.07
122600	Hex. Hd. Cap Screw, %6"—12x1%" U. S. S.		.07

MEMORANDUM A SECOND STREET OF SECOND STREET SECOND STREET

